# **HD-Audio Codec-Specific Models**

## **ALC880**

3stack

3-jack in back and a headphone out

3stack-digout

3-jack in back, a HP out and a SPDIF out

5stack

5-jack in back, 2-jack in front

5stack-digout

5-jack in back, 2-jack in front, a SPDIF out

6stack

6-jack in back, 2-jack in front

6stack-digout

6-jack with a SPDIF out

6stack-automute

6-jack with headphone jack detection

#### ALC260

gpio1

Enable GPIO1

coef

Enable EAPD via COEF table

fujitsu

Quirk for FSC S7020

fujitsu-jwse

Quirk for FSC S7020 with jack modes and HP mic support

#### ALC262

inv-dmic

Inverted internal mic workaround

fsc-h270

Fixups for Fujitsu-Siemens Celsius H270

fsc-s7110

Fixups for Fujitsu-Siemens Lifebook S7110

hp-z200

Fixups for HP Z200

tyan

Fixups for Tyan Thunder n6650W

lenovo-3000

Fixups for Lenovo 3000

benq

Fixups for Benq ED8

benq-t31

Fixups for Benq T31

bayleybay

Fixups for Intel BayleyBay

#### ALC267/268

inv-dmic

Inverted internal mic workaround

hp-eapd

Disable HP EAPD on NID 0x15

spdif

Enable SPDIF output on NID 0x1e

ALC22x/23x/25x/269/27x/28x/29x (and vendor-specific ALC3xxx models)

```
laptop-amic
        Laptops with analog-mic input
        Laptops with digital-mic input
alc269-dmic
        Enable ALC269(VA) digital mic workaround
alc271-dmic
        Enable ALC271X digital mic workaround
inv-dmic
        Inverted internal mic workaround
headset-mic
        Indicates a combined headset (headphone+mic) jack
headset-mode
        More comprehensive headset support for ALC269 & co
headset-mode-no-hp-mic
        Headset mode support without headphone mic
lenovo-dock
        Enables docking station I/O for some Lenovos
hp-gpio-led
        GPIO LED support on HP laptops
hp-dock-gpio-mic1-led
        HP dock with mic LED support
dell-headset-multi
        Headset jack, which can also be used as mic-in
dell-headset-dock
        Headset jack (without mic-in), and also dock I/O
dell-headset3
        Headset jack (without mic-in), and also dock I/O, variant 3
dell-headset4
        Headset jack (without mic-in), and also dock I/O, variant 4
alc283-dac-wcaps
        Fixups for Chromebook with ALC283
alc283-sense-combo
        Combo jack sensing on ALC283
tpt440-dock
        Pin configs for Lenovo Thinkpad Dock support
tpt440
        Lenovo Thinkpad T440s setup
tpt460
        Lenovo Thinkpad T460/560 setup
tpt470-dock
        Lenovo Thinkpad T470 dock setup
dual-codecs
        Lenovo laptops with dual codecs
alc700-ref
        Intel reference board with ALC700 codec
vaio
        Pin fixups for Sony VAIO laptops
dell-m101z
         COEF setup for Dell M101z
asus-g73jw
        Subwoofer pin fixup for ASUS G73JW
lenovo-eapd
        Inversed EAPD setup for Lenovo laptops
sony-hweq
        H/W EQ COEF setup for Sony laptops
pcm44k
        Fixed PCM 44kHz constraints (for buggy devices)
lifebook
        Dock pin fixups for Fujitsu Lifebook
lifebook-extmic
        Headset mic fixup for Fujitsu Lifebook
lifebook-hp-pin
        Headphone pin fixup for Fujitsu Lifebook
lifebook-u7x7
```

```
Lifebook U7x7 fixups
alc269vb-amic
        ALC269VB analog mic pin fixups
alc269vb-dmic
        ALC269VB digital mic pin fixups
hp-mute-led-mic1
        Mute LED via Mic1 pin on HP
hp-mute-led-mic2
        Mute LED via Mic2 pin on HP
hp-mute-led-mic3
        Mute LED via Mic3 pin on HP
hp-gpio-mic1
        GPIO + Mic1 pin LED on HP
hp-line1-mic1
        Mute LED via Line1 + Mic1 pins on HP
noshutup
        Skip shutup callback
sony-nomic
        Headset mic fixup for Sony laptops
aspire-headset-mic
        Headset pin fixup for Acer Aspire
asus-x101
        ASUS X101 fixups
acer-ao7xx
        Acer AO7xx fixups
acer-aspire-e1
        Acer Aspire E1 fixups
acer-ac700
        Acer AC700 fixups
limit-mic-boost
        Limit internal mic boost on Lenovo machines
asus-zenbook
        ASUS Zenbook fixups
asus-zenbook-ux31a
        ASUS Zenbook UX31A fixups
ordissimo
        Ordissimo EVE2 (or Malata PC-B1303) fixups
asus-tx300
        ASUS TX300 fixups
alc283-int-mic
        ALC283 COEF setup for Lenovo machines
mono-speakers
        Subwoofer and headset fixupes for Dell Inspiron
alc290-subwoofer
        Subwoofer fixups for Dell Vostro
thinkpad
        Binding with thinkpad acpi driver for Lenovo machines
dmic-thinkpad
        thinkpad_acpi binding + digital mic support
alc255-acer
        ALC255 fixups on Acer machines
alc255-asus
        ALC255 fixups on ASUS machines
alc255-dell1
        ALC255 fixups on Dell machines
alc255-dell2
         ALC255 fixups on Dell machines, variant 2
alc293-dell1
        ALC293 fixups on Dell machines
alc283-headset
        Headset pin fixups on ALC283
aspire-v5
         Acer Aspire V5 fixups
hp-gpio4
```

GPIO and Mic1 pin mute LED fixups for HP

```
hp-gpio-led
        GPIO mute LEDs on HP
hp-gpio2-hotkey
        GPIO mute LED with hot key handling on HP
hp-dock-pins
        GPIO mute LEDs and dock support on HP
hp-dock-gpio-mic
        GPIO, Mic mute LED and dock support on HP
hp-9480m
        HP 9480m fixups
alc288-dell1
        ALC288 fixups on Dell machines
alc288-dell-xps13
        ALC288 fixups on Dell XPS13
dell-e7x
        Dell E7x fixups
alc293-dell
        ALC293 fixups on Dell machines
alc298-dell1
        ALC298 fixups on Dell machines
alc298-dell-aio
        ALC298 fixups on Dell AIO machines
alc275-dell-xps
        ALC275 fixups on Dell XPS models
lenovo-spk-noise
        Workaround for speaker noise on Lenovo machines
lenovo-hotkey
        Hot-key support via Mic2 pin on Lenovo machines
dell-spk-noise
        Workaround for speaker noise on Dell machines
alc255-dell1
        ALC255 fixups on Dell machines
alc295-disable-dac3
        Disable DAC3 routing on ALC295
alc280-hp-headset
        HP Elitebook fixups
alc221-hp-mic
        Front mic pin fixup on HP machines
alc298-spk-volume
        Speaker pin routing workaround on ALC298
dell-inspiron-7559
        Dell Inspiron 7559 fixups
ativ-book
        Samsung Ativ book 8 fixups
alc221-hp-mic
        ALC221 headset fixups on HP machines
alc256-asus-mic
        ALC256 fixups on ASUS machines
alc256-asus-aio
        ALC256 fixups on ASUS AIO machines
alc233-eapd
        ALC233 fixups on ASUS machines
alc294-lenovo-mic
        ALC294 Mic pin fixup for Lenovo AIO machines
alc225-wyse
        Dell Wyse fixups
alc274-dell-aio
        ALC274 fixups on Dell AIO machines
alc255-dummy-lineout
        Dell Precision 3930 fixups
alc255-dell-headset
        Dell Precision 3630 fixups
alc295-hp-x360
        HP Spectre X360 fixups
alc-sense-combo
```

Headset button support for Chrome platform

huawei-mbx-stereo

Enable initialization verbs for Huawei MBX stereo speakers; might be risky, try this at your own risk

alc298-samsung-headphone

Samsung laptops with ALC298

alc256-samsung-headphone

Samsung laptops with ALC256

### ALC66x/67x/892

aspire

Subwoofer pin fixup for Aspire laptops

ideapad

Subwoofer pin fixup for Ideapad laptops

mario

Chromebook mario model fixup

hp-rp5800

Headphone pin fixup for HP RP5800

asus-mode1

**ASUS** 

asus-mode2

**ASUS** 

asus-mode3

**ASUS** 

asus-mode4

**ASUS** 

asus-mode5

ASUS

asus-mode6

ASUS

asus-mode7

**ASUS** 

asus-mode8

ASUS

zotac-z68

Front HP fixup for Zotac Z68

inv-dmic

Inverted internal mic workaround

alc662-headset-multi

Dell headset jack, which can also be used as mic-in (ALC662)

dell-headset-multi

Headset jack, which can also be used as mic-in

alc662-headset

Headset mode support on ALC662

alc668-headset

Headset mode support on ALC668

bass16

Bass speaker fixup on pin 0x16

bass1a

Bass speaker fixup on pin 0x1a

automute

Auto-mute fixups for ALC668

dell-xps13

Dell XPS13 fixups

asus-nx50

ASUS Nx50 fixups

asus-nx51

ASUS Nx51 fixups

asus-g751

ASUS G751 fixups

alc891-headset

Headset mode support on ALC891

alc891-headset-multi

Dell headset jack, which can also be used as mic-in (ALC891)

acer-veriton

```
Acer Veriton speaker pin fixup
asrock-mobo
        Fix invalid 0x15 / 0x16 pins
usi-headset
        Headset support on USI machines
dual-codecs
        Lenovo laptops with dual codecs
alc285-hp-amp-init
        HP laptops which require speaker amplifier initialization (ALC285)
ALC680
N/A
ALC88x/898/1150/1220
abit-aw9d
        Pin fixups for Abit AW9D-MAX
lenovo-y530
        Pin fixups for Lenovo Y530
acer-aspire-7736
        Fixup for Acer Aspire 7736
asus-w90v
        Pin fixup for ASUS W90V
cd
        Enable audio CD pin NID 0x1c
no-front-hp
        Disable front HP pin NID 0x1b
vaio-tt
        Pin fixup for VAIO TT
eee1601
        COEF setups for ASUS Eee 1601
alc882-eapd
        Change EAPD COEF mode on ALC882
alc883-eapd
        Change EAPD COEF mode on ALC883
gpio1
        Enable GPIO1
gpio2
        Enable GPIO2
gpio3
        Enable GPIO3
alc889-coef
        Setup ALC889 COEF
asus-w2jc
        Fixups for ASUS W2JC
acer-aspire-4930g
        Acer Aspire 4930G/5930G/6530G/6930G/7730G
acer-aspire-8930g
        Acer Aspire 8330G/6935G
acer-aspire
        Acer Aspire others
macpro-gpio
        GPIO setup for Mac Pro
dac-route
        Workaround for DAC routing on Acer Aspire
mbp-vref
        Vref setup for Macbook Pro
imac91-vref
        Vref setup for iMac 9,1
mball-vref
        Vref setup for MacBook Air 1,1
mba21-vref
        Vref setup for MacBook Air 2,1
mp11-vref
```

```
Vref setup for Mac Pro 1,1
mp41-vref
Vref setup for Mac Pro 4,1
inv-dmic
Inverted internal mic workaround
no-primary-hp
VAIO Z/VGC-LN51JGB workaround (for fixed speaker DAC)
asus-bass
Bass speaker setup for ASUS ET2700
dual-codecs
ALC1220 dual codecs for Gaming mobos
clevo-p950
Fixups for Clevo P950
```

#### ALC861/660

N/A

## ALC861VD/660VD

N/A

## **CMI9880**

minimal
3-jack in back
min\_fp
3-jack in back, 2-jack in front
full
6-jack in back, 2-jack in front
full\_dig
6-jack in back, 2-jack in front, SPDIF I/O
allout
5-jack in back, 2-jack in front, SPDIF out
auto
auto-config reading BIOS (default)

#### AD1882 / AD1882A

3stack

3-stack mode

3stack-automute

3-stack with automute front HP (default)

6stack

6-stack mode

### AD1884A / AD1883 / AD1984A / AD1984B

desktop 3-stack desktop (default) laptop with HP jack sensing mobile mobile devices with HP jack sensing thinkpad Lenovo Thinkpad X300 touchsmart HP Touchsmart

#### **AD1884**

N/A

#### **AD1981**

basic 3-jack (default) hp HP nx6320 thinkpad Lenovo Thinkpad T60/X60/Z60 toshiba Toshiba U205

#### **AD1983**

N/A

## AD1984

## AD1986A

3stack

3-stack, shared surrounds

laptop

2-channel only (FSC V2060, Samsung M50)

laptop-imic

2-channel with built-in mic

eapd

Turn on EAPD constantly

## AD1988/AD1988B/AD1989A/AD1989B

6stack

6-jack

6stack-dig

ditto with SPDIF

3stack

3-jack

3stack-dig

ditto with SPDIF

laptop

3-jack with hp-jack automute

laptop-dig

ditto with SPDIF

auto

auto-config reading BIOS (default)

### Conexant 5045

cap-mix-amp

Fix max input level on mixer widget

toshiba-p105

Toshiba P105 quirk

hp-530

HP 530 quirk

## Conexant 5047

cap-mix-amp

Fix max input level on mixer widget

#### Conexant 5051

lenovo-x200

Lenovo X200 quirk

## Conexant 5066

stereo-dmic

Workaround for inverted stereo digital mic

gpio1

Enable GPIO1 pin

headphone-mic-pin

Enable headphone mic NID 0x18 without detection

tp410

Thinkpad T400 & co quirks

thinkpad

Thinkpad mute/mic LED quirk

lemote-a1004

Lemote A1004 quirk

lemote-a1205

Lemote A1205 quirk olpc-xo OLPC XO quirk mute-led-eapd Mute LED control via EAPD hp-dock HP dock support mute-led-gpio Mute LED control via GPIO hp-mic-fix Fix for headset mic pin on HP boxes **STAC9200** ref Reference board oqo OQO Model 2 dell-d21 Dell (unknown) dell-d22 Dell (unknown) dell-d23 Dell (unknown) dell-m21 Dell Inspiron 630m, Dell Inspiron 640m dell-m22 Dell Latitude D620, Dell Latitude D820 dell-m23 Dell XPS M1710, Dell Precision M90 dell-m24 Dell Latitude 120L dell-m25 Dell Inspiron E1505n dell-m26 Dell Inspiron 1501 dell-m27 Dell Inspiron E1705/9400 gateway-m4 Gateway laptops with EAPD control gateway-m4-2 Gateway laptops with EAPD control panasonic Panasonic CF-74 auto BIOS setup (default) STAC9205/9254 ref Reference board dell-m42 Dell (unknown) dell-m43 Dell Precision dell-m44 Dell Inspiron eapd Keep EAPD on (e.g. Gateway T1616)

## STAC9220/9221

BIOS setup (default)

auto

Reference board 3stack D945 3stack 5stack D945 5stack + SPDIF intel-mac-v1 Intel Mac Type 1 intel-mac-v2 Intel Mac Type 2 intel-mac-v3 Intel Mac Type 3 intel-mac-v4 Intel Mac Type 4 intel-mac-v5 Intel Mac Type 5 intel-mac-auto Intel Mac (detect type according to subsystem id) macmini Intel Mac Mini (equivalent with type 3) macbook Intel Mac Book (eq. type 5) macbook-pro-v1 Intel Mac Book Pro 1st generation (eq. type 3) macbook-pro Intel Mac Book Pro 2nd generation (eq. type 3) imac-intel Intel iMac (eq. type 2) imac-intel-20 Intel iMac (newer version) (eq. type 3) ecs202 ECS/PC chips dell-d81 Dell (unknown) dell-d82 Dell (unknown) dell-m81 Dell (unknown) dell-m82 Dell XPS M1210 auto BIOS setup (default) STAC9202/9250/9251 ref Reference board, base config ml Some Gateway MX series laptops (NX560XL) m1-2Some Gateway MX series laptops (MX6453) m2Some Gateway MX series laptops (M255) m2-2Some Gateway MX series laptops m3Some Gateway MX series laptops m5Some Gateway MX series laptops (MP6954) m6Some Gateway NX series laptops auto BIOS setup (default)

#### STAC9227/9228/9229/927x

```
ref
        Reference board
ref-no-jd
        Reference board without HP/Mic jack detection
3stack
        D965 3stack
5stack
        D965 5stack + SPDIF
5stack-no-fp
        D965 5stack without front panel
dell-3stack
        Dell Dimension E520
dell-bios
        Fixes with Dell BIOS setup
dell-bios-amic
        Fixes with Dell BIOS setup including analog mic
volknob
        Fixes with volume-knob widget 0x24
auto
        BIOS setup (default)
STAC92HD71B*
        Reference board
dell-m4-1
        Dell desktops
dell-m4-2
        Dell desktops
dell-m4-3
        Dell desktops
hp-m4
        HP mini 1000
hp-dv5
        HP dv series
hp-hdx
        HP HDX series
hp-dv4-1222nr
        HP dv4-1222nr (with LED support)
auto
        BIOS setup (default)
STAC92HD73*
ref
        Reference board
no-jd
        BIOS setup but without jack-detection
intel
        Intel DG45* mobos
dell-m6-amic
        Dell desktops/laptops with analog mics
dell-m6-dmic
        Dell desktops/laptops with digital mics
dell-m6
        Dell desktops/laptops with both type of mics
dell-eq
        Dell desktops/laptops
alienware
        Alienware M17x
asus-mobo
```

Pin configs for ASUS mobo with 5.1/SPDIF out

BIOS setup (default)

auto

## STAC92HD83\*

ref

Reference board

mic-ref

Reference board with power management for ports

dell-s14

Dell laptop

dell-vostro-3500

Dell Vostro 3500 laptop

hp-dv7-4000

HP dv-7 4000

hp\_cNB11\_intquad

HP CNB models with 4 speakers

hp-zephyr

HP Zephyr

hp-led

HP with broken BIOS for mute LED

hp-inv-led

HP with broken BIOS for inverted mute LED

hp-mic-led

HP with mic-mute LED

headset-jack

Dell Latitude with a 4-pin headset jack

hp-envy-bass

Pin fixup for HP Envy bass speaker (NID 0x0f)

hp-envy-ts-bass

Pin fixup for HP Envy TS bass speaker (NID 0x10)

hp-bnb13-eq

Hardware equalizer setup for HP laptops

hp-envy-ts-bass

HP Envy TS bass support

auto

BIOS setup (default)

#### STAC92HD95

hp-led

LED support for HP laptops

hp-bass

Bass HPF setup for HP Spectre 13

## **STAC9872**

vaio

VAIO laptop without SPDIF

auto

BIOS setup (default)

## Cirrus Logic CS4206/4207

mbp53

MacBook Pro 5,3

mbp55

MacBook Pro 5,5

imac27

IMac 27 Inch

imac27\_122

iMac 12,2

apple

Generic Apple quirk

mbp101

MacBookPro 10,1

mbp81

MacBookPro 8,1
mba42
MacBookAir 4,2
auto
BIOS setup (default)

## Cirrus Logic CS4208

mba6

MacBook Air 6,1 and 6,2

gpio0

Enable GPIO 0 amp

mbp11

MacBookPro 11,2

macmini

MacMini 7,1

auto

BIOS setup (default)

## VIA VT17xx/VT18xx/VT20xx

auto

BIOS setup (default)