## Kernel driver asus\_wmi\_ec\_sensors

Supported boards:

- PRIME X570-PRO,
- Pro WS X570-ACE,
- ROG CROSSHAIR VIII DARK HERO,
- ROG CROSSHAIR VIII FORMULA,
- ROG CROSSHAIR VIII HERO,
- ROG STRIX B550-E GAMING,
- ROG STRIX B550-I GAMING,
- ROG STRIX X570-E GAMING.

## Authors:

• Eugene Shalygin < eugene.shalygin@gmail.com>

## **Description:**

ASUS mainboards publish hardware monitoring information via Super I/O chip and the ACPI embedded controller (EC) registers. Some of the sensors are only available via the EC.

ASUS WMI interface provides a method (BREC) to read data from EC registers, which is utilized by this driver to publish those sensor readings to the HWMON system. The driver is aware of and reads the following sensors:

- 1. Chipset (PCH) temperature
- 2. CPU package temperature
- 3. Motherboard temperature
- 4. Readings from the T Sensor header
- 5. VRM temperature
- 6. CPU Opt fan RPM
- 7. Chipset fan RPM
- 8. Readings from the "Water flow meter" header (RPM)
- 9. Readings from the "Water In" and "Water Out" temperature headers
- 10. CPU current