S3C24XX USB Host support

Introduction

This document details the S3C2410/S3C2440 in-built OHCI USB host support.

Configuration

Enable at least the following kernel options:

menuconfig:

```
Device Drivers --->
USB support --->

<*> Support for Host-side USB
<*> OHCI HCD support

.config:
```

- CONFIG USB
- CONFIG USB OHCI HCD

Once these options are configured, the standard set of USB device drivers can be configured and used.

Board Support

The driver attaches to a platform device, which will need to be added by the board specific support file in arch/arm/mach-s3c, such as mach-bast.c or mach-smdk2410.c

The platform device's platform_data field is only needed if the board implements extra power control or over-current monitoring.

The OHCI driver does not ensure the state of the S3C2410's MISCCTRL register, so if both ports are to be used for the host, then it is the board support file's responsibility to ensure that the second port is configured to be connected to the OHCI core.

Platform Data

See include/linux/platform_data/usb-ohci-s3c2410.h for the descriptions of the platform device data. An implementation can be found in arch/arm/mach-s3c/simtec-usb.c .

The *struct s3c2410_hcd_info* contains a pair of functions that get called to enable over-current detection, and to control the port power status.

The ports are numbered 0 and 1.

```
power_control:
```

Called to enable or disable the power on the port.

```
enable_oc:
```

Called to enable or disable the over-current monitoring. This should claim or release the resources being used to check the power condition on the port, such as an IRQ.

```
report_oc:
```

The OHCI driver fills this field in for the over-current code to call when there is a change to the over-current state on an port. The ports argument is a bitmask of 1 bit per port, with bit X being 1 for an over-current on port X.

The function s3c2410 usb report oc() has been provided to ensure this is called correctly.

port[x]:

This is struct describes each port, 0 or 1. The platform driver should set the flags field of each port to S3C HCDFLG USED if the port is enabled.

Document Author

Ben Dooks, Copyright 2005 Simtec Electronics