# Sliced VBI Data Interface

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 2)

Unknown directive type "cnamespace".
```

.. c:namespace:: V4L

VBI stands for Vertical Blanking Interval, a gap in the sequence of lines of an analog video signal. During VBI no picture information is transmitted, allowing some time while the electron beam of a cathode ray tube TV returns to the top of the screen.

Sliced VBI devices use hardware to demodulate data transmitted in the VBI. V4L2 drivers shall *not* do this by software, see also the ref. raw VBI interface < raw-vbi>. The data is passed as short packets of fixed size, covering one scan line each. The number of packets per video frame is variable.

```
System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources}\scample-onboarding-resources\linux-master)\ (\mbox{Documentation}\scample-onboarding-resources\linux-master)\ (\mbox{Documentation}\scampl
```

Unknown interpreted text role 'ref'.

Sliced VBI capture and output devices are accessed through the same character special files as raw VBI devices. When a driver supports both interfaces, the default function of a <code>/dev/vbi</code> device is <code>raw</code> VBI capturing or output, and the sliced VBI function is only available after calling the <code>ref:VIDIOC\_S\_FMT < VIDIOC\_G\_FMT></code> ioctl as defined below. Likewise a <code>/dev/video</code> device may support the sliced VBI API, however the default function here is video capturing or output. Different file descriptors must be used to pass raw and sliced VBI data simultaneously, if this is supported by the driver.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\((Documentation\)\((userspace-api)\)\((media)\((v41)\)\(dev-sliced-vbi.rst, line 21)\); \(backlink\)

Unknown interpreted text role 'ref'.

# **Querying Capabilities**

Devices supporting the sliced VBI capturing or output API set the  $V4L2\_CAP\_SLICED\_VBI\_CAPTURE$  or  $V4L2\_CAP\_SLICED\_VBI\_OUTPUT$  flag respectively, in the capabilities field of struct <code>:c.type:'v4l2\\_capability'</code> returned by the ref: <code>VIDIOC\_QUERYCAP'</code> ioctl. At least one of the read/write, streaming or asynchronous ref: <code>I/O</code> methods <code><io>'</code> must be supported. Sliced VBI devices may have a tuner or modulator.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 34); backlink

Unknown interpreted text role "c:type".

 $System \, Message: ERROR/3 \, (\mbox{D:\nonlinear-resources}) ample-onboarding-resources \linux-master) \, (\mbox{Documentation}) \, (userspace-api) \, (media) \, (v41) \, dev-sliced-vbi.rst, \, line \, 34); \, backlink$ 

Unknown interpreted text role 'ref'.

 $System \, Message: ERROR/3 \, (\mbox{D:\nonlinear-resources}) ample-onboarding-resources \linux-master) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mbox{Documentation}) \, (\mbox{user-space-api}) \, (\mbox{media}) \, (\mbox{v41}) \, (\mbox{linux-master}) \, (\mb$ 

Unknown interpreted text role 'ref'.

# **Supplemental Functions**

Sliced VBI devices shall support ref: video input or output < video > and ref: tuner or modulator < tuner > i octls if they have these

capabilities, and they may support ref. control ioctls. The ref. video standard < standard ioctls provide information vital to program a sliced VBI device, therefore must be supported.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\((Documentation\)\((userspace-api\)\)\((media)\((v41)\)\(dev-sliced-vbi.rst, line 45);\(backlink\)

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 45); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 45); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 45); backlink

Unknown interpreted text role 'ref'.

# **Sliced VBI Format Negotiation**

To find out which data services are supported by the hardware applications can call the <a href="ref":VIDIOC\_G\_SLICED\_VBI\_CAP">ref:VIDIOC\_G\_SLICED\_VBI\_CAP</a> ioctl. All drivers implementing the sliced VBI interface must support this ioctl. The results may differ from those of the <a href="ref":ref":VIDIOC\_S\_FMT < VIDIOC\_G\_FMT">ref":VIDIOC\_S\_FMT < VIDIOC\_G\_FMT</a> ioctl when the number of VBI lines the hardware can capture or output per frame, or the number of services it can identify on a given line are limited. For example on PAL line 16 the hardware may be able to look for a VPS or Teletext signal, but not both at the same time.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 56); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 56); backlink

Unknown interpreted text role 'ref'.

To determine the currently selected services applications set the type field of struct :c:type:\v412\_format\ to \v412\_BUF\_TYPE\_SLICED\_VBI\_CAPTURE or \v412\_BUF\_TYPE\_SLICED\_VBI\_OUTPUT, and the ref:\vIDIOC\_G\_FMT \leq \v1DIOC\_G\_FMT \rightarrow ioctl fills the fmt.sliced member, a struct :c:type:\v412\_sliced\_vbi\_format\.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 67); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 67); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-

 $\label{line-master} $$\max \operatorname{locumentation}(userspace-api) \end{locumentation} (userspace-api) \end{locumentation} (userspace-api) \end{locumentation} (v41) \end{locumentation} (userspace-api) \end{locumentation} (v41) \end{locumentation} (userspace-api) \end{locumentation} (userspa$ 

Unknown interpreted text role "c:type".

Applications can request different parameters by initializing or modifying the fmt.sliced member and calling the ref. 'VIDIOC S FMT < VIDIOC G FMT > 'ioctl with a pointer to the struct :c:type:'v4l2 format' structure.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 75); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 75); backlink

Unknown interpreted text role "c:type".

The sliced VBI API is more complicated than the raw VBI API because the hardware must be told which VBI service to expect on each scan line. Not all services may be supported by the hardware on all lines (this is especially true for VBI output where Teletext is often unsupported and other services can only be inserted in one specific line). In many cases, however, it is sufficient to just set the service\_set field to the required services and let the driver fill the service\_lines array according to hardware capabilities. Only if more precise control is needed should the programmer set the service lines array explicitly.

The ref: VIDIOC\_S\_FMT < VIDIOC\_G\_FMT> i iccl modifies the parameters according to hardware capabilities. When the driver allocates resources at this point, it may return an EBUSY error code if the required resources are temporarily unavailable. Other resource allocation points which may return EBUSY can be the ref: VIDIOC\_STREAMON` ioctl and the first :c:func: read()`, :c:func: write()` and :c:func: select()` call.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 91); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 91); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 91); backlink

Unknown interpreted text role "c:func".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\((Documentation\)\((userspace-api)\)\((media)\((v41)\)\(dev-sliced-vbi.rst, line 91);\(backlink\)

Unknown interpreted text role "c:func".

 $System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources}\scample-onboarding-resources\\\label{linux-master} \ (\mbox{Documentation}\scalebox{userspace-api\mbox{master}}\scalebox{linux-master})\ (\mbox{Documentation}\scalebox{userspace-api}\scal$ 

Unknown interpreted text role "c:func".

 $System \, Message: ERROR/3 \, (\mbox{D:\noboarding-resources} \mbox{linux-master) Cocumentation (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 100)}$ 

Unknown directive type "c:type".

```
.. c:type:: v412 sliced vbi format
```

#### struct v4l2 sliced vbi format

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 111)
```

Unknown directive type "tabularcolumns".

```
.. tabularcolumns:: |p{.85cm}|p{3.3cm}|p{4.45cm}|p{4.45cm}|p{4.45cm}|
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 113)

Unknown directive type "cssclass".

```
.. cssclass:: longtable
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 115)

Unknown directive type "flat-table".

On return the driver sets this field to the union of all elements of the returned ``service\_lines`` array. It may contain less services than requested, perhaps just one, if the hardware cannot handle more services simultaneously. It may be empty (zero) if none of the requested services are supported by the hardware.

```
* - __u16
- ``service_lines``\ [2][24]
- :cspan:`2`
```

Applications initialize this array with sets of data services the driver shall look for or insert on the respective scan line. Subject to hardware capabilities drivers return the requested set, a subset, which may be just a single service, or an empty set. When the hardware cannot handle multiple services on the same line the driver shall choose one. No assumptions can be made on which service the driver chooses.

Data services are defined in :ref:`vbi-services2`. Array indices map to ITU-R line numbers\ [#f2] as follows:

```
* -
    -
    - Element
    - 525 line systems
    - 625 line systems
* -
    -
    ``service_lines``\ [0][1]
    - 1
```

```
- 1
* -
  - ``service_lines``\ [0][23]
 - 23
 - 23
  - ``service lines``\ [1][1]
 - 264
 - 314
  - ``service_lines``\ [1][23]
  - 336
  - :cspan: `2` Drivers must set ``service_lines`` [0][0] and
     ``service lines``\ [1][0] to zero. The
    ``V4L2_VBI_ITU_525_F1_START``, ``V4L2_VBI_ITU_525_F2_START``,
``V4L2_VBI_ITU_625_F1_START`` and ``V4L2_VBI_ITU_625_F2_START``
    defines give the start line numbers for each field for each 525 or
    625 line format as a convenience. Don't forget that ITU line
   numbering starts at 1, not 0.
 - _u32
- ``io size`
  - :cspan: '2' Maximum number of bytes passed by one
    :c:func:`read()` or :c:func:`write()` call,
    and the buffer size in bytes for the
    :ref:`VIDIOC_QBUF` and
    :ref:`VIDIOC_DQBUF <VIDIOC_QBUF>` ioctl. Drivers set this field
    to the size of struct
    :c:type:`v412 sliced vbi data` times the
    number of non-zero elements in the returned ``service lines``
   array (that is the number of lines potentially carrying data).
  - __u32
- ``reserved``\ [2]
  - :cspan:`2` This array is reserved for future extensions.
    Applications and drivers must set it to zero.
```

### **Sliced VBI services**

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linuxmaster\Documentation\userspace-api\media\v41\(linux-master\) (Documentation) (userspaceapi) (media) (v41) dev-sliced-vbi.rst, line 218)

Unknown directive type "tabularcolumns".

.. tabularcolumns:: |p{4.2cm}|p{1.1cm}|p{2.1cm}|p{2.0cm}|p{6.5cm}|

 $System\,Message:\,ERROR/3\,(\texttt{D:}\nonline) - resources \verb|\sample-onboarding-resources| linux-linu$ master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspaceapi) (media) (v41) dev-sliced-vbi.rst, line 220) Unknown directive type "flat-table". .. flat-table:: :header-rows: 1 :stub-columns: 0 :widths: 2 1 1 2 2 \* - Symbol - Value - Reference - Lines, usually - Payload
\* - ``V4L2\_SLICED\_TELETEXT\_B`` (Teletext System B) - 0x0001 - :ref:`ets300706`, :ref:`itu653` - PAL/SECAM line 7-22, 320-335 (second field 7-22) - Last 42 of the 45 byte Teletext packet, that is without clock run-in and framing code, lsb first transmitted.

```
* - ``V4L2_SLICED_VPS``
  -0x0400
  - :ref: `ets300231`
  - PAL line 16
 - Byte number 3 to 15 according to Figure 9 of ETS 300 231, 1sb
   first transmitted.
* - ``V4L2_SLICED_CAPTION_525``
  - 0x1000
  -:ref:`cea608`
 - NTSC line 21, 284 (second field 21)
  - Two bytes in transmission order, including parity bit, lsb first
   transmitted.
* - ``V4L2 SLICED WSS 625``
 - 0x4000
  - :ref:`itu1119`,
    :ref:`en300294`
  - PAL/SECAM line 23
   See :ref:`v412-sliced-wss-625-payload` below.
* - ``V4L2 SLICED_VBI_525`
  -0x1000
  - :cspan:`2` Set of services applicable to 525 line systems.
* - ``V4L2_SLICED_VBI_625`
 - 0x4401
  - :cspan: `2` Set of services applicable to 625 line systems.
```

Drivers may return an EINVAL error code when applications attempt to read or write data without prior format negotiation, after switching the video standard (which may invalidate the negotiated VBI parameters) and after switching the video input (which may change the video standard as a side effect). The <a href="ref">ref">ref"</a> VIDIOC\_S\_FMT</a> VIDIOC\_G\_FMT> ioctl may return an EBUSY error code when applications attempt to change the format while i/o is in progress (between a <a href="ref">ref"</a> VIDIOC\_STREAMON and <a href="ref">ref"</a> VIDIOC\_STREAMOFF</a> <a href="ref">vIDIOC\_STREAMON</a> call, and after the first <a href="ref">c.fiunc</a> read() or <a href="ref">ref</a> refiunc</a> write() call).

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 268); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 268); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\((linux-master)\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 268); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 268); backlink

Unknown interpreted text role "c:func".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 268); backlink

Unknown interpreted text role "c:func".

#### V4L2\_SLICED\_WSS\_625 payload

The payload for V4L2 SLICED WSS 625 is:

Byte	0		1	
Bit	msb	lsb	msb	lsb
	7 6 5 4	3 2 1 0	x x 13 12	11 10 9 8

# Reading and writing sliced VBI data

A single :c:func:`read()` or :c:func:`write()` call must pass all data belonging to one video frame. That is an array of struct :c:type:`v4l2\_sliced\_vbi\_data` structures with one or more elements and a total size not exceeding io\_size bytes. Likewise in streaming I/O mode one buffer of io\_size bytes must contain data of one video frame. The id of unused struct :c:type:`v4l2\_sliced\_vbi\_data` elements must be zero.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 297); backlink

Unknown interpreted text role "c:func".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 297); backlink

Unknown interpreted text role "c:func".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 297); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 297); backlink

Unknown interpreted text role "c:type".

 $System\,Message:\,ERROR/3~(\mbox{D:\noboarding-resources\sample-onboarding-resources\linux-master\scalebox}) \label{linux-master} (\mbox{Documentation}\scalebox{userspace-api\mbox}) \label{linux-master} (\mbox{Documentation}\scalebox{userspace-api\mbox}) \label{linux-master} (\mbox{Documentation}\scalebox{userspace-api}\scalebox{userspace-a$ 

Unknown directive type "c:type".

.. c:type:: v412\_sliced\_vbi\_data

### struct v4l2 sliced vbi data

 $System\,Message:\,ERROR/3\, (\mbox{D:\noboarding-resources\sample-onboarding-resources\linux-master\scale}) \ (\mbox{Documentation}\scale-api)\ (\mbox{media}\scale-vbi.rst, line 310)$ 

Unknown directive type "tabularcolumns".

```
.. tabularcolumns:: |p{1.2cm}|p{2.2cm}|p{13.9cm}|
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 312)

Unknown directive type "flat-table".

```
contents of the ``data`` field are undefined and the driver must
    no longer insert data on the requested ``field`` and ``line`
  - __u32
- ``field`
  - The video field number this data has been captured from, or shall
    be inserted at. ``O`` for the first field, ``1`` for the second
    field.
* - _u32
- ``line``
  - The field (as opposed to frame) line number this data has been
    captured from, or shall be inserted at. See :ref:`vbi-525` and :ref:`vbi-625` for valid values. Sliced VBI capture devices can
    set the line number of all packets to ``O`` if the hardware cannot
    reliably identify scan lines. The field number must always be
    valid.
  - _u32
- ``reserved``
  - This field is reserved for future extensions. Applications and
   drivers must set it to zero.
  - <u>u</u>8
- ``data``\ [48]
  - The packet payload. See :ref:`vbi-services` for the contents and
    number of bytes passed for each data type. The contents of padding
    bytes at the end of this array are undefined, drivers and
    applications shall ignore them.
```

Packets are always passed in ascending line number order, without duplicate line numbers. The <code>c:func:write()</code> function and the <code>ref:VIDIOC\_QBUF</code> icctl must return an <code>EINVAL</code> error code when applications violate this rule. They must also return an <code>EINVAL</code> error code when applications pass an incorrect field or line number, or a combination of <code>field</code>, <code>line</code> and <code>id</code> which has not been negotiated with the <code>ref:VIDIOC\_G\_FMT < VIDIOC\_G\_FMT></code> or <code>ref:VIDIOC\_S\_FMT < VIDIOC\_G\_FMT></code> icctl. When the line numbers are unknown the driver must pass the packets in transmitted order. The driver can insert empty packets with <code>id</code> set to zero anywhere in the packet array.

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 350); backlink

Unknown interpreted text role "c:finc".
```

 $System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources\sample-onboarding-resources\linux-master)}\ (\mbox{Documentation}\ (\mbox{userspace-api\mbox{media}}\ (\mbox{v41}\ (\mbox{linux-master})\ (\mbox{Documentation})\ (\mbox{userspace-api}\ (\mbox{media})\ (\mbox{v41}\ dev-sliced-vbi.rst, line\ 350); \ backlink$ 

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 350); backlink

Unknown interpreted text role 'ref'.

 $System\ Message: ERROR/3\ (D:\onboarding-resources\sample-onboarding-resources\linux-master)\ (Documentation)\ (userspace-api)\ (media)\ (v41)\ dev-sliced-vbi.rst,\ line\ 350); \ backlink$ 

Unknown interpreted text role "ref".

To assure synchronization and to distinguish from frame dropping, when a captured frame does not carry any of the requested data services drivers must pass one or more empty packets. When an application fails to pass VBI data in time for output, the driver must output the last VPS and WSS packet again, and disable the output of Closed Caption and Teletext data, or output data which is ignored by Closed Caption and Teletext decoders.

A sliced VBI device may support ref read/write <rw>` and/or streaming (ref memory mapping <mmap>` and/or ref user pointer <userp>`) I/O. The latter bears the possibility of synchronizing video and VBI data by using buffer timestamps.

```
System\ Message:\ ERROR/3\ (\mbox{D:\noboarding-resources}\ sample-onboarding-resources\ linux-master)\ (\mbox{Documentation}\ (userspace-api)\ (media)\ (v41)\ dev-sliced-vbi.rst,\ line\ 370);\ backlink
```

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\((linux-master)\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 370); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 370); backlink

Unknown interpreted text role "ref".

### Sliced VBI Data in MPEG Streams

If a device can produce an MPEG output stream, it may be capable of providing ref. negotiated sliced VBI services <sliced-vbi-format-negotiation>` as data embedded in the MPEG stream. Users or applications control this sliced VBI data insertion with the ref. V4L2 CID MPEG STREAM VBI FMT <v4l2-mpeg-stream-vbi-fint>` control.

 $System \, Message: ERROR/3 \, (\mbox{D:\non-resources}) ample-onboarding-resources $$\lim \max - \mbox{Documentation} (\mbox{Documentation}) (\mbox{userspace-api}) (\mbox{linux-master}) (\mbox{Documentation}) (\mbox{userspace-api}) (\mbox{media}) (\mbox{v41}) (\mbox{dev-sliced-vbi.rst}, \mbox{line} 378); \\ \mbox{backlink}$ 

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 378); backlink

Unknown interpreted text role 'ref'.

If the driver does not provide the :ref:'V4L2\_CID\_MPEG\_STREAM\_VBI\_FMT < v4l2-mpeg-stream-vbi-fint>' control, or only allows that control to be set to :ref:'V4L2\_MPEG\_STREAM\_VBI\_FMT\_NONE < v4l2-mpeg-stream-vbi-fint>', then the device cannot embed sliced VBI data in the MPEG stream.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 386); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 386); backlink

Unknown interpreted text role 'ref'.

The ref: V4L2\_CID\_MPEG\_STREAM\_VBI\_FMT < v4l2-mpeg-stream-vbi-fint> `control does not implicitly set the device driver to capture nor cease capturing sliced VBI data. The control only indicates to embed sliced VBI data in the MPEG stream, if an application has negotiated sliced VBI service be captured.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 392); backlink

Unknown interpreted text role 'ref'.

It may also be the case that a device can embed sliced VBI data in only certain types of MPEG streams: for example in an MPEG-2 PS but not an MPEG-2 TS. In this situation, if sliced VBI data insertion is requested, the sliced VBI data will be embedded in MPEG stream types when supported, and silently omitted from MPEG stream types where sliced VBI data insertion is not supported by the device.

The following subsections specify the format of the embedded sliced VBI data.

MPEG Stream Embedded, Sliced VBI Data Format: NONE

The <a href="ref">ref">ref">ref"</a> VAI2\_MPEG\_STREAM\_VBI\_FMT\_NONE < <a href="v4I2-mpeg-stream-vbi-fint">v4I2-mpeg-stream-vbi-fint</a> embedded sliced VBI format shall be interpreted by drivers as a control to cease embedding sliced VBI data in MPEG streams. Neither the device nor driver shall insert "empty" embedded sliced VBI data packets in the MPEG stream when this format is set. No MPEG stream data structures are specified for this format.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation \) (userspace-api)\( (media \) (v41)\( dev-sliced-vbi.rst, \) line 412); backlink

Unknown interpreted text role 'ref'.

#### MPEG Stream Embedded, Sliced VBI Data Format: IVTV

The <a href="ref">ref"</a> V4L2\_MPEG\_STREAM\_VBI\_FMT\_IVTV < v4l2-mpeg-stream-vbi-fint</a> embedded sliced VBI format, when supported, indicates to the driver to embed up to 36 lines of sliced VBI data per frame in an MPEG-2 <a href="https://program.proceedings.org/">Private Stream 1 PES packet encapsulated in an MPEG-2 <a href="https://program.proceedings.org/">Program Pack</a> in the MPEG stream.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\((Documentation\)\((userspace-api)\)\((media)\((v41)\)\(dev-sliced-vbi.rst, line 423);\(backlink)\)

Unknown interpreted text role 'ref'.

Historical context: This format specification originates from a custom, embedded, sliced VBI data format used by the ivtv driver. This format has already been informally specified in the kernel sources in the file

Documentation/userspace-api/media/drivers/cx2341x-uapi.rst. The maximum size of the payload and other aspects of this format are driven by the CX23415 MPEG decoder's capabilities and limitations with respect to extracting, decoding, and displaying sliced VBI data embedded within an MPEG stream.

This format's use is *not* exclusive to the ivtv driver *nor* exclusive to CX2341x devices, as the sliced VBI data packet insertion into the MPEG stream is implemented in driver software. At least the cx18 driver provides sliced VBI data insertion into an MPEG-2 PS in this format as well.

The following definitions specify the payload of the MPEG-2 *Private Stream 1 PES* packets that contain sliced VBI data when ref: V4L2 MPEG\_STREAM\_VBI\_FMT\_IVTV <v4l2-mpeg-stream-vbi-fmt>' is set. (The MPEG-2 *Private Stream 1 PES* packet header and encapsulating MPEG-2 *Program Pack* header are not detailed here. Please refer to the MPEG-2 specifications for details on those packet headers.)

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 445); backlink

Unknown interpreted text role 'ref'.

The payload of the MPEG-2 *Private Stream 1 PES* packets that contain sliced VBI data is specified by struct <a href="mailto:ctype:'v412\_mpeg\_vbi\_fint\_ivtv">ctype:'v412\_mpeg\_vbi\_fint\_ivtv</a>. The payload is variable length, depending on the actual number of lines of sliced VBI data present in a video frame. The payload may be padded at the end with unspecified fill bytes to align the end of the payload to a 4-byte boundary. The payload shall never exceed 1552 bytes (2 fields with 18 lines/field with 43 bytes of data/line and a 4 byte magic number).

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master)\( (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 452); backlink

Unknown interpreted text role "c:type".

 $System\,Message:\,ERROR/3\, (\mbox{D:\noboarding-resources\sample-onboarding-resources\linux-master)}\ (\mbox{Documentation}\subseteq-api\media\v41\(linux-master)}\ (\mbox{Documentation}\) (userspace-api)\ (media)\ (v41)\ dev-sliced-vbi.rst,\ line\ 462)$ 

Unknown directive type "c:type".

```
.. c:type:: v4l2_mpeg_vbi_fmt_ivtv
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linuxmaster\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspaceapi) (media) (v41) dev-sliced-vbi.rst, line 467)

Unknown directive type "tabularcolumns".

.. tabularcolumns:: |p{4.2cm}|p{2.0cm}|p{11.1cm}|

```
System\,Message:\,ERROR/3\,(\texttt{D:}\nonline) - resources \verb|\sample-onboarding-resources|| the control of the contr
master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-
api) (media) (v41) dev-sliced-vbi.rst, line 469)
Unknown directive type "flat-table".
          .. flat-table::
                    :header-rows: 0
                    :stub-columns: 0
                    :widths:
                                                            1 1 2
                                    u8
                          - ``magic``\ [4]
                          - A "magic" constant from :ref:`v412-mpeg-vbi-fmt-ivtv-magic` that
                                indicates this is a valid sliced VBI data payload and also
                                indicates which member of the anonymous union, ``itv0`` or
                                  ``ITVO``, to use for the payload data.
                     * - union {

    (anonymous)

                     * - struct :c:type:`v4l2 mpeg vbi itv0`
                               ``itv0`
                           - The primary form of the sliced VBI data payload that contains
                               anywhere from 1 to 35 lines of sliced VBI data. Line masks are
                               provided in this form of the payload indicating which VBI lines
                               are provided.
                     * - struct :ref:`v412_mpeg_vbi_ITV0 <v412-mpeg-vbi-itv0-1>`
                           - ``ITVO`
                          - An alternate form of the sliced VBI data payload used when 36
                                lines of sliced VBI data are present. No line masks are provided
                                in this form of the payload; all valid line mask bits are
                                implcitly set.
                     * - }
```

### Magic Constants for struct v4l2\_mpeg\_vbi\_fmt\_ivtv magic field

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\((linux-master)\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 502)

Unknown directive type "tabularcolumns".

.. tabularcolumns:: |p{6.6cm}|p{2.2cm}|p{8.5cm}|

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 504)

Unknown directive type "flat-table".

```
- Indicates the ``ITVO`` member of the union in struct
  :c:type:`v4l2_mpeg_vbi_fmt_ivtv` is
 valid and that 36 lines of sliced VBI data are present.
```

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-
api) (media) (v41) dev-sliced-vbi.rst, line 524)
Unknown directive type "c:type".
   .. c:type:: v4l2 mpeg vbi itv0
```

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\Documentation\userspace-api\media\v41\((linux-master)\((Documentation)\) (userspace-
api) (media) (v41) dev-sliced-vbi.rst, line 526)
Unknown directive type "c:type".
   .. c:type:: v412 mpeg vbi ITV0
```

#### structs v4l2 mpeg vbi itv0 and v4l2 mpeg vbi ITV0

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-
api) (media) (v41) dev-sliced-vbi.rst, line 535)
Unknown directive type "tabularcolumns".
   .. tabularcolumns:: |p{4.6cm}|p{2.0cm}|p{10.7cm}|
```

 $System\,Message: ERROR/3\ (\texttt{D:} \ \texttt{Conboarding-resources} \ \texttt{Sample-onboarding-resources} \ \texttt{Linux-resources})$ master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspaceapi) (media) (v41) dev-sliced-vbi.rst, line 537)

```
Unknown directive type "flat-table".
    .. flat-table::
        :header-rows: 0
        :stub-columns: 0
                          1 1 2
        :widths:
               le32
           - ``linemask``\ [2]
           - Bitmasks indicating the VBI service lines present. These
               `linemask`` values are stored in little endian byte order in the
             MPEG stream. Some reference ``linemask`` bit positions with their
             corresponding VBI line number and video field are given below.
             b\ :sub:`0` indicates the least significant bit of a ``linemask``
             value:
             ::
                  linemask[0] b0:
                                         line 6 first field
                                        line 23 first field
                  linemask[0] b17:
                  linemask[0] b18:
                                         line 6 second field
                  linemask[0] b31:
                                          line 19 second field
                  linemask[1] b0:
                                         line 20 second field
                  linemask[1] b3:
                                          line 23 second field
                  linemask[1] b4-b31: unused and set to 0
         * - struct
             :c:type:`v412 mpeg vbi itv0 line`
           - ``line``\ [35]
           - This is a variable length array that holds from 1 to 35 lines of
             sliced VBI data. The sliced VBI data lines present correspond to the bits set in the ``linemask`` array, starting from b\ :sub:`0` of ``linemask``\ [0] up through b\ :sub:`31` of ``linemask``\ [0],
                                     of ``linemask``\ [1] up through b\ :sub:`3` of
             and from b\ :sub:`0`
              ``linemask``\ [1]. ``line``\ [0] corresponds to the first bit
             found set in the ``linemask`` array, ``line``\ [1] corresponds to the second bit found set in the ``linemask`` array, etc. If no
```

``linemask`` array bits are set, then ``line``\ [0] may contain one line of unspecified data that should be ignored by applications.

## struct v4l2 mpeg vbi ITV0

```
System Message: ERROR/3 (p:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 585)

Unknown directive type "tabularcolumns".

.. tabularcolumns:: |p{5.2cm}|p{2.4cm}|p{9.7cm}|
```

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 587)

Unknown directive type "flat-table".

 $System\,Message: ERROR/3 \ (\c : \c was ter \c was ter$ 

Unknown directive type "c:type".

```
.. c:type:: v4l2_mpeg_vbi_itv0_line
```

#### struct v4l2 mpeg vbi itv0 line

 $System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources}\scample-onboarding-resources\linux-master)\ (\mbox{Documentation}\scample-onboarding-resources\linux-master)\ (\mbox{Documentation}\scampl$ 

Unknown directive type "tabularcolumns".

```
.. tabularcolumns:: |p{4.4cm}|p{4.4cm}|p{8.5cm}|
```

 $System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources}\space-onboarding-resources\linux-master)\ (\mbox{Documentation}\space-api\mbox{media}\space-api\mbox{(linux-master)}\ (\mbox{Documentation})\ (\mbox{userspace-api}\space-api)\ (\mbox{media}\space-api)\ (\mbox{media}\sp$ 

Unknown directive type "flat-table".

```
- ``data``\ [42]- The sliced VBI data for the line.
```

## Line Identifiers for struct v4l2 mpeg vbi itv0 line id field

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v4l\(linux-master) (Documentation) (userspace-api) (media) (v4l) dev-sliced-vbi.rst, line 628)

Unknown directive type "tabularcolumns".

.. tabularcolumns:: |p{7.0cm}|p{1.8cm}|p{8.5cm}|
```

Unknown directive type "flat-table".

```
.. flat-table::
   :header-rows: 1
   :stub-columns: 0
   :widths:
   * - Defined Symbol
      - Value
     - Description
   * - ``V4L2_MPEG_VBI_IVTV_TELETEXT_B``
     - 1
     - Refer to :ref:`Sliced VBI services <vbi-services2>` for a
       description of the line payload.
        "V4L2 MPEG VBI IVTV CAPTION 525"
      - 4
     - Refer to :ref:`Sliced VBI services <vbi-services2>` for a
       description of the line payload.
         `V4L2_MPEG_VBI_IVTV_WSS_625`
     - Refer to :ref:`Sliced VBI services <vbi-services2>` for a
       description of the line payload.
    * - ``V4L2_MPEG_VBI_IVTV_VPS`
     - 7
      - Refer to :ref:`Sliced VBI services <vbi-services2>` for a
       description of the line payload.
```

[1] According to ref. ETS 300 706 <ets 300 706 > lines 6-22 of the first field and lines 5-22 of the second field may carry Teletext data.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(1inux-master\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 657); backlink Unknown interpreted text role "ref".

[2] See also ref. vbi-525 and ref. vbi-625.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master\) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 661); backlink Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\(linux-master) (Documentation) (userspace-api) (media) (v41) dev-sliced-vbi.rst, line 661); backlink Unknown interpreted text role "ref".