dvb-usb-dw2102 cards list

Unknown directive type "tabularcolumns".

.. tabularcolumns:: |p{7.0cm}|p{10.5cm}|

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\admin-guide\media\[linux-master] [Documentation] [admin-guide] [media] dvb-usb-dw2102-cardlist.rst, line 8)

Unknown directive type "flat-table".

- 0ccd:0102

* - X3M TV SPC1400HD PCI - 0x1f4d:0x3100

```
.. flat-table::
:header-rows: 1
:widths: 7 13
:stub-columns: 0
 * - Card name
  - USB IDs
 * - DVBWorld DVB-C 3101 USB2.0
  - 04b4:3101
 * - DVBWorld DVB-S 2101 USB2.0
  - 04b4:0x2101
* - DVBWorld DVB-S 2102 USB2.0
   - 04b4:2102
 * - DVBWorld DW2104 USB2.0
  - 04b4:2104
* - GOTVIEW Satellite HD
  - 0x1FE1:5456
 * - Geniatech T220 DVB-T/T2 USB2.0
   - 0x1f4d:0xD220
 * - SU3000HD DVB-S USB2.0
   - 0x1f4d:0x3000
 * - TeVii S482 (tuner 1)
  - 0x9022:0xd483
 * - TeVii S482 (tuner 2)
  - 0x9022:0xd484
* - TeVii S630 USB
   - 0x9022:d630
 * - TeVii S650 USB2.0
  - 0x9022:d650
 * - TeVii S662
  - 0x9022:d662
 * - TechnoTrend TT-connect S2-4600
  - 0b48:3011
 * - TerraTec Cinergy S USB
  - 0ccd:0064
 * - Terratec Cinergy S2 PCIe Dual Port 1
  - 153b:1181
 * - Terratec Cinergy S2 PCIe Dual Port 2
  - 153b:1182
* - Terratec Cinergy S2 USB BOX
   - 0ccd:0x0105
 * - Terratec Cinergy S2 USB HD
  - 0ccd:00a8
 * - Terratec Cinergy S2 USB HD Rev.2
   - 0ccd:00b0
 * - Terratec Cinergy S2 USB HD Rev.3
```