# **AUDIO SET ID**

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-
master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]audio-set-id.rst, line 2)
Unknown directive type "cnamespace".
.. c:namespace:: DTV.audio
```

#### Name

AUDIO\_SET\_ID

```
Attention!
```

This ioctl is deprecated

### **Synopsis**

```
System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\drivers\staging\media\av7110\[linux-master][drivers][staging][media]
[av7110]audio-set-id.rst, line 20)
Unknown directive type "cmacro".
.. c:macro:: AUDIO_SET_ID
```

int ioctl(int fd, AUDIO SET ID, int id)

## **Arguments**

## **Description**

This ioctl selects which sub-stream is to be decoded if a program or system stream is sent to the video device. If no audio stream type is set the id has to be in [0xC0,0xDF] for MPEG sound, in [0x80,0x87] for AC3 and in [0xA0,0xA7] for LPCM. More specifications may follow for other stream types. If the stream type is set the id just specifies the substream id of the audio stream and only the first 5 bits are recognized.

#### Return Value

On success 0 is returned, on error -1 and the errno variable is set appropriately. The generic error codes are described at the

rref: Generic Error Codes <gen-errors>' chapter.

 $System \, Message: ERROR/3 \, (\mbox{D:\nonboarding-resources} \mbox{sample-onboarding-resources} \mbox{linux-master} \mbox{drivers} \mbox{staging\mbox{media\av7110}[linux-master] [drivers] [staging] [media] [av7110] audio-set-id.rst, line 57); backlink$ 

Unknown interpreted text role 'ref'.