

Information about product item_number: 19

Adventure Dining Table, price \$90,

Brand

CampBuddy

Category

Camping Tables

Features

- Durable Construction: Made from high-quality materials to ensure long-lasting performance in outdoor environments.
- Portable and Lightweight: Designed to be compact and lightweight for easy transportation and setup during outdoor adventures.
- Adjustable Height: Offers adjustable height settings to accommodate various seating arrangements and preferences.
- Spacious Surface: Provides ample surface area to comfortably accommodate meals, drinks, and other essentials.
- Easy Setup: Quick and hassle-free setup with user-friendly mechanisms and instructions.
- Weather Resistant: Designed to withstand outdoor conditions, including sun, rain, and moisture.
- Sturdy and Stable: Features a robust and stable frame that can support the weight of food, dishes, and utensils.
- Folding Design: Enables easy folding and compact storage when not in use, making it ideal for camping and travel.
- Versatile: Suitable for various outdoor activities such as camping, picnics, barbecues, and beach outings.
- Easy to Clean: Smooth surface and materials that are easy to wipe clean after use.

Technical Specs

Best Use: Outdoor dining, camping, picnics

Material: Aluminum

Tabletop Material: Sturdy and easy-to-clean surface

Frame Material: Strong and lightweight frame construction

Adjustable Height: Yes

Foldable: Yes

****Dimensions (when set up):**** 60in x 30in x 28in

****Weight:**** 20lbs

User Guide

1. Safety Guidelines

- Before using the Adventure Dining Table, carefully read and understand all safety guidelines provided in this user guide.
- Always ensure the table is placed on a stable and level surface to prevent tipping or instability.
- Do not exceed the specified weight capacity of the table to avoid damage and potential injury.
- Keep children away from the table during assembly and use to prevent accidents.

2. Assembly Instructions

1. Unpack all components and verify that all parts are included.
2. Follow the provided assembly instructions specific to your Adventure Dining Table model.
3. Use the appropriate tools, if required, to securely attach the tabletop to the frame.
4. Ensure all connections and fasteners are tightened properly to guarantee stability.

3. Operating Instructions

- To set up the Adventure Dining Table, unfold the legs and secure them in place according to the manufacturer's instructions.
- Adjust the table height if applicable, ensuring it is suitable for your intended use.
- Place your dining items, such as plates, utensils, and food, on the tabletop with care.
- Use the table responsibly and avoid placing excessive weight on unsupported areas.

4. Cleaning and Maintenance

- After each use, remove any food debris and clean the tabletop with a mild detergent and water.
- Avoid using abrasive cleaners or harsh chemicals that may damage the table's surface.
- If the table becomes wet, dry it thoroughly before folding and storing to prevent mold or mildew growth.
- Store the Adventure Dining Table in a dry and secure location to protect it from the elements.

5. Warranty Information

The Adventure Dining Table comes with a limited warranty that covers manufacturing defects and workmanship issues. Please refer to the warranty card or the manufacturer's website for specific details on the warranty terms and conditions.

6. Contact Information

If you have any questions, concerns, or need assistance with your Adventure Dining Table, please contact our customer support team:

- Customer Support: 1-800-123-4567
- Email: support@adventurediningtable.com
- Website: www.adventurediningtable.com/support

Caution Information

1. ****Do not exceed the weight capacity:**** The Adventure Dining Table has a specified weight capacity. Do not exceed this limit to prevent damage to the table and potential injury.
2. ****Do not use as a step ladder or stool:**** The Adventure Dining Table is designed for dining purposes only. Do not stand or sit on the table, as it may lead to instability and accidents.
3. ****Do not place hot objects directly on the tabletop:**** The tabletop may not be heat-resistant. Always use heat-resistant mats or trivets to protect the surface from hot cookware or dishes.
4. ****Do not drag or slide the table on rough surfaces:**** Avoid dragging or sliding the Adventure Dining Table on abrasive or uneven surfaces, as it may scratch or damage the table's legs or frame.
5. ****Do not leave the table exposed to extreme weather conditions:**** Although the Adventure Dining Table is designed for outdoor use, prolonged exposure to extreme weather conditions such as heavy rain, snow, or intense sunlight may degrade its performance and durability. Store the table in a dry and secure location when not in use.
6. ****Do not dismantle or modify the table:**** Do not attempt to dismantle or modify any parts of the Adventure Dining Table. Alterations to the original design may compromise its stability, safety, and warranty coverage.
7. ****Do not use harsh chemicals or abrasive cleaners:**** Avoid using harsh chemicals, solvents, or abrasive cleaners on the tabletop or frame, as they may cause damage. Instead, use mild detergent and water for regular cleaning.
8. ****Do not leave sharp objects directly on the table:**** To prevent scratches or cuts on the tabletop, avoid placing sharp objects directly on the surface. Use coasters or protective covers when necessary.
9. ****Do not use the table on unstable or uneven surfaces:**** Ensure that the Adventure Dining Table is placed on a stable and level surface to prevent tipping or instability during use.
10. ****Do not leave children unattended near the table:**** Always supervise children when they are near or using the Adventure Dining Table to prevent accidents or injuries.

Warranty Information

The Adventure Dining Table comes with a limited warranty that covers manufacturing defects and faulty workmanship. The warranty terms and conditions are as follows:

1. **Duration:** The Adventure Dining Table is covered by a warranty period of 1 year from the date of purchase.
2. **Coverage:** The warranty covers defects in materials and workmanship under normal use and proper care. It includes issues such as structural defects, faulty hardware, or manufacturing flaws.
3. **Exclusions:** The warranty does not cover damages resulting from misuse, abuse, accidents, improper assembly, modifications, normal wear and tear, or any damage caused by natural disasters or extreme weather conditions.
4. **Claim Process:** In the event that you encounter a manufacturing defect or faulty workmanship covered by the warranty, please follow these steps:
 - Contact our Customer Care within the warranty period and provide the necessary information about the issue.
 - Our Customer Care team will guide you through the troubleshooting process, and if required, provide instructions for return or repair.
 - Please retain the original proof of purchase (receipt or order confirmation) as it will be required to validate your warranty claim.
5. **Resolution:** Based on the nature of the warranty claim, we will either repair or replace the defective part or the entire Adventure Dining Table at our discretion. If the exact model is no longer available, we will provide a comparable replacement.
6. **Contact Information:** For any warranty claims or inquiries, please reach out to our Customer Care team using the following contact details:

- Customer Care Phone: 1-800-123-4567
- Customer Care Email: support@adventurediningtable.com
- Customer Care Hours: Monday to Friday, 9:00 AM to 5:00 PM (EST)

Please note that this warranty is non-transferable and applies only to the original purchaser of the Adventure Dining Table.

Return Policy

- **If Membership status "None":** If you are not satisfied with your purchase, you can return it within 30 days for a full refund. The product must be unused and in its original packaging.

- **If Membership status "Gold":** Gold members can return their camping tables within 60 days of purchase for a full refund or exchange. The product must be unused and in its original packaging.
- **If Membership status "Platinum":** Platinum members can return their camping tables within 90 days of purchase for a full refund or exchange. The product must be unused and in its original packaging. Additionally, Platinum members receive a 10% discount on all camping table purchases but from the same product brand.

Reviews

1) **Rating:** 5

Review: I recently purchased the Adventure Dining Table Camping Stove, and it has been a game-changer for our outdoor adventures! The stove is compact, lightweight, and easy to set up. It provides a steady flame and quickly heats up our meals. The built-in windscreen is a great feature, as it keeps the flame protected on windy days. The cooking surface is spacious enough to accommodate multiple pots and pans. I highly recommend this stove to fellow campers who value convenience and efficiency.

2) **Rating:** 4

Review: The Adventure Dining Table Camping Stove has been a reliable companion on our camping trips. It's sturdy and well-built, ensuring stability while cooking. The flame control is precise, allowing us to adjust the heat according to our cooking needs. The stove heats up quickly and evenly, providing consistent performance. The compact design makes it easy to carry and store. The only improvement I would suggest is a more comprehensive user manual with detailed instructions for maintenance and cleaning.

3) **Rating:** 3

Review: I have mixed feelings about the Adventure Dining Table Camping Stove. On one hand, it's compact and lightweight, which is great for backpacking. The stove ignites easily and heats up quickly. However, I found the flame control to be a bit finicky, making it challenging to maintain a steady heat level. The cooking surface is also smaller than expected, limiting the size of pots and pans that can be used. Overall, it's an okay stove for basic cooking needs, but I would recommend exploring other options if you require more precise temperature control or larger cooking capacity.

4) **Rating:** 5

Review: I absolutely love the Adventure Dining Table Camping Stove! It's incredibly easy to use and provides consistent heat for cooking. The compact size is perfect for our camping trips, and the foldable design makes it effortless to pack and transport. The stove is durable and withstands outdoor conditions well. It has become an essential part of our camping gear, and I highly recommend it to anyone in need of a reliable and efficient camping stove.

5) **Rating:** 4

Review: The Adventure Dining Table Camping Stove is a reliable and affordable option for outdoor cooking. It's compact and lightweight, making it ideal for backpacking. The stove performs well, delivering a consistent flame and even heat distribution. The construction is sturdy, and the foldable

legs provide stability on various surfaces. The only minor drawback is the lack of an included carrying case, which would have made transportation and storage more convenient. Overall, it's a great value for the price and a worthy addition to any camping setup.

FAQ

1) How much weight can the Adventure Dining Table support?

The Adventure Dining Table can support up to 100 lbs (45 kg) of evenly distributed weight, making it suitable for various outdoor dining and cooking needs.

2) How do I set up the Adventure Dining Table?

The Adventure Dining Table features a foldable design with telescopic legs. Simply unfold the table, extend the legs to the desired height, and secure them in place using the locking mechanism.

3) Is the Adventure Dining Table easy to clean?

Yes, the Adventure Dining Table has an easy-to-clean aluminum surface. Simply wipe it with a damp cloth or sponge and mild detergent to remove any dirt or spills.

4) Can I use a camping stove on the Adventure Dining Table?

Yes, the Adventure Dining Table is designed to accommodate camping stoves, cooking utensils, and other outdoor dining essentials. However, ensure that the stove is stable and use caution when cooking with open flames.