

Engineering Advanced diffraction techniques for Residual Stress determination

Michael Preuss
University of Manchester

Oxford School on Neutron Scattering

1

Introduction

- Residual stresses in materials
- Principles of measuring residual stresses by diffraction
- Neutron and Synchrotron X-ray diffraction
 - Properties
 - Facilities
- Case Studies / Questions
- From Engineering to Physical Metallurgy – Understanding plasticity
- Conclusions

Oxford School on Neutron Scattering

2

What are residual stresses

Deformation mismatch

Example: Welding




Oxford School on Neutron Scattering

3

Residual Stresses

- Internal stresses
- Caused by misfit
 - Type I
 - Type II
 - Type III


Bent bar:



Oxford School on Neutron Scattering

4


General Overview: Diffraction methods available



Oxford School on Neutron Scattering

5

General Overview: Basic Principles: diffraction




$$\lambda = 2d \sin \theta$$

- Diffraction measures elastic lattice strain as peak shifts
- Uses the poly-crystalline lattice planes as internal strain gauges

Oxford School on Neutron Scattering

6

Basic Principle



Oxford School on Neutron Scattering

7

Bragg scattering angle

wavelength:

$$\lambda = \frac{hc}{E} = \frac{12.39}{[keV]}$$

Bragg's law:

$$\lambda = 2d \sin\theta$$

Scattering Angle

$$\theta = \arcsin\left(\frac{12.39}{2d[keV]}\right)$$

$$\frac{12.39}{[keV]} = 2d \sin\theta$$

Oxford School on Neutron Scattering


9

General Overview: Basic Principles

- Measured strains have to be converted into stresses! (Hooke's law)

$$\varepsilon = \frac{a - a_0}{a_0} = \frac{d - d_0}{d_0}$$

The 9 components of a stress tensor:



The stress acts in the x-direction

τ_{xy}
on the plane with a normal in the y direction
(This convention maybe vice versa in some books.)

$$\boldsymbol{\sigma}_{ij} = \begin{pmatrix} \sigma_{xx} & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & \sigma_{yy} & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & \sigma_{zz} \end{pmatrix}$$

Tensor Equation: $\sigma_{ij} = C_{ijkl}\epsilon_{kl}$

Matrix Equation: $\boldsymbol{\sigma}_p = \mathbf{C}_{pq}\boldsymbol{\epsilon}_q$

General Overview: Basic Principles

- Measured strains have to be converted into stresses! (Hooke's law)

$$\varepsilon = \frac{a - a_0}{a_0} = \frac{d - d_0}{d_0}$$

e.g. isotropic triaxial
along principal
directions:

$$\varepsilon_{11} = \frac{1}{E} [\sigma_{11} - \nu(\sigma_{22} + \sigma_{33})]$$



$$\varepsilon_{22} = \frac{1}{E} [\sigma_{22} - \nu(\sigma_{33} + \sigma_{11})]$$

$$\varepsilon_{33} = \frac{1}{E} [\sigma_{33} - \nu(\sigma_{11} + \sigma_{22})]$$

To calculate a stress direction:

$$\sigma_{11} = \frac{E}{(1+\nu)(1-2\nu)} [(1-\nu)\varepsilon_{11} + \nu(\varepsilon_{22} + \varepsilon_{33})]$$

(Attention: not always this simple!)




Neutron and Synchrotron Sources

Neutron:

- Reactor Sources (Fission)
 - Constant wavelength/Single Peak
- Accelerator Sources (Spallation)
 - Time-of-flight / Full Spectra / Rietveld

Synchrotron:

- Monochromatic λ and white beam




Oxford School on Neutron Scattering

13

General Overview: Strain Scanning

Diffracting Gauge Volume: The volume element defined by the incident slits and diffraction slits


Neutron Diffraction



Oxford School on Neutron Scattering

14


Synchrotron Diffraction: Penetration depth (monochromatic beam)



Oxford School on Neutron Scattering

15

Synchrotrons: Scattering Angle 2θ



Oxford School on Neutron Scattering

21

General Overview: Diffracting Gauge Volume

Volume element of the material in which the recorded scattering takes place

- Results in averaged d-spacing (powder diffraction - many grains)
- Defines the minimum spatial resolution of the method (around 1mm^3 minimum gauge volume when using neutron diffraction)
- and type of residual stress resolved (macro-stress or type-I usually. Type-II for two phase materials).
- Use the largest possible gauge volume for your specific issue in order to minimise counting time

Near surface measurements

Neither peak shift (strain) nor measurement location is correct near a surface!

- Partial filling of sampling gauge gives a peak shift - **need to correct peak shift**
- Translator records centre of gauge which is rarely the centre of gravity of diffracting region
- **need to correct gauge position**

Neutron Properties


- Neutrons are scattered by atomic nuclei (electrons and X-rays which are scattered by the electron cloud).
- Since the scattering is nuclear process, scattering amplitude varies greatly for different isotopes of same element and in a unpredictable manner from element to element. X-ray and electron scattering increase monotonically with atomic number

Oxford School on Neutron Scattering

19

Neutron Properties

- Random Scattering length
- Penetration depth independent of energy/wavelength
- Electrically neutral
- Great penetration
- Low flux/intensity




Economic Depth	Al	Steel	Cu	Ti	Ni	SiC
mm	250	37	40	27	24	200

Oxford School on Neutron Scattering

20

Neutron Scattering



Oxford School on Neutron Scattering

26

Research Reactors


- Fission in Reactor Core
 - Moderated neutrons
 - Monochromators in guide
- “Constant Wavelength”
- Many Facilities in Europe:
 - **ILL**, SINQ, FRM-2 (G), Petten (NL), ...
 - Generally low flux except ILL and FRM-2

Oxford School on Neutron Scattering

22

Single Wavelength at Reactor

Single-wavelength instrument: D1A at the ILL
New instrument at ILL: SALSA




Oxford School on Neutron Scattering

23

Which peak gives us the pure macrostress response ?


In-situ Loading on a neutron diffraction beam line



Oxford School on Neutron Scattering

24

SALSA, ILL



Oxford School on Neutron Scattering

25


Typical Diffractometer at Synchrotron (here ID31 at the ESRF)



Oxford School on Neutron Scattering

26

Diamond gauge volume




27

Time of flight method

- Sharp pulse leaves source
- High energy neutrons (short λ) travel faster and arrive first, low energy (long λ) last $\lambda = ht/ml$ where l is the path length and t time of flight
- a single stationary detector records whole diffraction spectrum as a function of time of flight
- neutrons travel at $\sim 100\text{m/s}$ (speed of sound)
 $\lambda = 2d \sin \theta$ with θ fixed, i.e. λ proportional to d

Spallation Sources: Time of Flight



Fast neutrons arrive earlier
at detector!


$$\lambda = \frac{h}{p} = \frac{h}{mv} = \frac{ht}{mL}$$

$$+ \\ \lambda = 2d \sin\theta$$

Time-of-Flight:

$$d = \frac{h}{2mL \sin\theta} t$$

ENGIN-X, ISIS




Example of TOF: Rietveld Refinement

TOF: More Information!

Rietveld: Fewer Parameters!

$$d_{hkl} = \frac{a_0}{\sqrt{h^2 + k^2 + l^2}}$$

Data
Fitting
Difference



31

Spallation Sources: Measurement of Strain

$$\text{Strain: } \epsilon = \frac{a - a_0}{a_0} = \frac{\lambda - \lambda_0}{\lambda_0} = \frac{t - t_0}{t_0}$$


Cubic gauge volume !



Time-of-Flight:

$$\lambda = \frac{h}{2mL \sin\theta} t$$


Fixed



ENGIN-X at ISIS

Rietveld vs Single reflection

In-situ Loading on a neutron diffraction beam line




Rietveld analysis generally provides linear stress-strain response with elastic constant equal Young's Modulus

Oxford School on Neutron Scattering

33

Case Study: Inertia Friction Welding




Solid state joining of compressor, turbine discs and shafts

10th Oxford School on Neutron Scattering

34

Case Study: Inertia Friction Welding




10th Oxford School on Neutron Scattering

35



How would you measure such a sample ?

143mm diameter test inertia friction welds



Oxford School on Neutron Scattering


36



Case Study: Strain Mapping of a TIG weld

2D Map of Residual Strain about the End of a TIG Weld at 100 μm Resolution


This map include 20,00 measurements and took 8 hours to acquire




39

From Engineering to Physical/Mechanical Metallurgy

Single Crystal Anisotropy



Al, fcc



Single Crystal deformation

What do we know ?



- Deformation of metallic materials happens along most densely packed plane in most densely packed direction
 - For example: in fcc it is the (111) plane and the <110> direction
- Relatively good understanding what happen when a single crystal is deformed

Oxford School on Neutron Scattering

41

What we struggle with

- How does deformation work in a polycrystalline aggregate



Oxford School on Neutron Scattering

42

Deformation heterogeneity

- Polycrystalline deformation is heterogeneous
- Single crystal elastic and plastic anisotropy
- Grain incompatibility during deformation results in intergranular stresses

Why do we care ?

- Deformation mechanisms play a crucial role when material is processed as it affects the microstructure and hence performance of the material that is generated
 - exactly the same alloy can have a strength of 300 or 1000 MPa just by changing the microstructure

Why do we care ?

- Understanding deformation mechanisms is crucial in order to develop a more physical understanding of how materials perform
- Such knowledge is required to predict accurately the life of engineering components
- Particularly important for safety critical components

Oxford School on Neutron Scattering



In-situ loading experiments




Oxford School on Neutron Scattering

46

Experimental Methodologies


- Use of neutron diffraction and high energy synchrotron x-ray diffraction characterising residual stresses, intergranular strains and phase transformation



Case Study – Ni base Superalloy


- Use of neutron diffraction and high energy synchrotron x-ray diffraction characterising residual stresses, intergranular strains and phase transformation

Example – Ni base Superalloy




Case Study – Ni base Superalloy

- Use of neutron diffraction and high energy synchrotron x-ray diffraction characterising residual stresses, intergranular strains and phase transformation




Case Study – hcp metal




Effect of Sn on twinning in Zr alloys



- Twin nucleation criteria unknown
- Role of alloying elements on twinning unknown



Role of Sn on intergranular strain development




Lattice strain recorded in the loading direction



EPSC Modelling


- The elasto-plastic self-consistent model (EPSC), is based on the Eshelby-Hill formulation.
- An elliptical inclusion in an infinite medium.
- The surrounding medium is the average of all orientations.
- The inclusion has uniform stress and anisotropic properties i.e. different orientations have different elastic moduli and plastic deformation is only allowed on specified slip planes.
- The model is capable of simulating multiple thermo-mechanical processes.



Oxford School on Neutron Scattering

CPFEM


- CPFEM is more computer intensive than EPSC modelling, however, it enables the simulation of specified grain structures.



Oxford School on Neutron Scattering

56

Plasticity Modelling (CPFEM)



Oxford School on Neutron Scattering

57

Attempted General Guidelines: Neutrons

Neutrons:

- Non-destructive, full stress analysis because of cubic Gauge Volume (think three directions)
- Good penetration depth due to neutrality
- Big bulky sample with low stress gradients
- Reasonable spatial resolution independent of atomic number
- Steels, aluminium, nickel, copper zinc or related
- Sample in harsh environment: furnace, cryo. etc.
- Phase analysis with Rietveld analysis

Not-so good: near surface or thin materials, titanium, boron cadmium, fast, high-spatial resolution, high instrumental resolution, hydrogenous materials

Oxford School on Neutron Scattering

58

Attempted General Guidelines: Synchrotrons

Synchrotrons:

- Non-destructive, fast strain mapping, mostly single peak
- Light alloys (small atomic number)
- High spatial resolution aluminium-titanium (think microns)
- High instrumental resolution (small peak width)
- Near surface measurement because of analyser crystal
- Bulk materials / larger atomic number with energy-dispersive method
- Polymers

Not so good at: Steels and higher, big bulky samples, harsh environments, diamond shaped GV