

# **CESSNA 150**

STANDARD OPERATING PROCEDURES, SOP

Author VLE Cessna 150 Standard operating procedures

OM Appendix 1A 10.12.2011

## 2

## **INDEX**

GENERAL	3
Checklists	3
Use of lights	
Parking brake	
Flaps	
Engine priming	
BEFÖRE ENGINE START	
Engine fire during start	
Proper actions in engine fire	
Passenger briefing	
Instrument check 1 (Before taxi)	
Emergency procedures	
Rejected take-off	
Ground emergency	7
Engine power loss in flight	8
Forced landing	
TAXIING	
Instrument check 2	10
Take-off briefing	11
TAKE-OFF AND CLIMB	12
CRUISE AND AIRWORK	12
Stalls	13
Slow flight	13
Recoveries from unusual attitudes	14
Nose up, decreasing airspeed	14
Nose down, increasing airspeed	14
Steep turns	
APPROACH AND LANDING	
Approach briefing	15
Final check	
Missed approach / Go-around	
After landing	
FLIGHT PROFILES C150	17
Normal take-off	
Short field take-off	
Normal approach	
Short field approach	
Stall in clean configuration	
Stall in landing configuration	
Missed approach	
Traffic circuit	21

Author VLE

Cessna 150 Standard operating procedures

OM Appendix 1A 10.12.2011 3

## **GENERAL**

The purpose of this SOP is to give outline for TTT-Aviation flight operations. All pilots flying TTT-Aviation flights, including staff and students shall use this SOP unless it comes necessary for safety of flight.

#### **CHECKLISTS**

Checklists are used to improve safety. All pilots shall use checklists in each and every flight executed in TTT- Aviation flight operations.

- Read checklist item out loud, and acknowledge.
- "Beacon"....."ON"
- On items: "A/R" (As required), take sides to it.
- "Pitot -heat"......Not needed....."OFF"
- Starred items "By heart". Confirm afterwards from checklist
- Read list out loud so your Instructor or "Copilot" knows what it going on.

#### **USE OF LIGHTS**

**Beacon**: Switch always ON before engine start and switch OFF after engine has stopped and propeller remains still.

Navigation lights: Switch ON before engine start and turn OFF after engine has stopped

**Landing light:** Used when visibility has lowered. (Weather, sun low in horizon, night...) or by decision of PIC.

#### PARKING BRAKE

Parking brake shall be released just before taxi and locked when aircraft is stopped. Parking brake shall never be used in runway. Parking brake should not be used for longterm parking if wheel blocks are available (brakes may jam)

#### FI APS

"Speed xx, flaps yy" - Check IAS is on white arc and call out loud desired landing flap setting. Settings are "up, ten, two-zero, three-zero"

Author Cessna 150 Standard OM Appendix 1A 4
VLE operating procedures 10.12.2011

#### **ENGINE PRIMING**

Engine is primed by using manual pump on the left side of the left yoke. When priming, mixture is set rich (full forward) and throttle opened for 1 cm. Release pump, pull it full aft, let it fill with fuel (buzzing sound) and push in firmly.

Normally engine should be primed 2 or 3 times, in winter conditions 3 to 5. Engine starting should be committed immediately after priming to avoid fuel leakage and consequent intake manifold fire.

After priming, lock the pump piston by pushing it in and turning half a turn.

I f engine becomes over-primed it will not start. Excess fuel is removed by locking the primer, setting the mixture lean (knob full aft), full throttle and cranking the engine. Usually engine starts up, runs for a couple of seconds and cuts off. After this, engine priming and starting should be done normal way.

Author Cessna 150 Standard OM Appendix 1A VLE operating procedures 10.12.2011

## BEFORE ENGINE START

When starting engine, observe that the propeller slipstream will not cause damage to the people or property nearby! If you have to start the engine in small space, taxi to a more spacious area immediately after starting and then continue with checklists.

#### ENGINE FIRE DURING START

Engine fire during start is the most common fire in single-engined piston aircraft. Usually this happens in cold weather after excessive engine priming when unvaporized fuel leaks out of intake manifold and ignites. Engine fire is usually very hard to observe from the cockpit.

Proper actions in engine fire

**Continue starting** Crank the engine and try to suck flames into the

engine

If engine starts, set 1700 rpm. If engine will not start, continue cranking. In both cases, continue with following actions

Mixture lean Set mixture idle cut-off (knob fully aft)

**Fuel valve OFF**Close fuel valve
Magnetos OFF
Turn magnetos OFF

Master switch OFF Turn battery switch and alternator OFF

**Extinguish fire if needed**Use the fire extinguisher

**Inspect damage** After a fire aircraft must be checked by a qualified

maintenance personnel

5

Cessna 150 Standard OM Appendix 1A 6 Author 10.12.2011 VLE operating procedures

#### PASSENGER BRIEFING

Passenger briefing shall be performed whenever passengers are on board. It should include at least following items:

- Use of the seat belts
- Use of the doors
- Evacuation
- First aid kit
- Fire extinguisher
- Proper actions in emergency
- Engine & electrics shutdown
- Smoking ban
- Use of mobile phones
- Use of life vests, if applicable

## **INSTRUMENT CHECK 1 (BEFORE TAXI)**

<sup>&</sup>quot;Airspeed" - Air speed indicator should indicate zero

<sup>&</sup>quot;Wings level" - Check artificial horizon is level

<sup>&</sup>quot;QNH xxx, altitude xxx ft - Set altimeter

<sup>&</sup>quot;Slip & turn" - Check slip & turn indicator

<sup>&</sup>quot;Heading xxx" - Set directional gyro according to magnetic compass

<sup>&</sup>quot;Vertical speed" - Check vertical speed indicator (VSI)

Author Cessna 150 Standard OM Appendix 1A VLE operating procedures 10.12.2011

#### **EMERGENCY PROCEDURES**

Emergencies and abnormal situations during flight are quite rare and surprising. In an emergency there's usually no time to use checklists or to think proper actions for a long time. Following by-heart items **Rejected take-off, Ground emergency, Engine power loss in flight and Forced landing** should be studied thoroughly and briefed before every flight.

7

In other emergencies, actions should be taken according to the aircraft flight manual and checklists.

#### Rejected take-off

Take-off run will be rejected in case of a tire failure, engine failure, traffic etc.

"STOP" Call out aloud

"Throttle idle" Retard the throttle to idle

"Brakes" Keep the a/c on the runway centerline and apply

brakes as required

"Inform ATC" Inform air traffic control about the rejected take-off, its or other traffic reason and whether you vacate the runway or not.

#### **Ground emergency**

Fire or other situation, in which the aircraft must be evacuated rapidly on ground.

"Parking brake" Set parking brake -> prevents a/c from moving "Fuel selector OFF" Close fuel selector -> shuts down the engine,

prevents fire from spreading

"Mixture CUT-OFF" Pull mixture knob full aft-> shuts down the engine,

prevents fire from spreading

"Magnetos OFF" Set magnetos OFF -> shuts down the engine,

prevents accidental restart (propeller)

"Inform ATC" Inform ATC about the evacuation and your situation "Master switch OFF" Turn off master switch and alternator -> reduces risk

of fire

**"Evacuate w/ fire** Evacuate people to the rear sector of the a/c, extinguish the

**extinguisher"** fires if possible

Author Cessna 150 Standard OM Appendix 1A 8 VLE operating procedures 10.12.2011

#### Engine power loss in flight

A/c loses all or part of its engine power in flight due to icing, fuel problems or technical failure.

"Speed 70 mph (60 KIAS)" Trim the plane to best gilde ratio speed

"Choose landing spot" Choose suitable spot for forced landing and fly

towards it.

"Carb heat ON" Pull carburettor heat fully aft (open) and leave it open

"Primer IN" Check primer pump is in and locked

"Fuel selector OPEN" Check fuel selector is open "Mixture RICH" Set mixture full rich (forward)

"Check magnetos, try to start" Check magnetos are in BOTH position. If engine runs

roughly/powerlessly, try LEFT or RIGHT position. If

engine has stopped completely, try START.

"Inform ATC" Inform ATC about your situation, location and

intentions

#### **Forced landing**

Situation, in which a forced landing is imminent. These actions should be performed after "Engine power loss in flight".

"MAYDAY" Send emergency message containing your situation,

location and intentions.

"7700" Squawk 7700

**"Fuel selector OFF"**Close fuel selector to reduce the risk of fire and to

ensure that the engine will not restart in wrong

time/place

"Mixture CUT-OFF" Set mixture lean (full aft) -> shuts down the engine,

reduces the risk of fire

"Magnetos OFF" Set magnetos OFF -> Shuts down the engine and

prevents its restart in wrong time/place

"Flaps" Set flaps as required. Recommended 30°

"Master switch OFF" Set master switch and alternator OFFjust before

touchdown -> reduces the risk of fire

Author VLE

Cessna 150 Standard operating procedures

OM Appendix 1A 10.12.2011

9

## **TAXIING**

In single-pilot operations checklists shall not be read during the taxi. Checklist items are completed by heart and checked after the taxi. If checklist should be read or a clearance copied during taxi, aircraft shall be stopped in a suitable place.

In the beginning of taxi check that the propeller slipstream will not cause damage to the people or property, and the wingtips or tail section will not hit anything. Immediately after leaving parking lot, check brakes and steering and call out:

"Brakes"

"Steering"

If brakes or steering do not work properly, shut down the engine immediately and let the plane to stop.

Proper taxi speed at apron and on narrow taxiways is walking speed, slow running at normal taxiways. Airspeed indicator should indicate zero all the time. Control taxi speed with throttle: ca. 1000 rpm is usually good setting. If braking is needed, apply brakes firmly and release the brakes. Do not keep brakes pressed half way: brake pads and discs wear out faster, and in the winter snow may melt to brakes jamming them.

Avoid holes, ice and patches of water if possible. When taxiing on bumpy gorund, keep the yoke pulled fully aft: this reduces load on nose wheel. In brisk crosswind, turn the yoke into the wind to reduce swinging of the aircraft and to improve steering.

Before crossing runways, observe carefully to your right and left. Call out:

<sup>&</sup>quot;Right side clear, left side clear"

Author Cessna 150 Standard OM Appendix 1A 10 VLE operating procedures 10.12.2011

#### **INSTRUMENT CHECK 2**

Instrument check 2 is completed during taxi into a corner or a curve.

"Gyro" Check proper action of the directional gyro against the magnetic

compass (moves smoothly, reading increases or decreases

properly)

"Slip & turn OK" Check proper action of turn & slip indicator (when turning left, turn

indicator indicates left turn and ball slips to the right)

"Wings level" Check proper action of artificial horizon: wings should remain

level during turns

Author Cessna 150 standard OM Appendix 1A 11 VLE operating procedures 10.12.2011

#### TAKE-OFF BRIEFING

Take-off briefing is intended to make a clear picture of a take-off and actions during it. T/O briefing shall be performed before every flight, and it includes following items:

- Runway in use
- T/O procedure (normal / short field / cross wind, rotation speed)
- Safe turning altitude (normally 400 ft AGL rounded to next hundred feet, not before runway end)
- Heading/altitude after take-off
- Actions in case of engine failure during initial climb

#### Example:

"Runway 36, normal take-off, rotation 55 mph (50 kts), when passing 500 ft right turn to DEGER climbing to 1000 feet. In case of engine failure landing to front sector, head wind"

"Runway 08, cross wind take-off, rotation 55 mph (50 kts), when passing 600 ft right turn to SALPA climbing to 1000 ft. In case of engine failure landing to front sector, head wind"

Author Cessna 150 standard VLE operating procedures

OM Appendix 1A 10.12.2011

## TAKE-OFF AND CLIMB

Normal take-off is commenced without flaps. Initial climb to 1000 ft AGL shall be commenced at **75 mph** (65 kts) IAS. After that, use cruise climb speed **85 mph** (75 kts) IAS.

In short field take-off, when aircraft has passed obstacles and speed is at least **70 mph** (60 kts) IAS, flaps are selected in and climb continued.

Climbs shall be performed with max power and mixture full rich. After passing 3000 ft mixture should be leaned according to aircraft flight manual to achieve best performance.

During take-off following actions and call-outs shall be performed:

"Max power" Open throttle fully and check mixture is full rich and carburator

heat is closed

"Engine" Check tachometer reading increases (min. 2150 rpm) and engine

instruments are on green.

"Speed alive" Check ASI reading increases

**"55, rotation"** When reaching **55 mph** (50 kts) IAS start rotation.

## CRUISE AND AIRWORK

When reaching desired cruising altitude, accelerate to **100 mph** (90 kts) IAS, whichafter set 65% power according to the aircraft flight manual. Lean mixture as required. During cruise, monitor engine instruments and fuel consumption. When passing waypoints, mark remaining fuel to operational flight plan.

If conditions are favorable to engine carburator icing, monitor carburator temperature indicator, engine run and rpm. If engine starts to run roughly or rpm drops without reason, open carburator heat fully for one minute and then close it. Carburator heat shall not be kept fully or partially open continuously.

Before practising stalls, slow flight, unusual attitudes or steep turns, you shall

- Remove all loose objects and ensure seat belts are locked and tight
- Check airspace with S-turns to your right and left
- Set mixture rich
- Open carburator heat when reducing power

12

Author Cessna 150 standard OM Appendix 1A 13 VLE operating procedures 10.12.2011

#### **STALLS**

Cessna 150 has normal stalling characteristics. Stall warning horn activates 5-10 mph (kts) before stall. Stall is recovered by lowering the aircraft's nose ca. 5° below horizon, applying max power and reducing flap setting. When airspeed starts to increase, aircraft is set to climb and flaps taken up. Altitude loss in correctly performed stall is less than 100 ft.

"Stall" Call out aloud and release the yoke pressure
"Max power" Apply full throttle, check carburator heat is closed

"Flaps 10" If flaps are down, check airspeed is more than 65 mph (55 kts)

IAS and set flaps to 10°. If flaps are up, they shall be kept up.

"Safe speed, When aircraft is climbing and airspeed more than 70 mph (60 kts)

**safe altitude,** IAS, set flaps up.

flaps up"

#### SLOW FLIGHT

## Speeds in slow flight

Without flaps 60 mph (55 kts) IAS Flaps 30° 55 mph (50 kts) IAS

When recovering from slow flight, apply full throttle and close carburator heat. When airspeed is more than **65 mph** (55 kts) IAS, set flaps 10°. When accelerating through **70 mph** (60 kts) IAS, set flaps up. Call-outs are the same as with stalls, but "Stall" is omitted.

Author Cessna 150 standard OM Appendix 1A 14 VLE operating procedures 10.12.2011

#### RECOVERIES FROM UNUSUAL ATTITUDES

#### Nose up, decreasing airspeed

Set max throttle and close carburator heat. Lower the nose to the horizon and then level the wings. Let aircraft accelerate and select flaps up (if applicable). When passing **70 mph** (60 kts) IAS set aircraft to climb to safe altitude.

#### Nose down, increasing airspeed

Set throttle to idle. Level the wings (verfiy from horizon). Gently pull the nose above the horizon and check speed. Apply max power and climb to the safe altitude at Vy.

ATT! When practising nose down – attitudes, remember not to exceed highest allowed airspeed **162 mph** IAS (Vne) or engine rpm!

#### STEEP TURNS

Before turningf set ~2500 RPM. Increase bank angle to 45 or 60° and monitor airspeed: it should remain at **100 – 90 mph** (90-80 kts) IAS all the time.

Author Cessna 150 standard VLE operating procedures

OM Appendix 1A 10.12.2011

15

## APPROACH AND LANDING

#### APPROACH BRIEFING

Approach briefing should answer the following questions: How to approach this airfield? How to land there? What to do in case of a go-around? Approach briefing should be performed 10-15 minutes before arrival and it shall contain following items:

Joining downwind/base/final Section of a traffic circuit according to

clearance/approach chart

runway xxx,Runway in usevia xxxReporting point

xxx 1000 ft, traffic circuit 600 ft , Altitude at reporting point /

field elevation 120 ft traffic circuit / field elevation above/below

sea level

In case of missed approach.... What to do in case of a go-around

"Joining right base runway 36 via DEGER. DEGER 1000 ft, traffic circuit 600 ft, elevation 57 ft. In case of a missed approach right-hand traffic circuit 600 ft"

"Joining downwind 26 via MYLLY. MYLLY 1200 ft, traffic circuit 1000 ft, elevation 339 ft. In case of a go-around traffic circuit 1000 ft"

#### FINAL CHECK

Final check is used to ensure that the aircraft is in landing configuration and also ready for go-around if needed. Final check is more important when flying heavier aircraft with retractable landing gear.

"Final check"

"Mixture rich"

"Carb heat"

"Flaps"

Check mixture is set full rich
Check carburator heat is open
Check proper landing flap setting

Author Cessna 150 standard OM Appendix 1A 16

VLE operating procedures 10.12.2011

#### MISSED APPROACH / GO-AROUND

In missed approach a landing must be cancelled due to other traffic, unstable approach, weather or technical problems. A go-around shall always be commenced firmly and without delay.

"Going around" Call out aloud

"Max power" Set max power, close carburator heating

"Flaps 10" Select flaps 10° If flaps are up, they shall be kept up "Safe speed, safe When passing 200 ft AGL OR clear of obstacles, and altitude, flaps up" airspeed is 70 mph (60 kts) IAS or greater, select

flaps up and continue climb at Vy

#### AFTER LANDING

After landing vacate runway without hurry or delay. After vacating runway, following items are completed by heart:

"Transponder" Set transponder Standby "Carb heat" Close carburator heating

"Flaps" Select flaps up
"Pitot heat" Set pitot heat OFF

Taxi to a parking lot and complete "After landing" and "Parking" checklists. When leaving the aircraft, check following items:

- Aircraft journey logbook is properly filled
- Control lock is set
- All electrical equipment is switched OFF
- Parking brake is released
- Your own things and trashes are taken away from the a/c
- Pitot cover and wing covers (if applicable) are properly set
- Aircraft is properly tied down
- Wheel blocks are set
- Flight plan is closed


Author VLE

Cessna 150 Standard operating procedures


OM Appendix 1A 10.12.2011 17

## FLIGHT PROFILES C150

#### NORMAL TAKE-OFF



#### SHORT FIELD TAKE-OFF




Author VLE

Cessna 150 Standard operating procedures


OM Appendix 1A 10.12.2011

## 18

#### NORMAL APPROACH



#### SHORT FIELD APPROACH




Author VLE

Cessna 150 Standard operating procedures


OM Appendix 1A 10.12.2011

#### 19

#### STALL IN CLEAN CONFIGURATION



#### STALL IN LANDING CONFIGURATION




Author VLE

Cessna 150 Standard operating procedures

OM Appendix 1A 10.12.2011 20

#### MISSED APPROACH



#### TRAFFIC CIRCUIT

