

Go to GitHub-Robocon-Useful-resource download en.flasher-stm32.zip & unzip




Open STMFlashLoader Demo






And choose the port *port not everyone is same,Please go to computer Management check(windown + x, g). Then click Next.




Click next





Click download to device



Choose file than click next

