MEWP ACCESS





Guarding of Works

All works must be in accordance with Safety at Street Works Code of Practice (RED Book) With the work area adequately guarded and protected.

Pole Testing and Inspections

PRIOR to climbing or working on any pole, you must complete a pole test and inspection: Please refer to Pole testing and Inspection method statement in the Team pack

MEWP access for Overhead installation

- Put on Personal Protective Equipment. Including: Hard hat with chin strap, fire retardant high visibility clothing, harness with short lanyard.
- Assemble all of the equipment to be used and check each item for safety.
- Ensure operator has all equipment and tools available within platform and that they're suitably secured for working aloft.
- Enter MEWP and fix safety harness with short lanyard.
- Ensure hand-tools are secure in basket.
- Ensure MEWP is suitably earthed, not forgetting to CAT and Genny ground prior to fixing earth stake
- Position MEWP below area of work and raise platform to working height.
- Commence installation operations as per plans in reachable area.
- When required carefully move MEWP to new area and commence installation operations
- Keep checking area of floor for obstructions.
- When work aloft has finished descend the MEWP.
- Disconnect the lanyard and exit the MEWP.

Completion of Work:

- Leave site in a clean and tidy state
- All tools and equipment have been removed from site and stored safely in works
- All waste generated is removed in the correct manner
- All barriers, cones and signs are packed away and placed securely in works
- A final sweep of site should be undertaken to ensure all the above points have been ticked

Competencies

- SA001 Safety Overhead
- S8 PIA overhead cable installation
- S9 Pole stepping on congested poles
- NRSWA Unit S1 & S2
- **IPAF** Accredited



HAZARD **IDENTIFICATION**

- Working at Height
- **Falling Objects**
- Contact with Electrical services
- Live Traffic
- Pedestrians
- Weather
- Flora / Fauna



PLANT, EQUIPMENT, **MATERIALS**

- Gate Guards, Barriers, Signs, Cones
- Level 2 Tetra Ladder System
- Tool carry belt (tool tethers)
- Ultrasonic Height measuring device
- Probe & Hammer



EMERGENCY ARRANGEMENTS

- Ensure you are familiar with the emergency arrangements detailed in the CPP
- All work vehicles to carry First Aid Kit and Fire Extinguisher. Ensure provisions are readily available and easily accessible.
- In the event of an emergency MEWP must be lowered to ground level. Where MEWP operator becomes incapacitated, a second person at ground level should lower the MEWP with ground controls.




ENVIRONMENTAL

- Ensure good housekeeping is maintained at all times.
- Ensure a pre-work check is carried out for any environmental
- Spill kits must be available on the vehicle at all times.



PPE REQUIREMENTS

PPE items shown below must be available and worn wear necessary during this task.





COSHH

Refer to COSHH Assessments for further information

Creasot seepage from Pole during hot weather (wear gloves where