

EXCAVATION RISK ASSESSMENT





DOCUMENTS

- Ensure PRE-START SURVEY and RISK ASSESSMENT carried out.
- Where required **PERMIT TO** WORK MUST be used.

SAFE DIGGING

Risk Assessment. IF IN DOUBT - SHOUT!

Always carry out a


• Always use utility plans

to help locate plant.


However, remember: They are NOT accurate

- to within 1 metre. • Utility services are sometimes
- not shown on plans. • Use your eyes to check for










• COMPLETE site specific

UP TO 1.2M

Risk Assessment.

- IMPLEMENT Control
 - measures. • **REVIEW** weekly as
 - a minimum.



• **COMPLETE** Excavation

1.2M TO 1.5M

- Risk Assessment. • IMPLEMENT Control
- measures. BRIEF ALL PERSONNEL on requirements.





• Permit to Work REQUIRED. • IMPLEMENT Control measures.

OVER 1.5M

BRIEF ALL PERSONNEL

on requirements.





• Ensure angle of battering is safe. • Ensure vehicle.

movement is CONTROLLED.

• Batter back the ground

where **SAFE** to do so.





undercutting trench wall.

COLLAPSE if previously excavated or if there is a high water table.

UNSTABLE

GROUND

cracks.

• CHECK nearby area for

• Ground is more LIABLE TO



Permit to Work where required.

Be aware of unstable ground

become UNSTABLE.

adjacent building to

- SUMMARY
- Carry out a suitable and sufficient Risk Assessment and ensure you have a



Use utility plans, check scarring and look for street furniture to locate plant

Avoid trench collapsing when undermining, traffic loading and de-watering

Batter back where safe to do so and control vehicle movement

FOR MORE INFORMATION OR IF YOU HAVE ANY CONCERNS CONTACT

YOUR SHEQ DEPARTMENT