## openreach

ISIS Practice For Openreach & Partners

AEI/BPG/G027

Issue 2, 10-Aug-2021 Use until 10-Aug-2022

Published by AE&I

Privacy- None

## Installation of Dexgreen Tool less PCP Splitter Blocks

### About this document ...

#### **Author**

The author of this document may be contacted at:

Daniel Calver
Access engineering & innovation
(BOI)
Post Point Polaris House
Adastral Park
Martlesham Heath
Ipswich
SUFFLK
IP5 3RE

Telephone: +447795986836

Fax:

Email: daniel.calver@openreach.co.uk

#### **Content approval**

This is the Issue 2 of this document.

The information contained in this document was approved on 10-Aug-2021 by Clive Owens, Copper Connectivity Team Leader

## **Version History**

Version No.	Date	Author	Comments
Issue 2	10-Aug-2021	Daniel Calver	Privacy and Audience markings updated. (Ada Hilton)
Issue 1	18-May-2021	Daniel Calver	New Document

#### **Table of Content**

1	INTR	RODUCTION 5	
2	INST	ALLING THE SPLITTER BLOCK	5
	2.1	LOCATION CHART FOR SPLITTER BLOCKS WITHIN THE (PCP)	
	2.2	FRAME INSTALLATION ON A PCP BACKMOUNT 10	)
	2.3	FITTING IN A TOP BOX 13	
	2.4	FITTING IN A STAND — OFF CABINET 12	2
3		LE PREPARATION AND INSTALLATION (PCP) 12	
4	INST	ALLATION OF CONNECTOR MODULE 13	3
5		IUMPER INSTALLATION	
6	USIN	IG THE TEST ADAPTER	1
7	SPLI	TTER REPLACEMENT	1
Q	STO	RFS	1

#### 1 Introduction.

ATTENTION: Any work carried out on any street furniture will require the cabinets to be scanned with a high voltage detector wand before works commences.

To help alleviate congested ducts between the DSLAM and the PCP, splitters can be moved from the NGA DSLAM Cabinet into the PCP. This process also frees up duct space as only one cable is required between the DSLAM and the PCP instead of the two currently required. The following document explains how to install the Dexgreen Tool less splitter blocks into the PCP in various scenarios.

Note: This document covers Huawei and ECI NGA DSLAM Cabinet tie pairs.

When installing the Dexgreen splitter block in a Top Box ALL blocks must be installed as left hand or right hand installations mixed installations are not permitted

Splitter blocks cannot be installed on Bix or 3M backmounts.

Splitter blocks must be installed in accordance with the NGA-FTTC PCP Splitter-policy ISIS NWK/LNK/559.

## 2 Installing the Splitter Block.

The splitter block can only be installed in PCP's in the positions shown in section 2.1 of this document and must be located in an area on the mounting column that allows a one hundred pair logical spacing.

#### 2.1 Location chart for splitter blocks within the (PCP)

Green/orange in the figs 1-8 indicates planning policy for splitter block mounting position. Only fit blocks where indicated in **GREEN** from fig 1 to fig 8.



Fig 1












Fig8



The splitter blocks cannot be placed in between copper connectors Fig 9

NWK/LNK/C558 NGA – FTTC PCP Splitter – Policy states that only the 2 top positions on either a 300 or 400 back mounts within the PCP.

The two splitter block rule, is to stop excessive jumper management with the PCP as each block when full, will require 200 jumpers each. As this will obstruct the connectors already located within the back mount if placed within a space that is populated with copper connectors.

#### 2.2 Frame installation on a PCP backmount


Select a position on the back mount column for the splitter block, ensuring it is within the 100 pair mounting column position and a ten pair space between the splitter block and the connector strip / splitter block below is maintained. The splitter block occupies a one hundred pair space on the mounting column and should be fitted in a location agreed by the planning team. As detailed in section 2.1 of this document.

WHEN INSTALLED ON A 400 PAIR TOOL LESS BACKMOUNT THE TOP OF THE FRAME MUST BE FITTED TO THE FIRST CONNECTOR MOUNT. WHEN INSTALLED ON A 300 PAIR TOOL LESS BACKMOUNT THE TOP OF THE FRAME CAN BE FITTED TO THE FIRST OR SECOND CONNECTOR MOUNTS.

Instructions on how to fit the splitter block are shown in the video below.

Fitting to a PCP backmount


*Note:* When installing the fixing plates to the frame leave the screws loose to aid installation as shown in picture below.




#### 2.3 Fitting in a Top Box


Instructions on how to fit the splitter block are shown in the video below Fitting in a Top Box

Note: When installing a splitter block in a top Box provision must be made for the Tie cable to be installed on the opposite side to the Jumper management system.



*Note:* When installing a splitter block in a top Box ALL blocks must be installed as left hand or right hand installations mixed installations are not permitted





#### 2.4 Fitting in a Stand – off cabinet

Instructions on how to fit the splitter block are shown in the video below Fitting in a stand-off cabinet

# 3 Cable Preparation and Installation (PCP).

Tie cables should ideally be run within the mounting column, unless it is pre populated with connectors. In this case the sleeved cable can be run behind the existing jumpers and secured to the outside of the back mount column.

## ENSURE THAT THE CABLE IS RUN ON THE OPPOSITE SIDE OF THE BACKMOUNT TO THE JUMPER GUIDE ON THE MOUNTING FRAME OR THE CABLE WILL IMPINGE ON JUMPER RUNNING.

Remove cable sheath so that the cable butt is approximately 120mm above the duct mouth and apply sleeving 12A, Item code, 071931, to the tie cable, ensuring the sleeving runs up parallel to the base of the splitter block. Allow approximately 500mm of conductor to protrude from the sleeving 12A for jointing purposes

This will allow improved cable management alongside the back mounting column. The 12A sleeving can be placed inside the back mount if there are **no connectors** in place on the back mount.

INSTALL MAINTENANCE LOOP AT THE BOTTOM OF THE SLEEVED CABLE, THIS WILL KEEP JUMPER FIELD FREE.

### 4 Installation of connector module

Instructions on how to terminate the tie pair conductors and install the splitters at the rear of the connector module are shown in the video below.

Module installation

Note: When all of the pairs have been installed from the DSLAM to the PCP splitter block, a continuity test on the cable must be completed before any splitters are inserted into the block.

## 5 L2C Jumper installation

Instructions on how to run and terminate jumpers correctly are shown in the video below.

*Note:* The overlenght jumper guide on the side of the frame must be used for all jumper installation otherwise splitter replacement will not be possible

## 6 Using the Test Adapter

Instructions on how use the two pole test adapter are shown in the video below.

Use of 2 pole test adapter

*Note:* ONLY the two pole test adapter Item Code 096461 is to be used on the splitter module.

## 7 Splitter Replacement

Instructions on how remove and replace a splitter are shown in the video below.

Splitter Replacement

*Note:* Always reinstate the jumpers on the overlenght jumper guide on the side of the frame. This will ensure that the splitters can be replaced in the future.

#### 8 Stores

Item	Item code
2 pole test adapter	096461

Splitter connector module	108949
PCP splitter pack of 10	108950
PCP splitter frame	108951
Stand off cabinet kit	108952