## **EXCAVATION BACKFILL**





#### Ensure a Risk Assessment is carried out and control measures put in place.

- Reinstatement of carriageway and footways must be carried out in accordance with the New Roads and Street Works Act 1991(Specification for the reinstatement of Openings in Highways latest edition).
- Check all backfill materials being used conform to SROH/SROR specification.
- Make sure work area is adequately protected and guarded during the works
- 4. Where a Grab Lorry is being utilised to place backfill material within the excavation, an additional operative (2nd mate) must be present to monitor the works and pedestrian movements.
- When using vibrating equipment, HAVS usage must be recorded, always rotate the task.
- 6. Ducts and cables must be adequately protected using fine fill material, ensure material is spread evenly using hand tools removing voids.
- Use lightweight vibrating compaction plate to compact fine fill material.
- Lay marker warning tape/boards along the top of the duct or cable route.
- 9. Backfill excavations to the required level using suitable material.
- Compact in layers using Whacker/Vibrating Plate, complete the required number of passes to achieve compaction.

**Note:** Use a measuring stick to ensure backfill level is correct for road/surface type and does not compromise the depth of surfacing materials.

- Where required, Clegg Tests must be carried out to confirm correct compaction has been achieved.
- Once all backfill works are complete, ensure footway boards and road plates are secured in place where required.



# HAZARD IDENTIFICATION

- Slips, Trips and Falls
- Manual Handling
- Plant & Equipment
- Live Traffic / Pedestrians



# PLANT, EQUIPMENT, MATERIALS

- Rammer / Vibrating Compaction Plate
- Hand Tools (Insulated)
- Warning Marker Tape
- Aggregates
- Grab Lorry



### **EMERGENCY ARRANGEMENTS**

- Ensure you are familiar with the point of work emergency arrangements
- All vehicles to carry First Aid Kit and Fire Extinguisher.



#### **ENVIRONMENTAL**

- Ensure Plant & Equipment is switched off when not in use.
- Only refuel in designated safe areas.
- Spill Kit to be available on site.
- Always remove waste materials from site.



### **PPE REQUIREMENTS**

PPE items shown below must be available and worn where necessary during this task.





COSHH

Refer to COSHH Assessments for further information on the below

DUST	•
PETROL	<b>⋄ ⋄ ⋄</b>