


WORKING NEAR OVERHEAD CABLES





RISK ASSESSMENT

ALWAYS carry out and **RECORD** a Risk Assessment prior to commencing the task.




CABLE


the height of cables. If in doubt seek advice from the asset owner.

7 METRE

NEVER assume










ZONE


can reach inside the exclusion zone. If the spoil is within the exclusion zone, no attempt must be made

Ensure that NO part

of plant or equipment



SAFE STAND OFF DISTANCE



3 METRE

EXCLUSION ZONE





Different pylons and poles have different exclusion

REMEMBER: Overhead cables may go from house to house and NOT be

connected to poles.

(safe working) zones.





equipment frequently cross under live cables, GOAL POSTS must be erected.

Where plant and

Excavator booms

may require height restrictions to be fitted.



This can have FATAL consequences for

cranes/plant.

the DRIVER.


In wet or damp conditions,

electricity can jump large

distances and earth via

STOW JIBS

where overhead cables have been struck by grab lorries leaving site with the JIB/BOOM still raised. Ensure it is stowed



before moving.

• Check cable height.

• Carry out a Risk Assessment.

• Be aware in damp or wet conditions.

• Be aware of different exclusion zones for pylons and poles.

Use goal posts and height restrictions for excavator booms.

• Keep plant and equipment outside the exclusion zone.

• Make sure JIB/BOOM is stowed before moving.



FOR MORE INFORMATION OR IF YOU HAVE ANY CONCERNS CONTACT YOUR SHEQ DEPARTMENT



MGroupServices