



TELEPHONE ENTRY BOX CN 13794 BRICKLAYERS INSTALLATION INSTRUCTIONS

COVER OUTWARDS
FROG UP
TUBES MUST BE INSERTED THROUGH
BOTH HOLES
DO NOT REMOVE COVER
ENSURE MORTAR IN END SLOTS AND
FROG TO LOCK BRICK AND TUBES

LAY "BRICK"

1			© British Telecommunications plc 1	9 DU NO	T SCALE	ORIGINAL SCALE
	DRN			MATERIAL	FINISH	REFERENCES
A2	CKD HEGX					
A 3	CERTIFICATION			INSTALLATION		DISTN:-HQ AND U/G CONSTRUCTION
R700	DATE 20 - 4 - 88	AMENDMENT ISSU	BRITISH TELECOMMUN	ICATIONS JKC	/NSET 3.1.1 CN	14184 8108.1844/2.ET, 6-84.IMP. 8854044.