

No	Activity	Hazard	Person(s) in Danger	Control Measures	Residual Risk Rating
74	All work activities	High Pressure Water Jetting of Telecoms Networks Pedestrians and vehicles, Confined Spaces, Manual Handling, Weather Conditions, Pressurised Systems, Blockage removal	Employees, Other Contractors, Members of the Public	 Wear appropriate PPE. All excavations in highway to be guarded in accordance with NRSWA guidelines (Red Book) and the necessary signage displayed. Manhole cover removed using correct lifting keys or mechanical lifter After manhole cover removal allow 20 minutes natural ventilation. Confined Spaces NC 1 entry controls to be implemented at all times including gas detector. If entering a manhole confined space appropriate to the entry risk are to be followed. Entry Permit to be operated and competencies checked. All operatives clear of manhole prior to jetting operations. High Pressure Water Jetting Operatives trained in High Pressure Water Jetting Operations. Visual inspection of hoses joints and 	



	filters before use and on completion	
	of works.	
	- Follow appropriate hygiene controls.	
	- COSHH assessments	