MGroupServices

Telecom Division

Joint Photo Guide

Joints need to be restrained on a Mobra. If this is not possible you can restrain a Joint on Bearers and Arms or with an A frame. If this is not possible due to a congested box, we need to restrain the Joint and cables with tubing the best way we can. Examples are below

If the Joint is on a Mobra

- 1. Picture of the box lid off.
- 2. Picture of the Joint up on the arm showing Joint number
- 3. Picture showing Cables are restrained.







If the Joint is on Bearers and Arms

- 1. Picture with the box lid off
- 2. Picture showing Joint with Joint number visible
- 3. Picture showing the Joint and cables neatly restrained









If the Joint is on an A Frame

- 1. Picture with the box lid off.
- 2. Picture of Joint showing Joint number.
- 3. Picture showing Joint and Cables are restrained.







If the box is congested

If none of the above are options due to a congested box the Joint and cables will need to be restrained with tubing. Please check with an Avonline supervisor on the standards we require.

