Варианты заданий к лабораторной работе №1

Порядок выполнения работы

- 1. В базовом примере (см. ниже) заменить фрагмент кода, выделенный зелёным, на фрагмент из своего варианта, создать новый проект в Atmel Studio и сформировать исполняемый код (файл «.hex»), проверить работу данного кода на МК.
- 2. Определить зависимость количества тактов, за которое выполняется заменённый блок кода, от констант x и у (и z)
- 3. Вычислить значения констант x и у (и z), при которых блок кода «delay» будет выполняться ровно 1 секунду (при тактовой частоте 8 МГц). При невозможности обеспечения точной величины задержки необходимо дополнить блок кода соответствующим количеством команд NOP (на месте закомментированной команды NOP в базовом примере).

Базовый пример

```
start:
               R20
     SER
               DDRA, R20
     OUT
     IN
               R21, PORTA
     COM
               R21
     OUT
               PORTA, R21
delay:
     LDI
               R17, 255;
     LDI
               R16, 255;
delay sub:
     DEC
               R16
               delay_sub
     BRNE
     DEC
               R17
     BRNE
               delay_sub
     :NOP
     RJMP start
```

Варианты заданий – заменяемые блоки кода

Номер варианта	Фрагмент кода	Номер варианта	Фрагмент кода		
1	delay:	2	delay:		
	LDI R18, 10; z	7.	LDI R18, 10; z		
	LDI R17, 255; y	V	<i>LDI R17</i> , 255; y		
	LDI R16, 255;	c	LDI R16, 255; x		
	delay_sub:		delay_sub:		
	DEC R16		NOP		
	BRNE delay_sub		DEC R16		
	NOP		BRNE delay_sub		
	DEC R17		DEC R17		
	BRNE delay_sub		BRNE delay_sub		
	DEC R18		DEC R18		
	BRNE delay_sub		BRNE delay_sub		

Номер	Φ			Номер	Фил		
варианта	Фрагмент кода		варианта	Фрагмент кода			
3	delay:			4	delay:		
	LDI	R19, 8;	W		LDI	R19, 8;	W
	LDI	R18, 128;	z		LDI	R18, 128;	\mathcal{Z}
	LDI	R17, 255;	у		LDI	R17, 255;	y
	LDI	R16, 255;	x		LDI	R16, 255;	x
	delay_sub:				delay_sub:		
	DEC	R16			DEC	R16	
	CP	R16, R19			BRNE	delay_sub	
	BRNE	delay_sub			DEC	R17	
	DEC	R17			CP	R17, R19	
	BRNE	delay_sub			BRNE	delay_sub	
	DEC	R18			DEC	R18	
	BRNE	delay_sub			BRNE	delay_sub	
5	delay:			6	delay:		
	LDI	R18, 10;	z		LDI	R18, 10;	\mathcal{Z}
	LDI	R17, 255;	y		LDI	R17, 255;	y
	LDI	R16, 255;	$\boldsymbol{\mathcal{X}}$		LDI	R16, 255;	X
	delay_sub:				delay_sub:		
	LSR	R16			LSL	R16	
	BRNE	delay_sub			BRNE	delay_sub	
	DEC	<i>R17</i>			DEC	R17	
	BRNE	delay_sub			BRNE	delay_sub	
	DEC	R18			DEC	R18	
	BRNE	delay_sub			BRNE	delay_sub	
7	delay:			8	delay:		
	LDI	R16, 10;	z		LDI	R25, 10;	\mathcal{Z}
	LDI	R25, 255;	у		LDI	R24, 255;	y
	LDI	R24, 255;	$\boldsymbol{\mathcal{X}}$		LDI	R16, 255;	X
	delay_sub:				delay_sub:		
	SBIW	R24, 1			DEC	R16	
	BRNE	delay_sub			BRNE	delay_sub	
	DEC	R16			SBIW	R24, 1	
	BRNE	delay_sub			BRNE	delay_sub	
9	delay:			10	delay:		
	LDI	R18, 10;	\boldsymbol{z}		LDI	R18, 10;	z
	LDI	R17, 255;	У		LDI	R17, 255;	y
	LDI	R16, 255;	$\boldsymbol{\mathcal{X}}$		LDI	R16, 255;	X
	delay_sub:				delay_sub:		
	DEC	<i>R16</i>			DEC	R16	
	SBRC	<i>R16, 7</i>			BRNE	delay_sub	
	BRNE	delay_sub			DEC	R17	
	DEC	R17			BRNE	delay_sub	
	BRNE	delay_sub			NOP		
	DEC	R18			DEC	R18	
	BRNE	delay_sub			BRNE	delay_sub	