Share

Artifacts are private by default. You can update sharing permissions from here at any time.

# Booster Valve & Pump Sequencing

How Pump1/Pump2 and the two hydraulic circuits (direction valve A/C + relief valve B/D) are actually driven by `stage.go`'s `Stages` coordinator - reference for anyone reading the control loop or the wiring diagram.

## 01 PUMP LIFECYCLE

Both pumps run for the entire fill, independent of which circuit is mid-stroke - there's no per-stage pump logic.




Pump1 and Pump2 both energise the instant a fill starts and de-energise together on every path that ends a job (normal completion, operator Stop, or a safety fault) - see `controller.go`'s `Start()`, `Stop()`, `superviseJob()` and `raiseFault()`.

## 02 CIRCUIT SYNCHRONISATION

Each circuit (direction valve + relief valve) drives and watches its own pressure independently - but neither direction valve is allowed to reverse until **both** circuits have finished their stroke and re-opened their relief valve. That barrier is the whole mechanism that keeps the two cylinders in lockstep.

