NW: 46° 10′ 36′′ N / 007° 11′ 33′′ E

Z1: 46° 16' 40" N / 007° 32' 37" E

46° 17' 46" N / 007° 42' 09" E

Z: Z1 - Z

Altitudes en ft: Hauteurs en ft

Altitudes in ft; Heights in ft

NOTE: When airspace D is not active, monitor TWR FREQ