

# UEFI & EDK II Training

How to Write a UEFI Driver

tianocore.org





## LESSON OBJECTIVE


- What is the UEFI Driver Model
- Details on Driver Binding Protocol
- **Example of UEFI Driver**



# UEFI DRIVER MODEL



## **UEFI Drivers - Location**





## What are UEFI Drivers?

- UEFI Drivers extend firmware
- Portable across platforms
- Enables rapid development
- Produce Protocols



UEFI driver is chained into a link list of Drivers Managing Devices



## Defining a UEFI Driver

UEFI Loadable Image

May produce/consume protocols

Supports complex bus hierarchies

Driver Binding Protocol matches drivers to devices, adds version management

Supports specific hardware, can be unloaded or override an existing driver



## What is a UEFI protocol?

## Protocols


 Interfaces consisting of functions and data structures named by a GUID and stored in the Handle Database


## Handle Database


 Everything in the platform system gets a handle, drivers, devices, Images, etc.


## **GUIDs**


 The UEFI Platform only knows items in the Handle Database by its GUID













## **UEFI Drivers Vs. Applications**

Entry Point Protocol (1)


Protocol (2)


Protocol (3)


**UEFI** Loader


**Driver Initialization** 

**Exit Driver** 













Construction of a protocol

**Protocol Interface** 

Function Pointer
Function Pointer

. . .

Handle Database

www.tianocore.org





## Construction of a protocol

**Protocol Interface** 

Function Pointer
Function Pointer

. . .

Handle Database

#### **UEFI** Driver

#### **GUID 1**

Protocol specific functions

#### GUID 2





Construction of a protocol

**InstallProtocolInterface** 

#### **Protocol Interface**

Function Pointer
Function Pointer

Handle Database

#### **UEFI** Driver

#### GUID 1

Protocol specific functions

#### GUID 2





Construction of a protocol

**InstallProtocolInterface** 

**Protocol Interface** 

Function Pointer
Function Pointer

. . .

Handle Database

#### **UEFI** Driver

#### GUID 1

Protocol specific functions

#### GUID 2





## Construction of a protocol

**Protocol Interface** 

**Function Pointer** 

**Function Pointer** 

**InstallProtocolInterface** 

HandleProtocol(GUID, ...)

Invoking one of the Protocol Services

Handle Database



#### **GUID 1**

Protocol specific functions

#### GUID 2




**Database** 

## **Drivers Produce Protocols**



## Construction of a protocol

InstallProtocolInterface



#### **UEFI** Driver

#### **GUID 1**

Protocol specific functions


#### GUID 2





## Construction of a protocol

**InstallProtocolInterface** 



#### **UEFI** Driver

#### **GUID 1**

Protocol specific functions

#### GUID 2




**Database** 

## **Drivers Produce Protocols**



## Construction of a protocol

**InstallProtocolInterface** 



#### **UEFI** Driver

#### **GUID 1**

Protocol specific functions

#### GUID 2

Protocol specific functions

Device, or next Driver



## **UEFI Driver Binding Protocol**





Supported()

Determines if a driver supports a controller



Start()

Starts a driver on a controller & Installs Protocols



Stop()

Stops a driver from managing a controller



## Supported - PCI Controller Device Handle

#### PCI Controller Device Handle

EFI\_DEVICE\_PATH\_PROTOCOL

EFI\_PCI\_IO\_PROTOCOL

#### **Tasks**

- 1. Opens PCI\_IO Protocol
- 2. Checks
- 3. Closes PCI\_IO Protocol
- 4. Returns: Supported or Not Supported

#### Inputs:

- "This"
- Controller to manage
- Remaining Device Path

#### Supported()

- Checks to see if a driver supports a controller
- Check should not change hardware state of controller
- Minimize execution time, move complex I/O to Start()
- May be called for controller that is already managed
- Child is optionally specified

See § 10.1 UEFI 2.x Spec.



## Start - PCI Controller Device Handle

## PCI Controller Device Handle

EFI\_DEVICE\_PATH\_PROTOCOL

EFI\_PCI\_IO\_PROTOCOL

EFI BLOCK IO PROTOCOL

#### Inputs:

- "This"
- Controller to manage,
- Remaining Device Path

#### Start()

- Opens PCI I/O
- Starts a driver on a controller
- Can create ALL child handles or ONE child handle



## Stop - PCI Controller Device Handle

#### PCI Controller Device Handle

EFI\_DEVICE\_PATH\_PROTOCOL

EFI\_PCI\_IO\_PROTOCOL

EFI BLOCK IO PROTOCOL

#### Inputs:

- "This"
- Controller to manage,
- Remaining Device Path

#### Stop()

- Closes PCI I/O
- Stops a driver from managing a controller
- Destroys all specified child handles
- If no children specified, controller is stopped
- Stopping a bus controller requires 2 calls
  - One call to stop the children. A second call to stop the bus controller itself



## Stop - PCI Controller Device Handle

## PCI Controller Device Handle

EFI\_DEVICE\_PATH\_PROTOCOL

EFI PCI IO PROTOCOL

#### Inputs:

- "This"
- Controller to manage,
- Remaining Device Path

#### Stop()

- Closes PCI I/O
- Stops a driver from managing a controller
- Destroys all specified child handles
- If no children specified, controller is stopped
- Stopping a bus controller requires 2 calls
  - One call to stop the children. A second call to stop the bus controller itself



# UEFI DRIVER EXAMPLE


Examine details of the UEFI Driver - ScsiDiskDxe





edk2/MdeModulePkg/Bus/Scsi/ScsiDiskDxe

- ScsiDiskDxe.inf
- ScsiDisk.c
- ScsiDisk.h







edk2/MdeModulePkg/Bus/Scsi/ScsiDiskDxe

- ScsiDiskDxe.inf
- ScsiDisk.c
- ScsiDisk.h

.inf

[.inf] Entry, Global Protocols



```
[Defines]
INF_VERSION
BASE_NAME
MODULE_UNI_FILE
FILE_GUID
MODULE_TYPE
VERSION_STRING
```

ENTRY\_POINT

[Sources]
 ComponentName.c
 ScsiDisk.c
 ScsiDisk.h

[Packages]
 MdePkg/MdePkg.dec

- $= 0 \times 00010005$
- = ScsiDisk
- = ScsiDisk.uni
- = 0A66E322-3740-4cce-AD62-BD172CECCA35
- = UEFI DRIVER
- = 1.0
- = InitializeScsiDisk

<u>Link to .inf</u> - Entry point function InitializeScsiDisk
Guids and Protocols





edk2/MdeModulePkg/Bus/Scsi/ScsiDiskDxe

- ScsiDiskDxe.inf
- ScsiDisk.c
- ScsiDisk.h

.inf

.h



[.h] Driver's Private Data Structure declaration



## Example: ScsiDisk.h


```
#ifndef _SCSI_DISK_H_
#define _SCSI_DISK_H_

#include <Uefi.h>

#include <Protocol/ScsiIo.h>
#include <Protocol/ComponentName.h>
#include <Protocol/BlockIo.h>
#include <Protocol/BlockIo2.h>
#include <Protocol/EraseBlock.h>
#include <Protocol/DriverBinding.h>
#include <Protocol/ScsiPassThruExt.h>
#include <Protocol/ScsiPassThru.h>
#include <Protocol/DiskInfo.h>
```

Link to ScsiDisk.h UEFI Driver's Private Data Structure declaration







## Example: ScsiDisk.c

```
#include "ScsiDisk.h"
EFI_DRIVER_BINDING_PROTOCOL gScsiDiskDriverBinding = {
  ScsiDiskDriverBindingSupported,
  ScsiDiskDriverBindingStart,
  ScsiDiskDriverBindingStop,
  0xa,
 NULL,
 NULL
};
EFI_DISK_INFO_PROTOCOL gScsiDiskInfoProtocolTemplate = {
  EFI_DISK_INFO_SCSI_INTERFACE_GUID,
  ScsiDiskInfoInquiry,
  ScsiDiskInfoIdentify,
  ScsiDiskInfoSenseData,
  ScsiDiskInfoWhichIde
```

#### **Review:**

- Driver Binding Protocol
- Initialization Entry point
- Supported
- Start
- Stop

Link to ScsiDisk.c



## SUMMARY

- UEFI Drivers manage HW and extend the Firmware
- The UEFI Driver Binding Protocol: Supported, Start and Stop
- Example of UEFI Driver ScsiDisk Driver







## Return to Main Training Page



Return to Training Table of contents for next presentation link





## **ACKNOWLEDGEMENTS**

Redistribution and use in source (original document form) and 'compiled' forms (converted to PDF, epub, HTML and other formats) with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code (original document form) must retain the above copyright notice, this list of conditions and the following disclaimer as the first lines of this file unmodified.

Redistributions in compiled form (transformed to other DTDs, converted to PDF, epub, HTML and other formats) must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS DOCUMENTATION IS PROVIDED BY TIANOCORE PROJECT "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL TIANOCORE PROJECT BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Copyright (c) 2020, Intel Corporation. All rights reserved.