Making Molds
- Mold Max 40 100
-Mold Max 40 Part B
- Vaccoum pump with chamber
- Walls (30 print these)
- Measuring caps (measure 100 A: 10B)
Proceduri:
-30 print valls or make enclosure
- Measure out part A: part B
-Stir thoroughly and pour into Vacuum chance
- Turn vacuum in for 3 minutes
- Pour into moll
- Care time: 1 day
- Remove mold
Platinum cured silicone doesn't cure if using tin cured silicone mold
To prevent come inhibition for platinum-come silicones:
1) Run ration mold through IPA, IPA, and Greenwork (single green
2) let dry and dean off any remaining residue
3) Coat mold with MMMA (acylic lacquer)
4) Cure print with UV while submerged in vater for 30 min
6) Soak in water for 6 hours 7) Ong off and repeat ship 6 1-3 mare times
8) Coat with wold veleage (Easy Meleage 200)