

# Idea Lab One

instrukcja montażu build manual




# Step 1




Assembly sides of frame

# Step 2




Use 8 M3 screws and assembly 4 bottom corners.
Before mounting corners put M3 nuts into corners

# Step 3




Install bottom plate using 4 M3 screws

## Step 4




Y axis assembly. Put 2 Lm08uu linear bearings on to smooth rod Y Put Y end caps onto rods.

## Step 5



Put Y axis rods into cap holes


#### Step 6



Put 22 tooth pulley into rod
Put 2x16tooth pulleys onto rod
Put 2 x 608ZZ bearing onto rods ends
Put 2 x y drive rod bracket onto rod









Put Y axis drive rod into frame and use 4 M3 screws to mount it

#### Step 8




Put 2 625ZZ bearing into Y bearing holder and use M5 screw with nut to mount it

# Step 9




Use 4 M3 screws with nuts to mount Y bearing holders

# Step 10




Put M3 nuts into all corners and assembly middle corners and front top corners with 12 M3 screws

#### Step 11



Put 14 tooth pulley onto motor shift. Next ude 2 M3 screws to assembly motor to x end

#### Step 12



Put x end's onto LM8UU bearings When You looking from back motor x end should be on the right