

If No transparent material is found, cut holes and stick polythene securely (Shown in green)