UUT Report

Station ID: IT-W-7303101

Serial Number: NONE

Date: venerdì 14 aprile 2023

Time: 12:20:31 Operator: ITLAVIT1

Execution Time: 00:28:36.009

Number of Results: 145

UUT Result: Terminated

Begin Sequence: MainSequence

(C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\MOD\Complete_test.seq)

UUT Parameters		
Status: Done		
TestResults/Data:		
Product Name:	ARI LV	
Communication Module:	RS485	
UUT_info_comm		
Status:	Done	
TestResults/Data:		
Product type:	ARI HV	
COMM type:	COMM1_RS485	
Product Firmware version:	"	
COMM Firmware version:	"	
General and Architecture and LED		
Status:	Terminated	
Module Time:	1715.01	

Begin Sequence: General and Architecture and LED (C:\Users\itlavit1\OneDrive - ABB\LabRnD_Shared\TestStand\Sequences\MOD\Complete_test.seq)

Additional Results		
Status:	Done	
TestResults/Data	a:	
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power off and the LED is OFF.	
Status:	Passed	
Additional Result	S S	
Status:	Done	
TestResults/Data:		
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT-Active state.	
Status:	Passed	
Additional Results		
Status:	Done	
TestResults/Data:		
PopupString:	Check that the LED is "Blinking Green" in both active and close configurations.	
Status:	Passed	
Additional Results		

Status:	Done	
TestResults/Data:		
PopupString:	Check that the LED is "Blinking Green".	
Status:	Passed	
Additional Results		
Status:	Done	
TestResults/Data	:	
	Check that manual opening and closing of the device shall be possible when the device is power ON and in NOT- Active state.	
Status:	Passed	
Additional Results		
Status:	Done	
TestResults/Data	:	
PopupString:	Check that the LED is "Blinking Green"in both active and close configurations.	
Status:	Passed	
Additional Results		
Status:	Done	
TestResults/Data	:	
PopupString:	Check that the LED is "Blinking Green".	
Status:	Passed	
Additional Results		
Status:	Done	
TestResults/Data	:	
PopupString:	Check that the LED is "Blinking Green"in both active and close configurations.	
Status:	Passed	
Additional Results		
Status:	Done	
TestResults/Data	:	
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.	
Status:	Passed	

Additional Results	
Status:	Done
TestResults/Data:	
PopupString:	Check that the LED is "Fix Green"in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
TestResults/Data:	
PopupString:	Check that the LED is "Blinking Green".
Status:	Passed

Additional Results	
Status:	Done
TestResults/Data:	
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Check LED Status		
Status:	Failed	
Additional Results		
Status:	Done	

TestResults/Data:		
PopupString:	Check that the LED is "Fix Green"in close active configuration and "Blinking green" in open active configuration.	
Status:	Failed	

Additional Results	
Status:	Done
TestResults/Data:	
PopupString:	Check that the LED is "Fix Green".
Status:	Passed
Additional Results	
Status:	Done
TestResults/Data	a:
PopupString:	Check that manual opening and closing of the device shall be possible when the device is power ON and in Active state.
Status:	Passed

Additional Results	
Status:	Done
TestResults/Data:	
PopupString:	Check that the LED is "Fix Green"in close active configuration and "Blinking green" in open active configuration.
Status:	Passed
Additional Results	
Status:	Done
TestResults/Data	a:
PopupString:	Check that when the ARI is power ON an auto-reclosing command is executed.
Status:	Passed
Additional Results	
Status:	Done
TestResults/Data:	
PopupString:	Check that the LED is "Fix Green" after autoreclose.
Status:	Passed
Check LED Status	
Status:	Failed
Check LED Status	
Status:	Failed

End Sequence: General and Architecture and LED

End Sequence: MainSequence

End UUT Report