UUT Report

Station ID:	IT-W-7303101
Serial Number:	NONE
Date:	lunedì 30 ottobre 2023
Time:	11:19:46
Operator:	administrator
Execution Time:	191.0932605 seconds
Number of Results:	217
UUT Result:	**Terminated**
Product:	MOD LV
Product type:	MOD HV
Comm type:	COMM1_RS485
Product FW Version:	56010805
Comm FW Version:	56010000

Begin Sequence: MainSequence
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Simultaneous trip_open	
Status:	Skipped

General and Architecture and LED	
Status:	Skipped

Input-Output	
Status:	Skipped

Power Outage	
Status:	Skipped

Motor Driver	
Status:	Skipped

Modbus Register check	
Status:	Terminated
Module Time:	183.2060986

Begin Sequence: Modbus Register check
(C:\Users\ITLUBAR5\ABB\LABRND VITTUONE - LabRnD_Shared\TestStand\Sequences\MOD\General_test.seq)

Internal communication failure	
Status:	Done
Register Value:	OK

Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus worked.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked during dead time.
Status:	Passed

Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed
input	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Communication	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
input	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Communication	
Status:	Done
Register Value:	Disable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	

Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
input	
Status:	Done
Register Value:	Enable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input worked.
Status:	Passed
Communication	
Status:	Done
Register Value:	Enable
Pass/Fail Test	
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing and opening via input worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing and opening via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote closing via modbus worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via input has not worked.
Status:	Passed
Additional Results	
Status:	Done
PopupString:	Check that the remote opening via modbus worked.
Status:	Passed
Status Breaker	

Status:	Done
Register Value:	Open

Test Status Breaker	
Status:	Passed

Status Breaker	
Status:	Done
Register Value:	Open

Test Status Breaker	
Status:	Passed

Status Breaker	
Status:	Done
Register Value:	Close

Test Status Breaker	
Status:	Passed

Status Breaker	
Status:	Done
Register Value:	Close

Test Status Breaker	
Status:	Passed

Status Breaker	
Status:	Done
Register Value:	Open

Test Status Breaker	
Status:	Passed

Status Breaker	
Status:	Done
Register Value:	Open

Test Status Breaker	
Status:	Passed

End Sequence: Modbus Register check

End Sequence: MainSequence

End UUT Report