

Guest OS
Trap Handler
Virtual CPU
Virtual Machine
Virtual Device
Hardware Mediator
Hardware
Hypercall
Virtual
Read / Write
Request
Redirects To The
Responsible
Virtual Machine
Redirects To The
Target
Virtual Device
Parse
Event To
The
Hardware
Format
Validate Operation
[Valid Operation]
Dispatch
or
Enqueue
Forward
Return
"Valid Operation"
Return Virtual
Machine Result
Return Virtual
Device Result
Return
"Invalid Operation"
Return
Hypercall
Result
[Valid Operation]
[Invalid Operation]
[Invalid Operation]
Dispatch
An
Exception