Meridian HX-200 Water Pump: Overview and Specifications

The Meridian HX-200 is a self-priming centrifugal water pump for garden irrigation, rainwater transfer and light drainage. Please read this manual completely before first use and keep it for future reference.

Technical data

- Maximum flow rate: 120 litres per minute
- Maximum head: 38 metres
- Motor power: 1.1 kW, supply 230 V at 50 Hz
- Weight: 14.5 kg
- Maximum water temperature: 40 degrees Celsius
- Housing material: cast aluminium, protection class IP55

Safety Warnings

- Never run the pump dry. Running without water destroys the mechanical seal within minutes.
- Do not pump flammable or corrosive liquids such as petrol, solvents or acids.
- The pump can handle solid particles up to 4 mm in diameter. Larger particles block the impeller.
- Connect the pump only to a circuit protected by a residual-current device (RCD) rated at 30 mA.
- Always disconnect the power plug before any maintenance or cleaning.
- Keep children and pets away from the pump while it is running.
- Do not use the pump for the household drinking water supply.

Installation

- Place the pump on a flat, stable surface with at least 30 cm of free space around it for ventilation.
- Use a suction hose with an inner diameter of at least 32 mm. The maximum suction lift is 7 metres.
- The outlet connection is 25 mm (1 inch).
- Before the first start, fill the pump housing with 1.5 litres of water (priming). Without priming the pump cannot draw water.
- Fit a check valve in the suction line and use a foot filter to keep debris out.

Maintenance

- Clean the inlet filter every 50 operating hours, or more often with dirty water.
- Replace the mechanical seal every 2,000 operating hours. Use the genuine seal kit MK-200.
- The bearings are sealed for life and must not be lubricated.
- Before winter, drain all water from the pump housing and store the pump in a frost-free room.
- An annual inspection by an authorised service partner is recommended.

Troubleshooting and Warranty

Error codes

- E1: dry run detected. The pump stops after 30 seconds. Fill the housing with water and restart.
- E2: motor overheating. The thermal cutoff stops the motor at 85 degrees Celsius. Let it cool down.
- E3: blocked impeller. Disconnect power and remove the blockage.

Status LED

A steady green LED means the pump is running. A flashing blue LED means the pump is in pairing mode with the Meridian app.

Warranty and support

The warranty is 24 months for consumer use and 12 months for commercial use. Proof of purchase is required. Support hotline: +00 800 555 0142.