# Computer Structure and Language

#### Hamid Sarbazi-Azad

Department of Computer Engineering Sharif University of Technology (SUT) Tehran, Iran




(c) Hamid Sarbazi-Azad


Computer Structure & Language -- Lecture#2: Memory & Instruction Format


2


#### **Computer System**


In famous stored-program computer structure of John von Neumann (known as von Neumann model), CPU is connected to the memory system and I/O devices.












Main Memory


**Notation.** We use  $M_{addr}$  to show a memory location with address addr.

For example,  $M_{1000}$  indicates location# 1000 in the main memory.

The content of a memory location (or register, e.g. MAR or MBR) is shown by a pair of parentheses around the location address.

For example,  $(M_{1000})$  indicates the data stored in location# 1000 in the main memory.





c) Hamid Sarbazi-Azad

Computer Structure & Language -- Lecture#2: Memory & Instruction Format

10


#### **Main Memory**


Memory Characteristics:


- Addressable unit: The smallest group of bits that has a unique address in memory. It is 8 bits in most machines.
- Access width/length: The number of bits that can be read or written in one memory access. It is different from machine to machine.
- Word: The number of bits of the operands that CPU process when a machine instruction is executed. It is n-bit in an n-bit machine. In first generation CPUs, we had n=8 or 16. For most current machines we have n=32. But machine with n=64 and larger word sizes are also available.

Typically, Addressable unit size < Word size < Access width.

If not explicitly mentioned, then assume all are of equal size.







## Instruction Format

An Imperative Sentence in human languages is formatted as:

Subject + verb + Object(s).

Example: Mohsen please call Mike.

In machine language, we follow a similar format.

Note that in a computer the only Subject is CPU. So, we need not mention it.

So, a machine instruction looks like:

Verb + Object(s) or Operation + Operand(s)

## **Instruction Format**

So, a machine instruction looks like:

Operation + Operand(s).

Operation can be coded by a bit pattern named Operation Code (or OpCode) and Objects are location addresses indicating Operand(s) in binary patterns.

So, the instruction format in an n-address machine looks like:



c) Hamid Sarbazi-Azad Con

Computer Structure & Language -- Lecture#2: Memory & Instruction Format

16

#### **Instruction Format**

**Example**: In a 2-address machine:

- memory size is 128 units of 16 bits.
- Operations include Add (opcode=00), Subtract (opcode =01), Move (opcode=10), and No-operation (opcode=11).

For example, machine instruction  $01\ 0001111\ 0001010$  means the operation is Subtract and the two operands are  $M_{15}$  and  $M_{10}$ .

So, the notational instruction can be shown as:

$$M_{15} \leftarrow (M_{15}) - (M_{10});$$

Opcodo


Computer Structure & Language -- Lecture#2: Memory & Instruction Format


17

#### Opcode

#### What information can Opcode give?

- 1. Operation type: add, sub, ....
- 2. Number of operands (if multiple has multiple instruction formats)
- 3. Instruction length (if machine has multiple instruction formats)
- 4. Type of operands: integer, real, signed, ...
- 5. Length of operands: 8 bits, 16 bits, n bytes
- 6. Addressing mode of operands: direct, indirect,...





## **END OF SLIDES**