## 1 | Silicon

- · Integrated circuits changed computer circutries
- · Circuts's sillicon purified as polycillion chunks
  - The cubic seed will form a new cubic sillicon
  - Impurities added to sillicon to cause it to conduct
  - Negative charged free carrier (asinic) => n type
  - Positive charged carrier (boron) => p type
- · Christle ground to form ingots
- · Then, sliced thin as wafers
- · Wafers are then ground thin + removed of surface contaminates
- · Then, wafers are checked for resistivity
- CMOS
  - n-type transitior sandwich a p type region
  - A charge on the gate wolud cause the charge to go through from source => drain
  - Vise, versa
- Meaning, when the P-N circut combinations are on, the N-P combination is off
- High temperature used to grow sillicon dioxide to protect the sillicon as sillicon interacts with pure exygen
- · Photoresist smeared on the wafer, and light is exposed to each part to etch patters
- Then, lazers/plasma/acid guides etching of the wafer suface
- Plasma implimant impurities to cause conductivity
- · Photoresist then washed off
- · The wafer is then cleaned off

Then, the actual circut wires are introduced:

- 1. Deposition of sillican oxite
- 2. Photolithagraphy, masking + etching
- 3. Depositivion of tusten as pulig
- 4. Deposition + potterning of alluminum alloy as wires

Lastly, the water is put into pieces to be placed onto circuts.