

## FlyByWire A380X Checklist

## For simulation purposes only

BEFORE START	
SECURITY INSPECTION	COMPLETE
CKPT PREP	COMPLETE
OXYGEN	_ SET
GEAR PINS & COVER	REMOVE
FUEL QTY	_ LBS +/ LBS
T.O DATA	SET
ALTIMETER	_ INHG/HPA SET
PARK BRK	SET
SIGNS	ON/AUTO
WINDOWS/DOORS	CLOSE
BEACON	ON

AFTER START		
A-ICE	AS RQRD	
F/CTL	СНЕСК	
RUDDER TRIM	NEUTRAL	
PITCH TRIM	СНЕСК	
GROUND EQUIPMENT	CLEAR	

BEFORE TAKEOI	FF
FLIGHT INSTRUMENTS	СНЕСК
TAKEOFF BRIEFING	CONFIRM
V1/VR/V2/FLEX TEMP	СНЕСК
SIGNS	ON
SPLRs	ARM
FLAPS	T.0
AUTO BRAKE	RTO
T.O CONFIG	NORMAL
CABIN CREW	READY
PACK 1+2	AS RQRD
EXTERIOR LIGHTS	SET

AFTER TAKEOFF/CLIMB	
LDG GEAR	UP
FLAPS	0
PACK 1+2	ON
APU MASTER SW	OFF
LAND SW	OFF
ALTIMETER	STANDARD SET

APPROACH	
CABIN CREW	ADVISE
LANDING DATA	SET
AUTO BRAKE/BTV	AS RQRD
LANDING BRIEFING	CONFIRM
ECAM STS	NORMAL
ALTIMETER	_ QNH/HPA SET
LAND SW	ON
MINIMA	SET
SEAT BELTS	ON

LANDING	
A/THR MODE	AS RQRD
SIGNS	ON
LDG GEAR	DOWN
FLAPS	LDG
SPLRs	ARM

AFTER LANDING	ì
EXTERIOR LIGHTS	SET
SPLRs	DISARM
FLAPS	0
APU	START

PARKING	
PARK BRK	ON
EXT LT	AS RQRD
APU BLEED	ON
ALL ENGs	OFF
FUEL PMPs	OFF
SEAT BELTS	OFF

SECURING THE AIRCRAFT	
ADIRS	OFF
OXYGEN	OFF
APU BLEED	OFF
EMER EXIT LT	OFF
SIGNS	OFF
APU	OFF
ALL 3 LAPTOPS	OFF
ALL 4 BATs	OFF