

FlyByWire A380X Checklist

For simulation purposes only

BEFORE START	
CKPT PREP	COMPLETE
GEAR PINS & COVER	REMOVE
PHONES	OFF
FUEL QTY _ KGS	CHECK
FUEL PMPS	ON
BARO REF	QNH_/X-CHECK
SIGNS	ON/AUTO
SEAT BELTS	ON
ADIRS	NAV
V1/VR/V2/FLEX	SET
WINDOWS/DOORS	CLOSE
SURV DEFAULT	SELECT
PARK BRK	AS RQRD
NWS DISC MEMO	AS RQRD
BEACON	ON

AFTER START	
A-ICE	AS RQRD
ECAM STS	NORMAL / CHECK

BEFORE TAKEOFF	
FLIGHT INSTRUMENTS	CHECK
BRIEFING	CONFIRM
FLAP SETTINGS	CONFIG
T.O DATA	SET
SQUAWK	SET
SIGNS	ON
SELT BELT	ON
CABIN	READY
SPLRs	ARM
FLAPS	TO
T.O CONFIG	NORMAL
T.O RWY	CONFIRM
CABIN	SECURE
PACK 1+2	AS RQRD

AFTER TAKEOFF / CLIMB	
LDG GEAR	UP
FLAPS	0
PACK 1+2	ON
APU	AS RQRD
BARO EF	STD/X-CHEK

	APPROACH
BRIEFING	CONFIRM
ECAM STS	NORMAL/CHECK
SEAT BELTS	ON
BARO REF	QNH_ / X-CHECK
MINIMUM	ST

LANDING	
CABIN	SECURE
A/THR	SPEED/OFF
AUTO BRK MODE	MODE/OFF
LDG RUNWAY CONDITION	CHECK
SIGNS	ON
SEAT BELTS	ON
CABIN	READY
LDG GEAR	DOWN
GND SPLRs	ARM
FLAPS	LDG

AFTER LANDING	
SPLRs	DISARMED
FLAPS	0
APU	START
REDUCED ENGINE TAXI	CONSIDER (M1)

PARKING	
PRK BRK	ON
APU BLEED	ON
ALL ENGs	OFF
FUEL PMPs	OFF
SEAT BELTS	OFF
BEACON	OFF
EXT LT	AS RQRD
ALL LAPTOPS	AS RQRD

SECURING THE AIRCRAFT	
PRK BRK / CHOCKS	ON
ADIRS	OFF
OXYGEN	OFF
EMER EXIT LT	OFF
SIGNS	OFF
APU BLEED	OFF
APU	OFF
EXT PWR	AS RQRD
ALL 4 BATs	OFF