I/O System


Computer Organization

Wednesday, 16 October 2024

Many slides adapted from: Computer Organization and Design, Patterson & Hennessy 5th Edition, © 2014, MK and from Prof. Mary Jane Irwin, PSU



Review: Major Components of a Computer




- Important metrics for an I/O system
 - Performance
 - Expandability
 - Dependability
 - Cost, size, weight
 - Security



Introduction

- I/O devices can be characterized by
 - Behavior: input, output, storage
 - Partner: human or machine
 - Data rate: bytes/sec, transfers/sec
- I/O bus connections





I/O System Characteristics

- Dependability is important
 - Particularly for storage devices
- Performance measures
 - Latency (response time)
 - Throughput (bandwidth)
 - Desktops & embedded systems
 - Mainly interested in response time & diversity of devices
 - Servers
 - Mainly interested in throughput & expandability of devices



I/O System Interconnect Issues

- A bus is a shared communication link (a single set of wires used to connect multiple subsystems) that needs to support a range of devices with widely varying latencies and data transfer rates
 - Advantages
 - Versatile new devices can be added easily and can be moved between computer systems that use the same bus standard
 - Low cost a single set of wires is shared in multiple ways
 - Disadvantages
 - Creates a communication bottleneck bus bandwidth limits the maximum I/O throughput
- The maximum bus speed is largely limited by
 - The length of the bus
 - The number of devices on the bus



5

Bus Signals and Synchronization

- Data lines
 - Carry address and data
 - Multiplexed or separate
- Control lines
 - Indicate data type, synchronize transactions
- Synchronous
 - Uses a bus clock
- Asynchronous
 - Uses request/acknowledge control lines for handshaking




Types of Buses

- Processor-memory bus ("Front Side Bus", proprietary)
 - Short and high speed
 - Design matched to memory organization to maximize bandwidth
 - Optimized for cache block transfers
- I/O bus (industry standard, e.g., ATA, SCSI, USB, Firewire)
 - Usually is lengthy and slower, allowing multiple connections
 - Needs to accommodate a wide range of I/O devices
 - Connect to processor-memory bus through a bridge or a backplane bus
- Backplane bus (industry standard, e.g., PClexpress)
 - Allow processor, memory and I/O devices to coexist on a bus
 - Used as an intermediary bus connecting I/O busses to the processor-memory bus



Typical x86 PC I/O System







I/O Bus Examples

	Firewire	USB	PCI Express	Serial ATA	External PCle
Intended use	External	External	Internal	Internal	External
Devices per channel	63	127	1	1	1
Data width	4	1 – 3	2/lane	4	2/lane
Peak bandwidth (MB/s)	375	650	7000/lane 1×, 2×, 4×, 8×, 16×, 32×	600	250/lane 1×, 2×, 4×, 8×, 16×
Hot pluggable	Yes	Yes	Depends	Yes	Yes
Max length	4.5m	5m	0.5m	0.45m	0.2m
Standard	IEEE 1394	USB Implementers Forum	PCI-SIG	SATA-IO	PCI-SIG



Intel i7-4960X Ivy Bridge-E









I/O Management

- I/O is mediated by the OS
 - Multiple programs share I/O resources
 - Need protection and scheduling
 - I/O causes asynchronous interrupts
 - Same mechanism as exceptions
 - I/O programming is fiddly
 - OS provides abstractions to programs



I/O Commands

- I/O devices are managed by I/O controller hardware
 - Transfers data to/from device
 - Synchronizes operations with software
 - Command registers
 - Cause device to do something
 - Status registers
 - Indicate what the device is doing and occurrence of errors
 - Data registers
 - Write: transfer data to a device
 - · Read: transfer data from a device



I/O Register Mapping

- Memory mapped I/O
 - Registers are addressed in same space as memory
 - Address decoder distinguishes between them
 - OS uses address translation mechanism to make them only accessible to kernel
- I/O instructions
 - Separate instructions to access I/O registers
 - Can only be executed in kernel mode
 - Example: x86



Polling

- Periodically check I/O status register
 - If device ready, do operation
 - If error, take action
- Common in small or low-performance realtime embedded systems
 - Predictable timing
 - Low hardware cost
- In other systems, wastes CPU time



Interrupts

- When a device is ready or error occurs
 - Controller interrupts CPU
- Interrupt is like an exception
 - But not synchronized to instruction execution
 - Can invoke handler between instructions
 - Cause information often identifies the interrupting device
- Priority interrupts
 - Devices needing more urgent attention get higher priority
 - Can interrupt handler for a lower priority interrupt



I/O Data Transfer

- Polling and interrupt-driven I/O
 - CPU transfers data between memory and I/O data registers
 - Time consuming for high-speed devices
- Direct memory access (DMA)
 - OS provides starting address in memory
 - I/O controller transfers to/from memory autonomously
 - Controller interrupts on completion or error



DMA/Cache Interaction

- If DMA writes to a memory block that is cached
 - Cached copy becomes invalid
- If write-back cache has dirty block, and DMA reads memory block
 - Reads invalid data
- Need to ensure cache coherence
 - Flush blocks from cache if they will be used for DMA
 - Or use non-cacheable memory locations for I/O



DMA / VM Interaction

- OS uses virtual addresses for memory
 - DMA blocks may not be contiguous in physical memory
- Should DMA use virtual addresses?
 - Would require controller to do translation
- If DMA uses physical addresses
 - May need to break transfers into page-sized chunks
 - Or chain multiple transfers
 - Or allocate contiguous physical pages for DMA



18

I/O System Design

- Satisfying latency requirements
 - For time-critical operations
 - If system is unloaded
 - Add up latency of components
- Maximizing throughput
 - Find "weakest link" (lowest-bandwidth component)
 - Configure to operate at its maximum bandwidth
 - Balance remaining components in the system
- If system is loaded, simple analysis is insufficient
 - Need to use queuing models or simulation



Pitfall: Offloading to I/O Processors

- Overhead of managing I/O processor request may dominate
 - Quicker to do small operation on the CPU
 - But I/O architecture may prevent that
- I/O processor may be slower
 - Since it's supposed to be simpler
- Making it faster makes it into a major system component
 - Might need its own coprocessors!



Pitfall: Peak Performance

- Peak I/O rates are nearly impossible to achieve
 - Usually, some other system component limits performance
 - E.g., transfers to memory over a bus
 - Collision with DRAM refresh
 - Arbitration contention with other bus masters
 - E.g., PCI bus: peak bandwidth ~133 MB/sec
 - In practice, max 80MB/sec sustainable



Measuring I/O Performance

- I/O performance depends on
 - Hardware: CPU, memory, controllers, buses
 - Software: operating system, database management system, application
 - Workload: request rates and patterns
- I/O system design can trade-off between response time and throughput
 - Measurements of throughput often done with constrained response-time



Transaction Processing Benchmarks

- Transactions
 - Small data accesses to a DBMS
 - Interested in I/O rate, not data rate
- Measure throughput
 - Subject to response time limits and failure handling
 - ACID (Atomicity, Consistency, Isolation, Durability)
 - Overall cost per transaction
- Transaction Processing Council (TPC) benchmarks (www.tcp.org)
 - TPC-APP: B2B application server and web services
 - TCP-C: on-line order entry environment
 - TCP-E: on-line transaction processing for brokerage firm
 - TPC-H: decision support business oriented ad-hoc queries



File System & Web Benchmarks

- SPEC System File System (SFS)
 - Synthetic workload for NFS server, based on monitoring real systems
 - Results
 - Throughput (operations/sec)
 - Response time (average ms/operation)
- SPEC Web Server benchmark
 - Measures simultaneous user sessions, subject to required throughput/session
 - Three workloads: Banking, Ecommerce, and Support



Conclusion

- I/O performance measures
 - Throughput, response time
 - Dependability and cost also important
- Buses used to connect CPU, memory, I/O controllers
 - Polling, interrupts, DMA



I/O System

Computer Organization

Wednesday, 16 October 2024

Many slides adapted from: Computer Organization and Design, Patterson & Hennessy 5th Edition, © 2014, MK and from Prof. Mary Jane Irwin, PSU

