ModusToolbox™ Software Training Level 3 – Wi-Fi



Chapter 4b: Cloud Protocol: HTTP

At this end of this chapter you will understand the HTTP protocol, including:

- The architecture and use model of the ModusToolbox™ any cloud *http_client* and *http_server* libraries
- How to use CURL to test HTTP(S) servers
- How to use HTTP(S) to read & write data to the Cloud using RESTful APIs
- How to create an HTTPS connection using TLS
- How to test your HTTP client using HTTPBIN

Note:

If you are taking this course on your own, you will need two CY8CKIT-062S2-43012 kits to do some of the exercises in this chapter. If you are taking this course in a classroom setting, you will only need one kit.

Table of contents

4b.1	Introduction	3
4b.2	HTTP 1.1 protocol	3
4b.2.1	Client request message format	4
4b.2.2	Client request > start line	4
4b.2.3	Client request > start line > HTTP methods	4
4b.2.4	Client request > start line > resources	6
4b.2.5	Client request > start line > options	6
4b.2.6	Client request > headers	6
4b.2.7	Client request > content body	7
4b.2.8	Server response message format	8
4b.2.9	Server response > start line	8
4b.2.10	Server response > start line > status codes	8
4b.2.11	Server response > start line > status message	8
4b.2.12	Server response > headers	g
4b.2.13	Server response > content body	g
4b.3	Client for URLs or "C" URL (CURL)	10
4b.4	Representational State Transfer (REST) & RESTful APIs	14
4b.4.1	Web APIs	15
4b.5	ModusToolbox™ any cloud HTTP 1.1 client library	15
4b.6	ModusToolbox™ any cloud HTTP 1.1 server library	
4b.7	Httpbin.org	24
4b.8	Initial State	
4b.8.1	Introduction	25
4b.9	Using Initial State	26
4b.9.1	Setting up an account, a Bucket, and a Tile	26
4b.9.2	Sending HTTP data	
4b.9.3	Using APIARY	
4b.10	Exercises	
Exercise 1	1: Use CURL to access http://httpbin.org	
	2: Use CURL to access https://httpbin.org using TLS	



4b.11 Related example "apps"	38
Exercise 12: Initial State – Graphing potentiometer position	38
Exercise 11: Initial State – Potentiometer position	
Exercise 10: Initial State – LED state controlled by hardware	
Exercise 9: Initial State – Virtual LED controlled using APIARY and CURL	37
Exercise 8: Use a web API for getting weather conditions	
Exercise 7: Use your kit to POST data to httpbin.org using TLS	
Exercise 6: Use your kit to POST data to httpbin.org	36
Exercise 5: Use your kit to GET data from httpbin.org using TLS	35
Exercise 4: Use your kit to GET data from httpbin.org	34
Exercise 3: Run the AnyCloud_HTTPS_Client/Server example applications	34

Document conventions

Convention	Usage	Example
Courier New	Displays code and text commands	<pre>CY_ISR_PROTO(MyISR); make build</pre>
Italics	Displays file names and paths	sourcefile.hex
[bracketed, bold]	Displays keyboard commands in procedures	[Enter] or [Ctrl] [C]
Menu > Selection	Represents menu paths	File > New Project > Clone
Bold	Displays GUI commands, menu paths and selections, and icon names in procedures	Click the Debugger icon, and then click Next .



4b.1 Introduction

When HTTP came on the scene in the early 90's, it was principally used to send static HTML pages. Over time, dynamic HTTP came into common use (reading and writing databases and creating HTML on the fly). Many companies built big teams of people to develop and deploy HTTP based applications internally to their employees and externally to their customers.

As IoT emerged, it was only natural and financially advantageous for companies to extend their existing infrastructure to enable IoT devices to communicate with the existing Web services. Although HTTP has issues which make it less than "perfect" for IoT, it is still the most important standard because of the huge investment that has been made in the existing Internet infrastructure.


There are essentially two versions of HTTP: 1.1 and 2.0. Although conceptually similar, they are materially different in their implementation.

HTTP 1.1 was released in 1999 and as of 2017 it still serves the bulk (>50%) of the web traffic. HTTP 2.0, which was released in 2015, brings many performance benefits but has seen slow uptake in the market.

ModusToolbox[™] any cloud currently only supports HTTP 1.1.

4b.2 HTTP 1.1 protocol

HTTP 1.1 is an application layer, single transaction, stateless, plain-text, client-server protocol. This means that a client (e.g. your device) opens a connection to a TCP server (in the Cloud), sends an ASCII text request, then the server responds, and the connection is closed. There is no memory in the protocol itself but there might be in an application e.g. Cookies.



HTTP requests and responses are made up of one mandatory start line, an optional group of HTTP headers (same format for client and server) and one optional content body (same format for client and server).



4b.2.1 Client request message format

An HTTP transaction starts with the client opening a TCP socket to the server (or a TLS TCP socket to the server). The client then sends up to four things:

- Client Request Start Line (4b.2.2)
- Headers (4b.2.6) (one or more strings of the form of "headername:headervalue\r\n")
- A "\r\n" line after the last header

Optional: Content Body (4b.2.7) (one payload with as many bytes as required e.g. a file or an html page or a JSON document)

4b.2.2 Client request > start line

The client request start line has five elements:

- The HTTP Method (4b.2.3)
- The requested Resource (0) path
- Optional: Options (4b.2.5) (a '?' followed by a list of optional arguments separated by '&')
- The version of HTTP (for this chapter it will always be "HTTP/1.1"
- A "\r\n"

An example legal client request start line is:

```
GET /ask HTTP/1.1
```

In the above example, *GET* is the HTTP Method, /ask is the Resource, and HTTP/1.1 is the version.

4b.2.3 Client request > start line > HTTP methods

There are 9 <u>HTTP methods</u> which are sometimes called "verbs" because they request a simple action from the server to act upon a Resource. The verbs fit into two categories (Safe/Unsafe, Idempotent/non-Idempotent)

- **Safe** the method doesn't change anything on the server and can be run without fear of side effects. Any method that changes anything on the server is therefore Unsafe.
- Idempotent no matter how many times you run the method, the state on the server state remains the same. For example, if you "PUT" a document to the server, it will only have one instance on the server no matter how many times you run it. As another example, a DELETE will have the same effect no matter how many times you run it. A non-idempotent method changes the state of the server every time you run it. For example, a POST might insert data in the database every time it is run.

4b.2.3.1 GET (safe, idempotent)

For the GET method (https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/GET), the server will reply with an HTTP response with the Content Body of the requested Resource (i.e. the file). The server response will include Headers that will tell the client how long the Content Body is "Content-length" and what is the MIME-Type (4b.2.7) of the Content Body "Content-type".

4b.2.3.2 HEAD (safe, idempotent)

The Head method (https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/HEAD) performs the same operation as "GET" except it only replies with the Headers and does not return the Content Body.



4b.2.3.3 PUT (unsafe, idempotent)

For the PUT method (https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/PUT), the client asks the server to replace the Resource with the Content attached to the message. The server knows the length of the Content based on the Header "Content-length" and the MIME Type based on the Header "Content-type".

4b.2.3.4 PATCH (unsafe, idempotent)

With this method (https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/PATCH) the client is requesting a partial PUT e.g. if the Resource is a document that contains a name and an age, then the client could PATCH just a new age by having content with the updated age by sending a JSON document with "{age:49}".

4b.2.3.5 POST (unsafe, non-idempotent)

For the POST method (https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/POST), the client asks the server to update the Resource based on the Content attached to the message. An example of this method is sending a temperature to the server which will be saved into the database. The server knows the length of the Content based on the Header "Content-length" and the MIME Type based on the Header "Content-type".

4b.2.3.6 DELETE (unsafe, idempotent)

The DELETE method https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/DELETE asks the server to remove the Resource.

4b.2.3.7 OPTIONS (safe, idempotent)

This OPTIONS method https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/OPTIONS asks the server to respond with an HTTP message that has a "Options" header that enumerates the list of legal HTTP Methods for that server.

4b.2.3.8 TRACE (safe, idempotent)

This TRACE method (https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/TRACE) is an infrequently implemented debugging Method that should cause the server to reply with the client message (echo'd back).

4b.2.3.9 CONNECT

The CONNECT method (https://developer.mozilla.org/en-US/docs/Web/HTTP/Methods/CONNECT) requests the server to open a tunneling TCP connection. This method is probably never used in an IoT application.

You should be aware that the idempotence and safety of these methods is established by convention. There is no technical reason why a "GET" couldn't delete the resource or a "PUT" couldn't return the resource, but you should never implement a web server like that.



4b.2.4 Client request > start line > resources

When you look at an http web address (sometime known as a Universal Record locator (URL)) you typically see:

http://server.com/path

or

http://server.com/path?option=28

These URLs are of the form of:

- "http:" specifies the protocol.
- "server.com" is the DNS name of the HTTP server
- "/path" the location of the resource on the HTTP server.
- "?option=28" is an option that is sent to the server (see next section)

In generic terms, a URL is "protocol://serverName/path?option".

In HTTP 1.1 the 2nd and 3rd elements of the client request line are the resource & options which are the same as the path and options from a URL. For example, you might see an HTTP request that looks like this:

```
GET /resource HTTP/1.1
```

Which is a request to the server to please send the document located at "/resource" as an HTTP response.

4b.2.5 Client request > start line > options

Options are appended to the resource location by placing a "?" at the end of the resource path. You can then specify options by adding "option=value" or just "option". You can specify multiple options by separating them with "&". These options are sometimes used to send commands or other information to the server e.g. "user=arh&password=secret".

An example request with an option to format the response as "simple" (what "simple" means is part of the application semantics) might look like this:

```
GET /resource?format=simple HTTP/1.1
```

4b.2.6 Client request > headers

The HTTP headers are just a list of "name: value" pairs, one per line with the name and the value separated by a ": ". The names are case insensitive. The Headers are used to send metadata between the client and server. The metadata may include the type of file being sent, how many bytes are in the file, what kinds of content can the client or server accept, what is the client user, what is the client password, etc. The Host header is required in all client requests. Other headers may be required depending on the request. Here are a few example Header lines:

```
Host: example.com
Content-type: application/json
Content-length: 129
Accept: application/json
X-Some-Header: 1239asdf
Set-cookie: nsatrack=129
```



Note:

You must send "\r\n" at the end of each header line, but ModusToolbox™ any cloud inserts this automatically for you if you use the HTTP library API functions.

The IANA has a <u>standard list</u> of headers and has developed a registration scheme for people to add more. In addition, you can define your own headers that can mean anything that your server/client can agree on. The names of these Headers are generally in the form of "X-something".

Every request to a server must include the "Host" header. Also, there are two headers for specifying the type and length of the content payload, "Content-type" and "Content-length" which are required for any request that includes a payload.

4b.2.7 Client request > content body

The optional body of the message can be sent by the client. It is just a string of bytes that starts right after the "\r\n" after the headers. The number of bytes sent is specified by the header "Content-length" and the format of the body is specified by the header "Content-type".

The legal values of the "Content-Type" header is also known as a "MIME Type". MIME (an old acronym that means Multipurpose Internet Mail Extension) types are specified by the <u>IANA</u> and can be found on their <u>website</u>. Some of the types that are probably useful for IoT applications include:

- application/json
- application/xml
- text/plain

The list runs to 100's of possible types:

Name 🖫	Template ∑	Reference 🖫
1d-interleaved-parityfec	application/1d-interleaved-parityfec	[RFC6015]
3gpdash-qoe-report+xml	application/3gpdash-qoe-report+xml	[3GPP][Ozgur Oyman]
3gpp-ims+xml	application/3gpp-ims+xml	[John_M_Meredith]
A2L	application/A2L	[ASAM][Thomas_Thomsen]
activemessage	application/activemessage	[Ehud_Shapiro]
activemessage	application/activemessage	[Ehud_Shapiro]
alto-costmap+json	application/alto-costmap+json	[RFC7285]
alto-costmapfilter+json	application/alto-costmapfilter+json	[RFC7285]
alto-directory+json	application/alto-directory+json	[RFC7285]
alto-endpointprop+json	application/alto-endpointprop+json	[RFC7285]
alto-endpointpropparams+json	application/alto-endpointpropparams+json	[RFC7285]
alto-endpointcost+json	application/alto-endpointcost+json	[RFC7285]
alto-endpointcostparams+json	application/alto-endpointcostparams+json	[RFC7285]
alto-error+json	application/alto-error+json	[RFC7285]
alto-networkmapfilter+json	application/alto-networkmapfilter+json	[RFC7285]
alto-networkmap+json	application/alto-networkmap+json	[RFC7285]
AML	application/AML	[ASAM][Thomas_Thomsen]
andrew-inset	application/andrew-inset	[Nathaniel_Borenstein]
applefile	application/applefile	[Patrik_Faltstrom]
ATF	application/ATF	[ASAM][Thomas_Thomsen]
ATFX	application/ATFX	[ASAM][Thomas_Thomsen]
atom+xml	application/atom+xml	[RFC4287][RFC5023]
atomcat+xml	application/atomcat+xml	[RFC5023]
atomdeleted+xml	application/atomdeleted+xml	[RFC6721]
atomicmail	application/atomicmail	[Nathaniel_Borenstein]
atomsvc+xml	application/atomsvc+xml	[RFC5023]
ATXML	application/ATXML	[ASAM][Thomas_Thomsen]
auth-policy+xml	application/auth-policy+xml	[RFC4745]

Chapter 4b: Page 7 of 39 Cloud Protocol: HTTP



4b.2.8 Server response message format

Upon receiving a request from a client, the server will respond with:

- Server Response Start Line
- Optional **Headers** (same format as the client header)
- Optional Content Body (same format as the client Content body)

The client can then:

Close the connection

or

 Leave the connection open to possibly send another request (the server will eventually close the connection after a timeout of unspecified length ... generally in the range of seconds.

4b.2.9 Server response > start line

The HTTP server response start line will have 4 elements:

- The protocol (probably "HTTP/1.1")
- The Status Code (a number as defined by the IETF)
- The Status Message (a short human readable text version of the status code). This should not be processed by your client to act, use the Status Code instead.
- A line with just "\r\n"

An example server response start line (indicating success) is:

```
HTTP/1.1 200 OK
```

Or a failure with the infamous 404 error:

```
HTTP/1.1 404 NOT FOUND
```

4b.2.10 Server response > start line > status codes

The server will respond with a 3-digit status code that is defined by the IETF in <u>section 10 of RFC2616</u>. The codes include a wide range of possible things that happened on the server including:

- 200 OK
- 201 Created
- 202 Accepted
- 400 Bad Request
- 404 Not Found

There is a practical discussion of these codes on the Mozilla foundation website.

4b.2.11 Server response > start line > status message

In addition to the server status code, the server will respond with a short description of the status code e.g. "OK" or "Created". You should treat the textual response as informational only. You should not parse it and make decisions based on it. For your application logic only use the server status code.



4b.2.12 Server response > headers

The server uses exactly the same Header format scheme as the client.

4b.2.13 Server response > content body

The server uses exactly the same content body format scheme as the client.



4b.3 Client for URLs or "C" URL (CURL)

CURL is a utility for sending and receiving HTTP requests which is built into Unix (Linux, MacOS) and is also available for Windows (but not built in). CURL is a handy tool to help you figure out what an HTTP website is doing so that you can build your ModusToolbox™ any cloud program to do the same thing. CURL will let you create HTTP requests with all the commands (GET, POST, PUT, ...), any headers you want, plus any content that you want.

For example, if you want to see what options are available on the "anything" resource on the httpbin.org website you can type the command:

```
curl -v -X OPTIONS http://httpbin.org/anything
```

This example will build an HTTP message that looks like this:

```
OPTIONS /anything HTTP/1.1 Host: httpbin.org
```

The website will then reply with the HTTP options that it supports, and you will see the output on the terminal (because of the -v).

The data sent from your client to the server is shown as lines starting with ">" while the response data from the server is shown as lines starting with "<".

```
* Trying 50.19.240.192...

* TCP_NODELAY set

* Connected to httpbin.org (50.19.240.192) port 80 (#0)

> OPTIONS /anything HTTP/1.1

> Host: httpbin.org

User-Agent: curl/7.55.1

> Accept: */*

> HTTP/1.1 200 OK

Connection: keep-alive

Server Response Start Line

> Server: meinheld/0.6.1

> Date: Tue, 05 Dec 2017 18:34:14 GMT

< Content-Type: text/html; charset=utf-8

< Allow: POST, HEAD, PATCH, OPTIONS

< Access-Control-Allow-Origin: *

< Access-Control-Allow-Credentials: true

< Access-Control-Allow-Methods: GET, POST PUT, DELETE, PATCH, OPTIONS

< Access-Control-Max-Age: 3600

< X-Powered-By: Flask

< X-Processed-Time: 0.000541925430298

< Connection #0 to host httpbin.org left intact
```

CURL supports both http (non-secure) and https (secure). If you specify the root certificate using the --cacert option, CURL will validate the certificate before proceeding with the http transaction. If the server requires the client certificate (e.g. AWS), using the --cert option will provide the client's certificate file.

Note that if you specify JSON with the -d option and your JSON has quotes in it, they must be escaped using backslash (\) characters. For example:

```
curl -v -X POST -H "Content-type: application/json" -d "{\"Key1\":\"Value1\"}"
http://httpbin.org/anything
```

If you are using Windows PowerShell to execute the CURL command, replace the double quotes that are <u>not</u> inside the JSON message with single quotes. In that case the above command would be:



```
curl -v -X POST -H 'Content-type: application/json' -d '{\"Key1\":\"Value1\"}'
http://httpbin.org/anything
```

When you specify a body (such as with -d), CURL will automatically calculate and send the Content-length header for you.

In the following table, I show a bunch of CURL commands that are sending requests to httpbin.org which I will talk about in detail in a later section. Some of the useful CURL options are:

Option	Explanation & Example
	Verbose: all the http request and response will be echo'd to the screen
-v	<pre>curl -v http://httpbin.org/get [Alans-MacBook-Pro:WA101 arhS curl -v http://httpbin.org/get * Trying 54.243.197.181 * TCP,NODELAY set * Connected to httpbin.org (54.243.197.181) port 80 (#0) > SET /get HTPP/.1 > Host: httpbin.org > User-Agent: curl/7.51.0 > Accept: */* > HTTP/1.1 200 OK < Connection: keep-alive < Server: meinheld/0.6.1 < Date: Mon, 24 Jul 2017 20:25:44 GMT < Content-Type: application/json < Access-Control-Allow-Origin: * < Access-Control-Allow-Credentials: true < X-Powered-By: Flask < X-Processed-Time: 0.000767946243286 < Content-Length: 213 < via: 1.1 vegur { "args": {}, "headers": ""*/*", "Connection": "close", "Host": "httpbin.org", "User-Agent": "curl/7.51.0" }, "origin": "207.67.13.18", "url": "http://httpbin.org/get" } **Curl_http_done: called premature == 0 **Connection #0 to host httpbin.org left intact</pre>
-X "command"	CURL will execute the specified HTTP command GET, POST, PUT, DELETE, OPTIONS, TRACE, CONNECT, HEAD. If you use PUT, POST you need to specify the content by addingdata curl -v -X OPTIONS http://httpbin.org/get



```
Option
                            Explanation & Example
                            Adds a header to the HTTP request. You can have multiple -H to add multiple headers. If you specify a header that CURL
                            does automatically e.g. "Content-Type:" it will be overridden by specifying this option.
                            curl -v -H 'x-some-custom: someValue' http://httpbin.org
                            [Alans-MacBook-Pro:WA101 arh$ curl -v -H "x-some-custom: someValue" http://httpbin.org/get
                                 Trying 23.21.145.230...
                             * TCP_NODELAY set
                            * Connected to httpbin.org (23.21.145.230) port 80 (#0) > GET /get HTTP/1.1
                             > Host: httpbin.org
                            > User-Agent: curl/7.51.0
                             > Accept: */*
                             > x-some-custom: someValue
                             < HTTP/1.1 200 OK
                             < Connection: keep-alive
                             < Server: meinheld/0.6.1
< Date: Mon, 24 Jul 2017 20:30:24 GMT
-H
                             < Content-Type: application/json
"headername:hea
                             < Access-Control-Allow-Origin: * < Access-Control-Allow-Credentials: true
dervalue"
                             < X-Powered-By: Flask
< X-Processed-Time: 0.00122499465942
                             < Content-Length: 248
                             < Via: 1.1 vegur
                               "args": {},
"headers": {
    "Accept": "*/*",
    "Connection": "close"
                                  "Host": "httpbin.org"
                                 "User-Agent": "curl/7.51.0",
                                 "X-Some-Custom": "someValue"
                                origin": "207.67.13.18",
                               "url": "http://httpbin.org/get"
                               Curl_http_done: called premature == 0
                             * Connection #0 to host httpbin.org left intact
                            Specifies the data for a PUT, POST. CURL will automatically add the "Content-length:" header.
                            curl -v -X PUT -H 'content-type: application/json' -d '{asdf}' http://httpbin.org/put
                            [Alans-MacBook-Pro:WA101 arh$ curl -v -X "PUT" -H "content-type: application/json" -d "{asdf}" http://httpbin.org/put
                                 Trying 107.20.224.87...
                            * TCP_NODELAY set
                              Connected to httpbin.org (107.20.224.87) port 80 (#0)
                            > PUT /put HTTP/1.1
                            > Host: httpbin.org
                             > User-Agent: curl/7.51.0
                            > Accept: */*
> content-type: application/json
                             > Content-Length: 6
                             * upload completely sent off: 6 out of 6 bytes
                             < HTTP/1.1 200 OK
                            < Connection: keep-alive < Server: meinheld/0.6.1
                             < Date: Mon, 24 Jul 2017 20:33:21 GMT
                            < Content-Type: application/json
< Access-Control-Allow-Origin: *
-d "data"
                             < Access-Control-Allow-Credentials: true
                            < X-Powered-By: Flask
--databinary
                             < X-Processed-Time: 0.00127291679382
"data"
                             < Content-Length: 351
                             < Via: 1.1 vegur
                               "args": {},
"data": "{asdf}",
"files": {},
"form": {},
"headers": {
    "Accept": "*/*",
    "Connection": "o
                                  "Connection": "close",
                                 "Content-Length": "6",
"Content-Type": "application/json",
"Host": "httpbin.org",
                                 "User-Agent": "curl/7.51.0"
                                "json": null,
                               "origin": "207.67.13.18",
"url": "http://httpbin.org/put"
                              Curl_http_done: called premature == 0
                            * Connection #0 to host httpbin.org left intact
```



Option	Explanation & Example
	Send output to filename. This only sends the content, not the headers to the file
	curl -o blah.json http://httpbin.org/get
-o filename	[Alans-MacBook-Pro:WA101 arh\$ curl -o blah.json http://httpbin.org/get % Total % Received % Xferd Average Speed Time Time Time Current Dload Upload Total Spent Left Speed 100 213 100 213 0 0 1543 0 1554 [Alans-MacBook-Pro:WA101 arh\$ ls blah.json blah.json [Alans-MacBook-Pro:WA101 arh\$ more blah.json {
	"args": {}, "headers": { "Accept": "*/*", "Connection": "close", "Host": "httpbin.org", "User-Agent": "curl/7.51.0" }, "origin": "207.67.13.18", "url": "http://httpbin.org/get" }
	CURL will make the method HEAD. You will need to use the $-v$ to see the headers because there will be no content sent back by the http server
	curl -vhead http://httpbin.org/get
	Alans-MacBook-Pro:WA101 arh\$ curl -vhead http://httpbin.org/get * Trying 75.101.156.200 **TCP_NODELAY set **Connected to httpbin.org (75.101.156.200) port 80 (#0) > HEAD /get HTTP/1.1 > Host: httpbin.org > User-Agent: curl/7.51.0 > Accept: */*
-head	<pre></pre>
	<pre>via: 1.1 vegur via: 1.1 vegur < Curl_http_done: called premature == 0 * Connection #0 to host httpbin.org left intact</pre>



Option	Explanation & Example
	This will add the header "Cookie: value" to your header
	curl -vcookie 'name=arh' http://httpbin.org/get
cookie "value"	Alans=MacBook=Pro:WA181 arhS curl -vcookie "name=arh" http://httpbin.org/get
cacert server cert.pem	Verify the certificate of the https connection with the certificate.pem root ca. In the example below, if the httpbin.pem does not match the root certificate received from httpbin.org the connection will fail.
	curlcacert httpbin.pem https://httpbin.org/get
cert	Send client_cert.pem to the HTTPS server to verify the client identity
client_cert.pem	curlcert client cert.pem https://httpbin.org/

This <u>link</u> (https://curl.haxx.se/docs/httpscripting.html#The_HTTP_Protocol) takes you to a useful tutorial using CURL with HTTP.

4b.4 Representational State Transfer (REST) & RESTful APIs

REST (https://en.wikipedia.org/wiki/Representational state transfer) is a design philosophy developed by Thomas Fielding for his PhD Dissertation. This philosophy has achieved wide acceptance on the Internet, and many people at least pay lip service to supporting it. In Dr. Fielding's thesis he described 7 characteristics: Uniform Interface, Stateless, Cacheable, Client-Server, Layered System, Code-on-demand. If you want to understand more of the philosophy please go read his thesis or google "rest api definition" or "rest api tutorial".

So now what? A RESTful API is a webserver that implements REST. In other words, an HTTP client can interact with a RESTful HTTP server using the principals outlined by REST. Practically and most commonly this means:

- You send and receive JSON documents
- The returned HTTP server status code tells you what happened with your request
- The HTTP resources are nouns such as:
 - /companies returns a list of the companies
 - /companies/cy is a list of the information about Cypress
 - /companies/cy/products is a list of all Cypress products
- The HTTP client methods are verbs such as:



- GET /companies/cy/products will return a JSON document with a list of all the products
- POST /companies will add a new company to the server (from the attached JSON document)
- DELETE /company/ftdi will delete FTDI from the list of companies

It is common to use options on the resource to perform actions such as:

Filtering /companies/cy/products?type=Wi-Fi

Pagination /companies?page=27

Searching /companies?search=Cypress

Sorting /companies?sort=rank_asc

4b.4.1 Web APIs

A Web API is a publicly available RESTful API. On the Internet, there are countless APIs created by both companies and people. There are a bunch of useful ones out there which you can reliably use in your projects. To find APIs, some web directories have been created including:

- https://www.programmableweb.com/category/all/apis
- https://github.com/APIs-guru/openapi-directory

A few APIs that might be useful include:

- Weather https://www.wunderground.com/weather/api
- Twitter https://dev.twitter.com/overview/api
- Google Translate https://cloud.google.com/translate/docs/translating-text

A vast number of the APIs on the internet use an "API key". This is generally a string of 20ish characters that enable you to access the API. When you register on the website of the API provider, they will tell you the API key. There are two common methods for sending the API keys

- HTTP option /blah/foo/bar?apikey=1234abcd
- HTTP header "X-myapikey: 1234abcd"

4b.5 ModusToolbox™ any cloud HTTP 1.1 client library

In the previous sections of this chapter I talk about the HTTP Protocol and the way it works and is used. In this section I start the process of explaining how to use ModusToolbox™ any cloud to implement HTTP. Fundamentally the ModusToolbox™ any cloud http-client library provides you APIs to build the client request lines, headers and content, and parse the output that comes from responses.

ModusToolbox[™] any cloud has two HTTP libraries, http-client and http-server which provide support for HTTP 1.1 clients and servers respectively. These libraries support both HTTP (non-secure) and HTTPS (secure).

Rather than write all of the code to get a HTTP client running yourself it is much easier to just create an application using the AnyCloud_HTTPS_Client code example and modify it according to your needs.

Note: The AnyCloud_HTTPS_Client code example has not yet been released so we will instead provide you with a template in the exercises.

That being said, the basic steps to set up an HTTP client using the http-client library are:



- 1. Include the wifi-connection-manager and http-client libraries using the Library manager.
- 2. Add the following COMPONENTS to your Makefile:

```
COMPONENTS=FREERTOS MBEDTLS LWIP SECURE SOCKETS
```

3. Add the following DEFINES to your *Makefile*:

```
DEFINES+=HTTP_MAX_RESPONSE_HEADERS_SIZE_BYTES=2048
DEFINES += HTTP_USER_AGENT_VALUE="\"anycloud-http-client\""
```

Note: Change "anycloud-http-client" to your desired user agent name, this name will be sent with all your requests.

```
DEFINES += HTTP_DO_NOT_USE_CUSTOM_CONFIG
DEFINES += MQTT DO NOT USE CUSTOM CONFIG
```

4. Add the following #include to your application code:

```
#include "cy http client api.h"
```

- 5. Initialize the http-client library by calling cy http client init with no arguments.
- 6. Optionally, if using TLS:
 - a. Declare a structure of type cy_awsport_ssl_credentials_t and initialize it to 0:

```
cy_awsport_ssl_credentials_t credentials;
(void) memset(&credentials, 0, sizeof(credentials));
```

- b. Set the client identity, configure the TLS properties, and initialize the server root certificate by populating the following members in the structure created above:
 - const char *client cert The client's certificate
 - size t client cert size The size of the client's certificate see notes below
 - const char *private key The client's private key
 - size t private key size The size of the client's private key see note
 - const char *root ca The root certificate with which to verify the server
 - size t root ca size The size of the server's root certificate see note

Note: The certificates and keys that you specify must consist of the entire string $\underline{including}$ the null termination so you must use \underline{sizeof} instead of \underline{strlen} when specifying the 3 sizes.

Note: The client's certificate and private key are only required if the server validates the client's identity. If not, those entries (and their size) need not be configured.

- 7. Create and configure a structure with the server information:
 - a. Create a struct of type <code>cy_awsport_server_info_t</code> with the info for the server you want to connect to and initialize it to 0:

```
cy_awsport_server_info_t serverInfo;
(void) memset(&serverInfo, 0, sizeof(serverInfo));
```

- b. Initialize the following data members in the structure:
 - const char *host_name The name of the server you want to connect to e.g. "httpbin.org"



- uint16 t port The port of the server you want to connect to
- 8. Register a disconnection callback by setting the value of a cy_http_disconnect_callback_t variable to the name of the function you want to be the disconnection callback. For example:

```
cy http disconnect callback t disconnectCallback = (void*)disconnect callback;
```

- 9. Create a handle for your HTTP client of type cy http client t.
- 10. Create your HTTP client by calling cy http client create. This function takes several arguments:
 - cy_awsport_ssl_credentials_t* A pointer to the struct you populated with TLS information, set this to NULL for an unsecure connection
 - cy_awsport_server_info_t* A pointer to the struct you populated with the server information
 - cy_http_disconnect_callback_t The variable you assigned to the disconnect callback function
 - void* User data to be sent while invoking the disconnect callback. Set this to NULL if you don't want to send anything
 - cy http client t* A pointer to the handle for your HTTP client
- 11. Connect to the HTTP server by calling the function <code>cy_http_client_connect</code>, which takes the following arguments:
 - cy http client t The handle for your HTTP client (this is not a pointer)
 - uint32_t The timeout value for sending messages in miliseconds
 - uint32 t The timeout value for receiving messages in miliseconds
- 12. Declare an array of uint8_t that is large enough to store all the HTTP messages that you will be sending and receiving.
- 13. Declare a struct of type <code>cy_http_client_request_header_t</code>. You will use this struct to specify what kind of request you want to send. This struct has the following data members that you need to populate:
 - uint8_t *buffer A pointer to the array of uint8_t you created previously. This is the buffer that requests you send and responses you receive from the server will be stored in
 - size t buffer len The length of your uint8 tarray
 - size_t headers_len The length of the headers in your request message, this value is updated by the function cy_http_client_write_header. You only need to set it if your application generates your headers
 - cy_http_client_method_t method The HTTP verb you want to send. Use the following enumeration:

```
typedef enum cy_http_client_method
{
    CY_HTTP_CLIENT_METHOD_GET,
    CY_HTTP_CLIENT_METHOD_PUT,
    CY_HTTP_CLIENT_METHOD_POST,
    CY_HTTP_CLIENT_METHOD_HEAD
} cy http client method t;
/**< HTTP Client Method PUT string */
/**< HTTP Client Method POST string */
/**< HTTP Client Method HEAD string */
/**</pre>
```

• int32_t range_start - Indicates the Start Range from where the server should return. If the range header is not required, set this value to -1



- int32_t range_end Indicates the End Range until where the data is expected. Set this to -1 if requested range is all bytes from the starting range byte to the end of file or the requested range is for the last N bytes of the file
- const char *resource path The path to the resource you want to access
- 14. Declare a struct of type cy_http_client_header_t. This will be the struct you use to specify the headers you want. This struct has the following members:
 - char *field The name of your header
 - size t field len The length of your header name see note below
 - char *value The value of your header
 - size t value len The length of your header value see note

Note: The field and value are strings and in this case you do NOT want to include the null termination so you must use strlen rather than sizeof to specify the lengths.

Note: If you need more than one header, declare the $cy_http_client_header_t$ struct as an array where each element in the array will the desired information for one header.

- 15. Write the headers to your HTTP message by calling <code>cy_http_client_write_header</code>, which takes the following arguments:
 - cy http client t The handle for your HTTP client
 - cy_http_client_request_header_t* A pointer to the struct you created previously
 - cy http client header t* A pointer to the struct or array you created previously
 - uint32 t The number of elements you created in the header struct array
- 16. Declare a variable of type cy_http_client_response_t. This will be the location that the server's response to your request is stored in.
- 17. Send your HTTP message and receive the server's response by calling <code>cy_http_client_send</code> with the following arguments:
 - cy http client t The handle for your HTTP client
 - cy http client request header t* A pointer to the struct you created previously
 - uint8 t*-A pointer to the buffer containing the content body of your message
 - uint32 t The length of what you are sending in the content body of your message
 - cy http client response t* A pointer to the variable you created to hold the response

If you don't want to send a content body, you can use \mathtt{NULL} and 0 for the last two arguments.

Note: When receiving the server's response, <code>cy_http_client_send</code> will block until either the buffer you assigned to <code>cy_http_client_request_header_t.buffer</code> is full or until the receive timeout you passed into <code>cy_http_client_connect</code> is reached.

18. To parse for specific headers in the server's response message you first need to create another struct or array of structs of type cy http client header t, and then set their field members to the header



names you want to parse for. Then you can call the function <code>cy_http_client_read_header</code>, which takes the following arguments:

- cy_http_client_t The handle for your HTTP client
- cy http client response t* A pointer to the response from the server
- cy_http_client_header_t* A pointer to the header struct you created in the first part of this step
- uint32 t The number of headers you are parsing for
- 19. To disconnect your HTTP client from the server you can call the function <code>cy_http_client_disconnect</code>, which only takes one argument:
 - cy_http_client_t The handle for your HTTP client
- 20. To delete your HTTP client, you can call the function <code>cy_http_client_delete</code> with the only argument being:
 - cy_http_client_t The handle for your HTTP client

For more details on using the http-client library, see the http-client library documentation.



4b.6 ModusToolbox™ any cloud HTTP 1.1 server library

Rather than write all of the code to get a HTTP server running yourself it is much easier to just create an application using the AnyCloud_HTTPS_Server code example and modify it according to your needs. That being said, the basic steps to set up an HTTP server using the http-server library are:

- 1. Include the wifi-connection-manager and http-server libraries using the Library manager.
- 2. Add the following COMPONENTS to your *Makefile*:

```
COMPONENTS=FREERTOS MBEDTLS LWIP SECURE SOCKETS
```

3. Add the following DEFINE to your *Makefile*:

```
DEFINES+=MAX NUMBER OF HTTP SERVER RESOURCES=<N>
```

Note:

Change <N> to be the max number of resources to be supported by your HTTP server. If you don't set it, the default value is 10.

4. Add the following #include to your application code:

```
#include "cy_http_server.h"
```

- 5. Initialize the http-server library by calling cy_http_server_network_init with no arguments.
- 6. Optionally initialize the server identity, configure TLS properties, and initialize the server root certificate by populating a struct of type: cy_https_server_security_info_t. This struct has data members:
 - uint8 t *certificate The HTTP server's certificate
 - uint16 t certificate length The length of the HTTP server's certificate
 - uint8 t *private key The server's private key
 - uint16 t key length The length of the server's private key
 - uint8 t *root ca certificate A pointer to the root certificate with which to verify clients
 - uint16 t root ca certificate length The length of the root certificate
- 7. Declare a struct of type <code>cy_network_interface_t</code>. Then populate its member data according to the following:
 - cy_network_interface_type_t type The network interface type. Pick this from the enumeration:



Note:

In the above code nw_interface is of type cy_network_interface_t and https_ip_address is of type cy_socket_sockaddr_t.

- 8. Create a variable of type cy http server t. This will be the handle for your server.
- 9. Call the function cy http server create with the following arguments:
 - cy network interface t* A pointer to the struct you created previously
 - uint16 t The port you want your HTTP server to run on
 - uint16 t The maximum number of client connections that can be accepted
 - cy_https_server_security_info_t* A pointer to the variable you created to hold the security info
 - cy_http_server_t* A pointer to the server handle
- 10. Create a function to handle requests from clients. You can copy the following example function and modify it according to your needs:

```
* Function Name: dynamic_resource_handler
*************
* Summary:
* Handles HTTPS GET, POST, and PUT requests from the client.
* HTTPS GET sends the current CYBSP USER LED status as a response to the client.
* HTTPS POST toggles the CYBSP_USER_LED and then sends its current state as a
   response to the client.
^{\star} HTTPS PUT sends an error message as a response to the client if the resource
* registration is unsuccessful.
* url path - Pointer to the HTTPS URL path.
* url parameters - Pointer to the HTTPS URL query string.
   stream - Pointer to the HTTPS response stream.
   arg - Pointer to the argument passed during HTTPS resource registration.
* https message body - Pointer to the HTTPS data from the client.
  int32 t - Returns HTTPS REQUEST HANDLE SUCCESS if the request from the client
* was handled successfully. Otherwise, it returns HTTPS_REQUEST_HANDLE_ERROR.
 ************************
int32 t dynamic resource handler(const char* url path,
                              const char* url_parameters,
                              cy_http_response_stream_t* stream,
                              void* arg,
                              cy http message body t* https message body)
   cy rslt t result = CY RSLT SUCCESS;
   int32 t status = HTTPS REQUEST HANDLE SUCCESS;
   char https_response[MAX_HTTP_RESPONSE_LENGTH] = {0};
   char *register new resource = NULL;
   switch (https message body->request type) {
       case CY HTTP REQUEST GET:
           APP INFO(("Received HTTPS GET request.\n"));
           /* Update the current LED status. This status will be sent
           * in response to the POST request.
           if (CYBSP LED STATE ON == cyhal gpio read(CYBSP USER LED)) {
              led status = LED STATUS ON;
           else{
              led status = LED STATUS OFF;
           sprintf(https response, HTTPS STARTUP WEBPAGE, led status);
```



```
/* Send the HTTPS response. */
            result = cy_http_server_response_stream_write_payload(stream, https_response,
sizeof(https_response));
            if (CY RSLT SUCCESS != result) {
                ERR INFO(("Failed to send the HTTPS GET response.\n"));
            break;
        case CY HTTP REQUEST POST:
            APP_INFO(("Received HTTPS POST request.\n"));
            /* Send the current LED status before toggling in response to the POST request.
             ^{\star} The user can then send a GET request to get the latest LED status
             * on the webpage.
             * /
            sprintf(https_response, HTTPS_STARTUP_WEBPAGE, led_status);
            /* Toggle the user LED. */
            cyhal_gpio_toggle(CYBSP_USER_LED);
            /* Send the HTTPS response. */
            result = cy http server response stream write payload(stream, https response,
sizeof(https_response));
            if (CY RSLT SUCCESS != result) {
                ERR INFO(("Failed to send the HTTPS POST response.\n"));
            break;
        case CY HTTP REQUEST PUT:
            register new resource = (char *)&resource name[0];
            if (https message body->data length > sizeof(resource name)) {
                /st Report the error response to the client. st/
                ERR INFO(("Resource name length exceeded the limit. Maximum: %d, Received: %d",
sizeof(resource name), (https message body->data length)));
                sprintf(https_response, HTTPS_RESOURCE_PUT_ERROR, sizeof(resource_name));
                /\star Send the HTTPS error response. \star/
                result = cy_http_server_response_stream_write_payload(stream, https_response,
sizeof(https response));
                if (CY RSLT SUCCESS != result) {
                    ERR INFO(("Failed to send the HTTPS PUT error response.\n"));
            }
            else{
                memcpy(register_new_resource, (char *)https_message_body->data,
https message body->data length);
                /* New resource request need to be queued. */
                if (pdTRUE != xQueueSend(register resource queue handle, (void
*)&register new resource, 0)){
                    ERR INFO(("Failed to send queue message.\n"));
            break;
        default:
            ERR INFO(("Received invalid HTTP request method. Supported HTTP methods are GET,
POST, and PUT.\n"));
            break;
    }
    if (CY RSLT SUCCESS != result) {
        status = HTTPS REQUEST HANDLE ERROR;
    return status;
}
```



- 11. To define a resource, create a struct of type cy_resource_dynamic_data_t or cy_resource_static_data_t for a dynamic or static resource respectively. For a dynamic resource populate its member data according to the following:
 - url_processor_t resource_handler The name of your function that will handle requests for the page specified by this resource
 - void *arg An argument to pass into your request handler function. Set this to NULL if you don't want to use it

For a static resource populate its member data according to the following:

- const void *data A pointer to the data for this resource
- uint32 t length The length of the data for this resource
- 12. To register resources on your HTTP server, call the function <code>cy_http_server_register_resource</code> with the following arguments:
 - cy http server t The server handle
 - uint8 t* A pointer to the URL of the resource
 - uint8 t* A pointer to the MIME type of the resource
 - cy_url_resource_type The content type of the resource, pick this from the enumeration:

• void* - A pointer to the static or dynamic resource type structure, this is the struct you created previously

Note:

Note You cannot register a static resource while the server is running. If you have already called cy_http_server_start and wish to register a static resource then you must first call cy_http_server_stop before registering a new resource.

- 13. To start the HTTP server, call the function cy http server start with the argument:
 - cy http server t The server handle

For more details on using the http-server library, see the http-server library documentation.



4b.7 Httpbin.org

Httpbin.org is a website that was created to help people test their HTTP (and HTTPS) requests. You can send PUT, POST, GET etc. and it will respond with something simple, often in JSON format to "echo" what you sent.

You can build HTTP requests in CURL to test your ideas about how to interact with different HTTP endpoints (i.e. resources). You could, for example, go to http://httpbin.org/get in your browser and it will return:

```
0
        ...
                                                                                Û
                                         httpbin.org
  "args": {},
  "headers": {
    "Accept": "text/html,application/xhtml+xml,application/xml;q=0.9,*/*;q=0.8",
    "Accept-Encoding": "gzip, deflate",
    "Accept-Language": "en-us",
    "Connection": "close"
    "Cookie": "_gauges_unique_day=1; _gauges_unique_month=1; _gauges_unique=1;
_gauges_unique_year=1",
    "Host": "httpbin.org"
    "Referer": "https://httpbin.org/",
    "User-Agent": "Mozilla/5.0 (Macintosh; Intel Mac OS X 10_12_6) AppleWebKit/603.3.8
(KHTML, like Gecko) Version/10.1.2 Safari/603.3.8"
  origin": "69.23.226.142",
  "url": "https://httpbin.org/get"
```

There are a bunch of endpoints (resources) which allow different HTTP methods to be tested. We will mostly use the /anything resource since (as the name implies) it allows just about anything. It will respond back with an echo of the data that you sent so you can compare to what you intended to send.

```
httpbin.org
•••
httpbin(1): HTTP Request & Response Service
      Freely hosted in HTTP, HTTPS, & EU flavors by Kenneth
      Reitz & Runscope.
BONUSPOINTS
      now.httpbin.org The current time, in a variety of formats.
ENDPOINTS
      / This page.
      /ip Returns Origin IP.
      /uuid Returns UUID4.
      /user-agent Returns user-agent.
      /headers Returns header dict.
      /get Returns GET data.
      /post Returns POST data.
      /patch Returns PATCH data.
      /put Returns PUT data.
      /delete Returns DELETE data
      /anything Returns request data, including method used.
```



4b.8 Initial State

4b.8.1 Introduction

<u>Initial State</u> is a Web API based IoT analysis platform. In other words, it is setup to let you stream data from your IoT devices into their cloud (i.e. they are a cloud services provider). Once your data is on their cloud, you can log into their web platform and display and analyze your data with their extensive library of graphical web-based tools.

Data that you send to the Initial State cloud is organized into a <u>Stream</u> of time stamped key/value pairs. All Streams of data are grouped together into <u>Buckets</u> (which can hold one or more Streams). Each key/value data point that you send can have a time attached with it, or Initial State can automatically attach the timestamp of your upload to the data point.

The key in the key/value pair should be a textual description of what you are recording e.g. temperature, humidity, LED State, etc. The value can be a real number, a text string, an emoji of the form ":code:" e.g. ":smile:".

Data can be displayed using one or more "Tiles". Each tile can display a summary (such as "ON" or "OFF"), a line graph of the values over time, a bar graph, etc. The figure below shows four value tiles and four line graph tiles. You can move Tiles around on the screen or resize them by right clicking on a Tile and selecting "Unlock Layout". You can zoom in on the time scale by clicking in the time bar along the top edge of the Tile screen and dragging the circles to the time range that you want to see.





There is also a Waves App, Line Graph App, and File Source Viewer that can be used to show data in different ways.

For example, if you lived in Kentucky near the Elkhorn Creek you could create a Bucket called "Elkhorn Creek" that has two Streams of data (no pun intended): one with the depth of the water in the creek and another with the temperature in the barn. You could then use the Line Graph App to display the water depth as shown below.




4b.9 Using Initial State


4b.9.1 Setting up an account, a Bucket, and a Tile

- Create a free account at <u>www.initialstate.com</u>.
- Create a new bucket by pressing the little + in the top left part of the screen next to the cloud icon.





Enter a name for the bucket, check the **Configure Endpoint Keys** box to let the server create a Bucket Key and an Access Key, and click the **Create** button at the bottom of the window




Note: You can get back to this window later by clicking on **settings** under the bucket name.


Once you have the Bucket setup, you should see the App Launcher as shown below. Click on the bucket name from the **shelf** window on the left (1) to make sure you are looking at the correct bucket and then click the App Launcher button (2). Use the three lines with an arrow to open/close the shelf (3).



You can also use the buttons along the top to switch to the Tile App, Waves App, Line Graph App, and File Source views (4).



To add a new tile, first select the Tiles App, click **Edit Tiles** (1), and then **Add Tile** (2). Enter the information that you want to display (3) and the tile will be created. Click outside the Add Tile window to close it. You will now see your tile, but it will be empty until you POST data to the bucket for the key that you created.



4b.9.2 Sending HTTP data

You can send HTTP POST requests to Initial State using one of two methods:



4b.9.2.1 JSON

- Server = groker.intialstate.com
- Resource = /api/events
- HTTP Header for X-IS-AccessKey: <yourAccessKey>
- HTTP Header for X-IS-BucketKey: <yourBucketKey>
- HTTP Header for Content-Type: application/json
- HHTP Header for Content-Length: <yourJsonLength>
- A JSON Document with an Array of Keymaps and values. For example, to set the key named "switch" to a value of "on", the JSON would be:

{"key":"switch","value":"on"}

4b.9.2.2 HTTP Option

- accessKey
- bucketKey
- eventKey0
- eventValue0

For example, you could send an event to set the key called "switch" to a value of "on" by sending an HTTP POST request with the following settings:

- Server: https://groker.initialstate.com
- Resource: /api/events
- Options: accessKey=<yourAccessKey>&bucketKey=<yourBucketKey>&eventKey0=switch&eventValue0=on




4b.9.3 Using APIARY


Initial State has documented their Web API with a tool called "APIARY". This is a web-based tool which shows all the APIs and how to use them with examples. It can also switch to "console" mode where you can fill in the boxes in HTTP requests and it will send them to the Initial State web server.

You can access the APIARY documentation from InitialState by clicking on the link **View The Events API Docs** from the right side of the App Launcher (remember, click the sine wave to get to the App Launcher). You can also access it by clicking **support** at the top right corner of the window, selecting **Streaming > Using the Events API**, and then clicking on **documented and testable on apiary**.

The initial APIARY window looks like this:




From the left panel, click on **Event Data > Events JSON** and then click the banner **Send Events** from the center panel. Next, click the button that says **Switch to Console** on the right panel. Once you do that, you will see the following window that includes documentation on sending events (center panel) and a test console that you can use to send POST requests (right panel).






From the console, you can create and send HTTP requests. For example, to send the value "on" to a key called "switch" from the console, you would do the following:

First click on **Header** and fill in your API Key and Bucket Key. The header for Content-Type is already filled in for you and the Content-Length will be automatically calculated.



Then click on **Body** and type in the JSON document for the message.





When you press **Call Resource** it will show you the HTTP 1.1 document and the result.

```
Request

HEADERS

Content-Type:application/json
X-IS-AccessKey:aAJE60wgGbQMN**
X-IS-BucketKey:BJ69GN8WSSNN
Accept-Version:-0
content-length:38

BODY

01 [
02 {
03 "key": "switch",
04 "value": "on"
05 }
06 ]
```

If you have a Tile set up to monitor the state of the key "switch" you will see its value change to "on" once the message is received.



4b.10 Exercises

Exercise 1: Use CURL to access http://httpbin.org

or the httpbin.org certificate.

Make sure you are viewing the root certificate before you save it.

b. Put the certificate in the same folder as the CURL executable to simplify specifying the path.

The website httpbin.org is a public server HTTP debugging utility. It will let you make requests and then tell you what is happening by echoing back what you sent in JSON format. 1. Use a web browser to view http://httpbin.org From a command terminal run: CURL -v -X GET http://httpbin.org/anything If your Wi-Fi AP has a proxy server, CURL will not be able to connect (unless you specify the proxy server). Note: Note: If you are using Windows, you will have to download CURL. To use it: a. Go to https://curl.se/windows/ and download CURL. Unzip the file you downloaded and navigate to curl-version/bin/ using the file explorer. b. Shift-Right-Click in the File Explorer window and select either Open command window here or Open PowerShell window here. c. Alternately, you can open a command window (cmd) or a modus-shell and manually change directory (cd) to the location listed above. d. From the new window, run the command as: curl <other arguments> (for Command window or modus-shell) ./curl <other arguments> (for PowerShell) The leading dot and slash are required in Windows PowerShell because by default it aliases "curl" to a Note: different function that is similar to CURL but is not the same. e. If you are using PowerShell, remember to use single quotes instead of double quotes (except inside a JSON string). 3. Use CURL to do a POST to the resource /anything Use CURL to do a GET from the resource /html. Exercise 2: Use CURL to access https://httpbin.org using TLS Use a TLS connection to access httpbin.org. The steps are: 1. Use a web browser to save the certificate for https://httpbin.org. Note: The steps to do this were covered in Chapter 6B. a. You must save the root certificate to use in CURL. It will not work with the intermediate certificate

Note:



	2.	Use CURL to do a GET from https://httpbin.org/anything You will need to use thecacert option in CURL to provide the certificate file.
	3.	Look at the log file to see the TLS handshaking occurring.
Exer	cise	3: Run the AnyCloud_HTTPS_Client/Server example applications
	1.	If you are taking this course in a classroom setting, for this exercise, partner with another student in the class, one of you should run the server application while the other runs the client application. If you are taking this course on your own, you should run both of the applications. This will require two CY8CKIT-062S2-43012 kits.
	2.	Create two new applications. One using the AnyCloud_HTTPS_Server example application and the other using the template in the Wi-Fi class files under <i>Templates/ch04b_ex03_https_client</i> .
N	lote:	You can also run the AnyCloud_HTTPS_Server application by itself. In that case, you connect to it using cURL or a web browser. If you want to try this approach, see the README.md file in the AnyCloud_HTTPS_Server application. If you do that, you should still change the server name to something unique so that others don't connect to your server.
	3.	Update the Wi-Fi configuration parameters in the http_client.h and secure_http_server.h files.
	4.	If you are taking this course in a classroom setting, update the macro <code>HTTPS_SERVER_NAME</code> in <code>secure_http_server.h</code> to be something unique so that other groups don't connect to your server by mistake. You could use your initials and/or your partner's initials for this.
N	lote:	Don't forget to update the server hostname in the client's application as well (the hostname in the client application should end in ".local" because it will use mDNS to find the server's IP address).
	5.	Program both kits – one with the server and one with the client. Once they connect, press the button on the client to send the LED on/off commands.
Exer	cise	4: Use your kit to GET data from httpbin.org
•		then run a project to get data from httpbin.org using your development kit. The project will GET from the /html resource and then from the /anything resource. The steps are:
	1.	Create an application using the template in the class files under <i>Templates/ch04b_ex04_httpbin_get</i> .
	2.	Use the Library Manager to include the http-client library.
N	lote:	The Makefile has already been updated with the required COMPONENTS and DEFINES.
	3.	Update the Wi-Fi configuration parameters in http_client.h.
	4.	Search for "TODO" in http_client.c and http_client.h and implement the required functionality.
	5.	Open a serial terminal connection to your kit.
	6.	Build, program, and run the project.
	7	Observe the results in the terminal window



	8.	Which server port is used for HTTP (non-secure)?
	9.	What header(s) is/are sent with each request?
	10	. What is the variable "connected" used for? Why is it needed?
	11	. Uncomment the section of code to wait for the server to disconnect between requests. How long does the server wait before closing the connection?
Impo	ort and	e 5: Use your kit to GET data from httpbin.org using TLS I then run a project to GET data from httpbin.org using your development kit using a TLS n. The steps are:
	1.	Create an application using the template from <i>Templates/ch04b_ex05_httpbin_get_secure</i> .
	Note:	The http-library has already been included in the application and the Makefile has been updated with the required COMPONENTS and DEFINES.
	2.	Update the Wi-Fi configuration parameters.
	3.	Search for TODO in http_client.c and http_client.h and implement the required functionality.
	4.	Open a serial terminal connection to your kit.
	5.	Build, program, and run the project.
	6.	Observe the results in the terminal window.
	7.	Which server port is used for HTTPS (secure)?
П	8.	What function call and parameter specifies that the connection should use TLS?



Exercise 6: Use your kit to POST data to httpbin.org

/anything. The data you send will be echoed back to you by the server. The steps are: 1. Create an application using the template from Templates/ch04b_ex06_httpbin_post. Note: The http-library has already been included in the application and the Makefile has been updated with the required COMPONENTS and DEFINES. Update the Wi-Fi configuration parameters. Search for TODO in http_client.c and implement the required functionality. Use a short JSON message as the body of the message. For example, you could use the key/value pair {"any cloud":"yes"}. 4. Open a serial terminal connection to your kit. Build, program, and run the project. Observe the results. What headers are sent with the POST request? What is the JSON content that is posted? Exercise 7: Use your kit to POST data to httpbin.org using TLS Import and then run a project to POST data to httpbin.org using your development kit using a TLS connection. The steps are: Create an application using the template from *Templates/ch04b_ex07_httpbin_post_secure*. Note: The http-library has already been included in the application and the Makefile has been updated with the required COMPONENTS and DEFINES. 2. Update the Wi-Fi configuration parameters. Search for TODO in *http_client.c* and implement the required functionality. Use a short JSON message as the body of the message. For example, you could use the key/value pair {"any cloud":"yes"}. 4. Open a serial terminal connection to your kit. Build, program, and run the project. Observe the results.

Import and then run a project to POST JSON data to httpbin.org using your development kit. The resource is



Exercise 8: Use a web API for getting weather conditions

Create a project that will call weatherstack.com's Web API to request the current weather in various cities, then display it on the TFT display. You will need to set up a free account with weatherstack.com in order to obtain an API key. The documentation for weatherstack's Web API is available here: https://weatherstack.com/documentation

The	opti	ions	s required are:
acc	ess_l	key	= <your api="" key=""></your>
que	ry=<	Nar	me of the city to get weather conditions for>
]	1.	Go to https://weatherstack.com , click on SIGN UP FREE in the top right corner, then create a free account in order to get an API key. Your API key will be available from the dashboard of your account: https://weatherstack.com/dashboard
]	2.	Clone the repo https://github.com/markgsaunders/weatherstackAPI . This project is already capable of querying weatherstack.com for the weather conditions in various cities and displaying them to the TFT display. Your job is to update it to use the http-client library rather than the secure-sockets library.
			Note how the HTTP communication is just text based and requests can be created simply by writing text strings – there is nothing fancy about the request/response.
	Note	e:	To get the display working you will have to add a call to cy8ckit_028_tft_init in capsense.c
Ex	erci	ise	9: Initial State – Virtual LED controlled using APIARY and CURL
		1.	Go to www.initialstate.com and sign up for an individual trial account.
		2.	Create a new Bucket called "TestBucket". See the section earlier on Initial State for detailed instructions.
		3.	Use the APIARY interface to write ON and OFF to the LED and see that the state changes in the Tile.
	Note	e:	You will need to enter the AccessKey and BucketKey for you bucket either as headers or as URL Parameters. Placeholder headers are provided with default values. You can find the values for your bucket by going to the bucket settings on the shelf.
	Not	e:	The body should be a JSON document that sends "key":"LED_State" with "value":"ON" or "value":"OFF"
	Note	e:	The first time you write to a key from APIARY, it will create a summary tile for you automatically, so you won't need to create it manually.
		4.	What status code is returned when you send the message? Look up the code to see what it means.
]	5.	Use CURL to send HTTP POST messages to turn ON and OFF the virtual LED. Verify that it changes in the Tile.



Exercise 10: Initial State - LED state controlled by hardware

Create a project to turn on and off the virtual LED on Initial State when a button on your kit is pressed. 1. Start with the project that sends data to httpbin.org. You will need to get the certificate for initial state.com or one of its CAs from a web browser and include it in the firmware. Use one of the three methods discussed in the TCP/IP Sockets chapter. Don't forget to escape the quotes inside the JSON message with backslashes (\"). Note: Note: Since the server can disconnect at any time, you should keep track of the connection state. You can set a bool inside the disconnection callback so that you know if you need to reconnect. **Exercise 11: Initial State - Potentiometer position** Create an application to write the value of the potentiometer to Initial State each time you press the button. Modify the project you created in exercise 10 to send the position of the potentiometer on your kit in degrees every time the button is pressed rather than sending the LED state. Note: Refer to the ModusToolbox $^{\text{\tiny{M}}}$ -Level2-PSoC $^{\text{\tiny{M}}}$ class for help reading the state of the potentiometer. **Exercise 12: Initial State - Graphing potentiometer position** Create an application that polls the position of the potentiometer. 1. The poll should occur once every second. Send data to initial state each time the position changes by 1 degree or more. Display the data on a graph on Initial State. Related example "apps" 4b.11

App Name	Function	
AnyCloud_HTTPS_Client	ModusToolbox™ any cloud HTTP client example application	
AnyCloud_HTTPS_Server	ModusToolbox™ any cloud HTTP server example application	

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Published by Infineon Technologies AG 81726 Munich, Germany

© 2021 Infineon Technologies AG. All Rights Reserved.

IMPORTANT NOTICE

The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics ("Beschaffenheitsgarantie").

With respect to any examples, hints or any typical values stated herein and/or any information regarding the application of the product, Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights of any third party.

In addition, any information given in this document is subject to customer's compliance with its obligations stated in this document and any applicable legal requirements, norms and standards concerning customer's products and any use of the product of Infineon Technologies in customer's applications.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

For further information on the product, technology, delivery terms and conditions and prices please contact your nearest Infineon Technologies office (www.infineon.com).

WARNINGS

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.