
PCG 6500 programming chart



Data: - Left edge of character is MSB ADR: - ARD=8*(petscii code-64)+line where 64 <= petscii code <= 127 0 <= line <= 7

