


E-Maintenance V7


Analyst Workflow



Equipment(s)




Choose Asset(s)




Asset(s)

Click "Upload File" to upload Asset images (Optional)



Click "Report Data" to feed report for the asset

Report Data




Key Points in Report Data:

- 1. For Asset Condition Code **0** and **1**, **Observations field is mandatory**.
- 2. For Asset Condition Code between 2 5, Recommendation and Observations field is mandatory.
- 3. Potential Failure Mode, Potential Failure Cause and Symptoms are Mandatory if Condition Code selected is between 2-5.
- 4. When QC is failed, an alert message will be displayed. In that case, you can hover over the alert message displayed on top of the screen to know what is the error.
- 5. Work Notification is based on Condition Code 2-5 and Priorities (Immediate Action, Repair at convenience).


Equipment Status

Save Equipment Status for Review



Leverage Service

Choose required Leverage Service for the Equipment and save



Job Status

