S72 TWS Earbuds

User Manual

Please read it carefully before use

Specifications:

BT Version:	V5.4
Frequency:	2.402~2.480 Ghz
BT Range:	33 feet without obstacle
Support Profile:	HSP/HFP/A2DP/AVRCP
Earbud Battery:	3.7V 40mAh
Charging Case Battery:	3.7V 400mAh
Microphone:	Si, -42dB±3dB
Speaker:	φ13mm, 32Ω, 3mW
Charging Input Current:	DC 5V 1A
Charging port:	Type-C
Type-C port Charge Time:	About 2.5 hours
Earbud Work Time per Charge(at 70% volume):	About 6 hours

Package Include:

Power On: When the earbuds are in the case, open the case to power on.
Power Off/Earbuds Charging: When the case has power, put the earbuds into the case and close it, the earbuds will power off and start charging automatically.
Auto Power Off: The earbuds will power off automatically if not paired in 3 minutes.

Earbuds battery low reminder: There will be an audio prompt every 1 minute.
Case battery low reminder: The case battery display will show 0 or not light up after you open the case.

Case charging: Use provided Type-C cable to charge the case with DC5V power adapter only. (Do not use power supply higher than 5V, it may damage the product thus can't be charged.)

Note: Please maintain a charge at least every 3 months, if the product will not be in use for a long time, to keep the battery active and prolong the life.

Diagram & Button Operations:



Earbud Indicator:

Waiting for pairing: Flash red and blue
Paired: Flash blue
Charging: Stay red
Charging finished: Go off

MFB:

Play/Pause music/Answer/Hang up phone calls: Touch 2 times
Reject phone calls: Touch and hold for about 2 seconds
Previous Track: Touch and hold L earbud for about 2 seconds
Next Track: Touch and hold R earbud for about 2 seconds
Volume Down: Touch L earbud 1 time
Volume Up: Touch R earbud 1 time
Activate phone voice control: Touch 3 times
Power on: Touch and hold for 3 seconds(When the earbuds are outside of the case, and in power off state.)
Power off: Touch and hold for 5 seconds(When the earbuds are outside of the case, and BT not paired by any devices.)

Digital Display:

Show case battery level: When the case has power, open/close the case, it will display 10 seconds and then go off.
Show earbuds charging: The L & R bar will flash.
Show case charging status: The number flash from 1 to 100 when charging, stay 100 after finished charging.

Type-C charging Port:

Use DC 5V power adapter only. (Do not use power supply higher than 5V.)

Pairing:

1. Earbuds Pairing: Open the case, the L & R earbuds will enter pairing mode and pair

One earbud indicator flash blue, while another one flash red and blue means L & R are paired.

2. Earbuds Pair with Phone: Turn on the of your phone, search for "S72" and pair.



The earbuds indicator both flash blue every 5 seconds means they are paired with phone.(Indicator will not flash when playing music.)
Auto-Pair: The earbuds will auto pair the last paired phone when power on next time. (Turn on the BT of your phone first, and then power on the earbuds.)

3. Open your phone music player and hit play, now you can enjoy music wirelessly, as well as answer handsfree calls.

FAQ:

Q1: The product can't pair with my phone.
1. Please turn off the BT of other devices, make sure the earbuds are in pairing mode.
2. Clear the pairing history of your phone. Turn off the BT then turn on, and try again.

Q2: The BT range or the sound quality is not good.
1. BT signal can be blocked by surrounding objects thus affect the audio quality, if no obstacle between the product and your phone, the range and sound quality will be better.
2. Keep away from other BT devices, microwaves, wireless routers, and other electronics.

Q3: Why there is a delay?
There is a data transmission process from your phone to the product, so sometimes you can feel delay. It's a common issue for all the BT devices, and BT V5.4 already made it better than the old versions.

Q4: Why the case can't charge the earbuds, or the earbuds won't power off after put back in case?
1. If the case has no power, then above issues happen, please charge the case, and it will turn normal after the case has power.
2. If the earbuds come with charging insulation sticker on the metal contacts, please make sure you removed them before charge.

Q5: Why people can't hear me in the call?
Please make sure you wear 2 earbuds when making calls, and check if there is any dirt blocked the microphone.

Q6: Only 1 earbud pair with my phone.
You need to let the L & R earbuds pair first, and then turn on phone to pair with the earbuds. One earbud indicator flash blue, while another one flash red and blue means L & R are paired.

Q7: The voice is low.
1. Please make sure you have tune your phone volume to max level.
2. Choose the ear caps size that suit your ears best, and make sure the earbuds fit well into your ear.

FCC Compliance Statement:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

CORRECT DISPOSAL OF THIS PRODUCT

(Waste Electrical & Electronic Equipment)

This making shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.