

1. Basic Network & Power Check

Same Wi-Fi Network: Ensure the iPad 4 and printer are connected to the exact same Wi-Fi network name (SSID).

Restart All Devices: Turn off your router, printer, and iPad 4. Power them back on in this order: Router, Printer, then iPad.

Printer Status: Ensure the printer is not in sleep mode, is not showing error lights (low ink/jam), and is connected to Wi-Fi.

2. Printer-Specific Adjustments

Enable AirPrint: Access your printer's settings (usually via its screen or IP address in a web browser) to confirm AirPrint is enabled.

Static IP Address: If the connection is intermittent, assign a static IP address to the printer via your router settings.

Firmware Update: Check if your printer manufacturer (HP, Epson, Canon) has a firmware update, as older printers might need updates to communicate with Apple devices.

3. iPad 4 Troubleshooting

Toggle Wi-Fi: Turn the Wi-Fi off and on again on the iPad.

Reset Network Settings: Go to Settings > General > Reset > Reset Network Settings. *Note: This will erase saved Wi-Fi passwords.*

Disable VPN: If you have any VPN or security apps installed, turn them off, as they can block AirPrint.

4. Alternatives if AirPrint Fails

Since the iPad 4 is older, it may struggle with modern network protocols.

Use Printer Manufacturer App: Download the specific app for your printer (e.g., HP Smart, Epson iPrint) from the App Store.

Printer Email Service: Many printers (HP ePrint, etc.) allow you to email a document to a specific email address assigned to your printer.

Wi-Fi Direct: If your printer supports it, connect your iPad directly to the printer's own Wi-Fi network (bypassing your home router).

5. Proper Restart Sequence (If still not working)

Turn off the WiFi Router.

Turn off the Printer.

Force restart the iPad (Hold Home and Power buttons until the Apple logo appears).

Turn on the Router and wait for it to fully connect to the internet.

Turn on the Printer.

Turn on the iPad and try to print.