recreational aerobatics:

Uncoordinated Flight

By Rich Stowell, MCFI-A

"You know the nearer your destination, the more you're slip slidin' away!" -Paul Simon



In the December 2006 issue of Sport Aerobatics, Rich Stowell provided an excellent article titled **Putting It Together**. That article reminded us that, as certificated pilots, we are already flying sequences. He wrote, "The ability to string together a series of individual maneuvers into a well-executed sequence surely represents one of the ultimate expressions of piloting skill. Of course, "flying sequences" is a familiar concept to air show and competition pilots. But all pilots-aerobatic or not-are taught a number of useful sequences during flight training. For example, not only is the traffic pattern among the earliest sequences pilots learn, it is also the most common sequence we fly."

This month, Rich helps us understand that controlled uncoordinated flight requires the same skill and finesse as coordinated flight. Once again, we'll learn that taking the skills we already have and applying them in new ways makes us become better and safer pilots.

new year than by practicing some intentional uncoordito distinguish between coordinated flight and coordinated inputs first. Coordinated *flight* occurs whenever we proactively cancel the adverse yaw effects associated with power (engine/propeller effects), aileron inputs, and airplane rigging. Otherwise, we would experience uncoordinated flight, which is what we'll explore in this article. Note that this is different from coordinated inputs, which simply means that our control movements are applied in concert. For instance, we coordinate aileron and rudder inputs when rolling into a coordinated turn. We should likewise coordinate aileron and rudder inputs when establishing a slip. In the former case, we remain in coordinated flight throughout; in the latter case, we intentionally cross-control our inputs for uncoordinated flight.

Uncoordinated flight comes in two basic flavors: skid and slip. For our purposes, skidding occurs when the deflected rudder points earthward. Slipping occurs when the airplane is stabilized in cross-controlled flight with the deflected rudder pointing skyward.

Skidding, as loosely defined above, has very limited utility. We normally avoid skidding at all costs, especially when in the traffic pattern. However, we can use an intentional skid to accomplish two specific maneuvers: an aggravated stall/spin entry from turning flight, and the pivot at the top of a hammerhead. Intentional spins will be discussed in the next installment of "Recreational Aerobatics." Suffice it to say that, unless you intend either to spin or to hammerhead, don't ever point the rudder toward the ground in uncoordinated flight!

Compared to skidding, slipping offers a variety of practical and beneficial uses. For example, we can slip to:

- Lose excess altitude on final approach
- Improve forward visibility in blind airplanes, such as the Pitts, Great Lakes, and Stearman
- Cancel crosswind effects during landing

- should we encounter a jammed aileron or rudder control
- metric thrust scenario in a twinengine airplane

rest of this article. However, a few words of caution before we go any further: The layout of fuel systems in some airplanes can result in fuel starvation during prolonged slips, especially in low-wing aircraft feeding from in a slipping stall. The Bonanza sudwing tanks. The A36 Bonanza, for example, places a 20- to 30-second time limit on continuous slipping; in some instances, slips in the RV series can fuel-starve the engine in a matter of just a few seconds. Please consult cockpit placards and your airplane flight manual for warnings about slips before attempting the exercises described below.

Stalls During Slips

How an airplane behaves in a slipping stall depends on several factors. For the power-off, no-flaps slip configuration, three reactions are possible. First, a Decathlon will retain its rudder and aileron authority during the slipping stall. Thus, it's possible to remain on your track in the slip as the Decathlon gently bobs into and out of stall buffet, albeit descending rapidly.

The Cessna 150, on the other hand, loses its rudder authority; consequently, the 150 begins a slipping spiral toward the low wing, bobbing in and out of stall buffet along the our slips. We'll also leave the throttle way. Even though you cannot keep the Cessna 150 on its original track, the opposite rudder remains suf-

hat better way to ring in the • Regain command of the airplane ficiently effective to prevent spin entry. In fact, you can perform a 360-degree stalled slipping spiral nated flight? Let's take a moment • Counteract a split flap or an asymif you're so inclined. Airspeed will remain low and constant throughout the high-drag turning descent.

> Potentially the most dangerous We'll focus on slipping in the stall behavior in a slip typically occurs in low-wing airplanes (and some high-wing airplanes with rather poor roll authority, such as the J-3 Cub). The A36 Bonanza, for example, loses its aileron authority denly and automatically rolls toward wings-level flight, i.e., toward the deflected rudder. If allowed to proceed, the airplane will transition from a slip into a skid. All the ingredients necessary for an over-the-top spin entry are present if we don't respond appropriately: stalled flight plus yaw and roll coupling.

> > Yet regardless of the airplane or how it reacts to a slipping stall, we still need to deal with stalled flight in the usual manner: break the stall with forward elevator. Reattach the airflow first; then release the slip inputs.

Straight Slips

Let's practice slipping along a straight line. At altitude, configure the airplane as if you were on downwind for landing (no flaps). Take a moment to memorize your pitch attitude. Since the airspeed indicator is inaccurate in a slip, our objective will be to keep the pitch attitude constant as we move into and out of set as is. This way, we won't have to climb quite as often between slips. Select a nice section line to follow,

Unless you intend either to spin or to hammerhead, don't ever point the rudder toward the ground in uncoordinated flight!

复Herobatics JANUARY 2007

or a distant point over the nose as an outside visual reference.

slowly yawing the nose to the right aileron you can apply even though of the reference line you want to track. Simultaneously apply sufficient left aileron to roll the left wing tip below the horizon. Establish a comfortable slip angle, and do whatever is needed with the elevator to hold a constant pitch attitude. The maximum amount of slip possible is usually determined by the amount of rudder available. A full-rudder slip in a typical nose-wheel Cessna, for example, results in a relatively small amount of slip compared to a fullrudder slip in a Citabria. Depending on the airplane, your "comfortable" slip could range from full rudder in the Cessna to only half of the rudder in the Citabria to perhaps only one-third or less of it in a high-performance aerobatic airplane.

When pilots enter slips, they often instinctively shift their bodies away from the bank angle in order to remain vertically upright to the horizon. This will throw you off of the roll-yaw-pitch axes of the airplane. Glance at the slip/skid ball. Listen

Furthermore, leaning away from the bank will effectively shorten your Begin the slip by smoothly and arm's throw, limiting the amount of more aileron deflection may be available. Once you've set your slip, make sure your upper body is relaxed, with your head and spine aligned with the airplane, not the horizon. Here's a tip: If you release all tension from your upper body, gravity will pull you into the correct position.

Do you have good slip posture? Okay, now check your track: The line you're slipping along extends from your chest to a point on the horizon. The nose of the airplane should be to the right of that line; the left wingtip, down and to the left of the line. Feel free to vary your rudder pressure to see how the nose moves as a result of too much and too little rudder for the particular slip angle. Similarly alternate aileron pressure from too much to too little. Readjust your slip inputs to track the line once again.

Now sight down the left wing and notice that the left aileron is sticking up, yet the airplane is not rolling.

to the sound of the airflow in the slip. Return to coordinated flight by smoothly yawing the nose back to your reference line while simultaneously rolling the wings to level. The nose will usually want to drop as well, so take care to keep the pitch attitude constant as you remove the slip inputs.

Next, move into a slip with left rudder and right aileron, performing the same coordinated actions and paying attention to the same details as before. Check your posture and your track. Remove the slip. Alternate your slips in this fashion until you can move smoothly into and out of them while consistently tracking your reference line. Then try transitioning the slip from one side all the way across to the other side. Make smooth, slow, and controlled inputs at first. Stay on track, keep the pitch attitude constant, and make your body move with the airplane.

In all likelihood, you'll descend during these slips. Don't try to compensate for the altitude loss; focus instead on your inputs, your track, and your posture.

Slipping Turns

Not only can we track a straight line in a slip, but we can also perform slipping turns. Try the following at altitude: Configure the airplane for slow-cruise. Note the pitch attitude relative to the horizon, which should be lower than the slow-flight pitch attitude used during your straight slips. Keeping this new pitch attitude constant, smoothly transition into a straight slip using left aileron and right rudder.

Let's now keep the rudder position constant. We'll vary only aileron and elevator for a left slipping turn. Smoothly increase the bank angle another 10 degrees or so. Next, smoothly apply a small amount of aft elevator. Allow the airplane to turn, and don't change the rudder! The slipping turn rate will seem quite a bit slower than a comparable coordinated turn. Also notice that the nose of the airplane appears to be lagging - to be following you - in the turn; thus, you should be looking ahead of the nose in the direction you're turning. Acknowledge the heaviness

When pilots enter slips, they often instinctively shift their bodies away from the bank angle in order to remain vertically upright to the horizon.



Hooker Custom Harness

324 E. Stephenson St. Freeport, Illinois 61032 Phone: (815) 233-5478 FAX: (815) 233-5479 E-Mail: info@hookerharness.com www.hookerharness.com

— Dealer for Strong Parachutes —



Intentional and controlled uncoordinated flight requires coordinated control inputs and practice. Photo courtesy of Rich Stowell.



JANUARY 2007



Mastering uncoordinated flight will improve forward visibility in blind airplanes such as the Pitts. Robert Bismuth.

Check your body posture. Lean into left of center.

of inputs applied to initiate the slipping turn. First, release the additional back elevator. Second, reduce the added bank angle. You should now be in a straight slip, tracking a **Controlled Yaw Exercises** straight line.

in aileron and elevator pressures. From that standpoint, think pressure changes rather than measurable movements of the controls. Also, and at the end of each slipping turn: level at all times. aileron followed by elevator to start; elevator followed by aileron to stop.

resuming the slipping turn. Do the the nose parallel to the horizon and

also experiment with holding the the turn, not away from it. Glance ailerons constant and modulating at the slip/skid ball which is resting only rudder and elevator pressures. In this case, release a small amount Let's now transition back to our of rudder pressure followed by a bit straight slip by reversing the order of aft elevator pressure to start the slipping turn. Release the aft elevator pressure and reapply rudder pressure to straighten the slip.

Okay, we're ready to play around You'll find that the difference with moving the nose of our airbetween the straight slip and the plane to scribe various shapes in the slipping turn is a subtle difference sky. Let's create our shapes as follows: We'll draw horizontal and vertical lines only (for now), we'll keep the corners between horizontals and verticals square (no rounding off!), make two separate inputs at the start and we'll keep the wings perfectly

Draw a box. Start in level, slowcruise flight. From here on, leave the Try a four-point, 360-degree slip- throttle alone. Pull the nose up along ping turn to the left, briefly transia a straight line 15 to 20 degrees above tioning to a straight slip every 90 the horizon. Pause there for a secdegrees of heading change before ond. Now yaw the nose left, keeping

you feel in the left side of your butt. same to the right as well. You can the wings level. Pause. Now push the nose down along a straight line 15 to 20 degrees below the horizon. Pause. Yaw the nose right, parallel to the horizon, wings-level, back over to the starting heading. Pause. Return to the slow-cruise flight attitude. Do the same thing to the right. Keeping the wings level and your lines perfectly horizontal and vertical will require continuous adjustments as speed, control authority, engine effects, and gyroscopic precession vary and interact.

> Once you're comfortable with that, spell out "CATS" in big block letters. Then "DOGS." Etch the numbers zero through nine and the various letters of the alphabet. Spell out your name. When you're proficient with block figures, try scribing a few wings-level, 45-degree lines with the nose. And when you get really good, cursive skywriting awaits you!

> Don't worry about holding a constant altitude during any of the slip exercises. Plan on starting high enough to compensate for the attendant altitude loss, and regain altitude

between maneuvers. Be vigilant for other traffic, too. And as mentioned in the previous installment on sequences, abort the exercises if either altitude or stalling becomes an issue.

Rich Stowell is a NAFI Master Instructor-Aerobatics. His much-anticipated new book, The Light Airplane Pilot's Guide to Stall/Spin Awareness, hits bookshelves in February. For more information, visit www.RichStowell.com.

Editor's Note: In 2007, Sport Aerobatics will continue to provide how-to articles designed to increase the safety, skill, and knowledge of our recreational and competitive members. Please let me know what topics vou would like to read about in upcoming issues. Do you have a maneuver that remains a mystery? What about emergency procedures? How are those "forward blind" landings working out? Please send your suggestions to me at tookyflyer@tds. net. This is an opportunity to fly with the very best aerobatic flight instructors without worrying about the price of avgas!

... you'll descend during these slips. Don't try to compensate for the altitude loss: focus instead on your inputs, your track, and your posture.



Merobatics 11

10 JANUARY 2007