

Wiring Diagram

Wiring diagram for the ENV-TMP Field Ready Temperature Sensor

When connecting the ENV-TMP to an arduino using the supplied sample code; make sure to connect VCC to Pin 2 and the analog lead to Pin A0

