

Chapter 32 - IE Mon

IE Mon is the interactive monitor built into Intuition Engine. It runs in the same terminal as BASIC and gives you direct access to the bus, the active CPU's registers, breakpoints, watchpoints, a disassembler, a byte memory editor, a reverse-execution timeline, save and restore of memory ranges, and a small handful of more specialised tools.

You enter the monitor from BASIC by typing `MON` at the prompt and leave it by typing `x`. Inside the monitor, each line is a command followed by space-separated arguments. Numeric arguments default to hexadecimal; prefix them with `#` for decimal.

32.1 General conventions

Convention	Example	Meaning
Address	1000	Hexadecimal \$1000
Address	#4096	Decimal
Address pair	1000 10FF	Inclusive range
Register	r0, pc, a	Active CPU's register
Hex byte literal	7E	Hex byte for write/fill

The monitor's prompt is the active CPU's short name followed by a greater-than sign: (`ie64`)>, (`6502`)>, (`z80`)>, etc.

32.2 Execution control

Command	Argument(s)	Effect
<code>g</code>	[<code>addr</code>]	Resume execution from current PC or <code>addr</code>
<code>s</code>	[<code>count</code>]	Step: execute one instruction (or <code>count</code>)
<code>u</code>	<code>addr</code>	Run until: resume, stop one-shot at <code>addr</code>
<code>x</code>		Exit the monitor (return to BASIC)

`s` always re-prints the registers after the step. `g` returns to the monitor on the next breakpoint, watchpoint, or `Ctrl-C`.

32.3 Registers and disassembly

Command	Argument(s)	Effect
<code>r</code>	[<code>reg</code>] [<code>value</code>]	Show all registers, or set one register
<code>d</code>	[<code>addr</code>] [<code>count</code>]	Disassemble at <code>addr</code>
<code>list</code>	[<code>addr</code>] [<code>count</code>]	List annotated lines when line data is loaded
<code>cpu</code>	[<code>name</code>]	Show the active CPU or switch to <code>name</code>

The argument to `cpu` is `ie64`, `ie32`, `6502`, `z80`, `m68k`, or `x86`.

32.4 Memory inspection and editing

Command	Argument(s)	Effect
m	addr [count]	Memory dump in hex + ASCII
w	addr byte [byte...]	Write bytes at addr
e	addr	Enter interactive hex editor mode
f	start end byte	Fill a range with one byte
h	start end pattern...	Hunt: search a range for a byte pattern
c	start end dest	Compare a range against dest
t	start end dest	Transfer a range to dest

w is a one-line byte writer. Use e addr when you want interactive byte editing. Byte arguments should be 00 to FF; larger values are stored as their low byte.

There is no mnemonic-entry command. To enter machine code, write the bytes with w and confirm them with d.

32.4.1 Byte-entry audio workflow

This is the standard machine-language programming loop in IE Mon:

```
(6502)> w 1000 A9 01 8D 00 F8 A9 00 8D 08 D2 A9 79 8D 00 D2 A9
(6502)> w 1010 AF 8D 01 D2 4C 14 10
(6502)> d 1000 9
 1000: A9 01          LDA #$01
 1002: 8D 00 F8        STA $F800
 1005: A9 00          LDA #$00
 1007: 8D 08 D2        STA $D208
 100A: A9 79          LDA #$79
 100C: 8D 00 D2        STA $D200
 100F: A9 AF          LDA #$AF
 1011: 8D 01 D2        STA $D201
T 1014: 4C 14 10      JMP $1014
(6502)> r pc 1000
(6502)> b 1014
(6502)> g
(6502)> m D200 2
D200: 79 AF 00 00 00 00 00 00 00 00 C0 00 00 00 00 00  y.....
D210: 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  .....
(6502)> bc 1014
```

The leading prefix in each disassembly line tells you what the monitor thinks about that address: two spaces for an ordinary instruction, T for a branch target that another line in the window references (the self-loop at \$1014 here), > for the current PC, and * for an active breakpoint. The d count argument is parsed as hexadecimal by default (so d 1000 9 gives nine lines and d 1000 10 would give sixteen); prefix the count with # for decimal. The m count argument is decimal by default and counts *rows of sixteen bytes*, not bytes. m D200 2 shows two sixteen-byte rows starting at \$D200, and the values written by the program appear in the first few columns of the first row.

The w line enters bytes. The d line proves those bytes decode as the intended instructions. The breakpoint stops execution before the final self-loop, and the memory dump proves the POKEY frequency and control bytes were written. You should

hear the tone while the audio engine is enabled. If the disassembly does not match the chapter transcript, fix the byte listing before running it.

32.4.2 Byte-entry graphics workflow

The same loop works for visible hardware. This 6502 example uses the ULA card: it sets the border, enables the ULA source, writes an 8-byte bitmap motif through the ULA latch/data port, writes one attribute byte, and then loops. It is deliberately small, but it does more than poke a colour register: it teaches the latched VRAM entry path used by larger ULA programs.

```
(6502)> w 1100 A9 05 8D 00 D8 A9 05 8D 04 D8 A9 00 8D 0C D8 A9
(6502)> w 1110 00 8D 10 D8 A9 FF 8D 14 D8 A9 81 8D 14 D8 A9 BD
(6502)> w 1120 8D 14 D8 A9 A5 8D 14 D8 A9 A5 8D 14 D8 A9 BD 8D
(6502)> w 1130 14 D8 A9 81 8D 14 D8 A9 FF 8D 14 D8 A9 00 8D 0C
(6502)> w 1140 D8 A9 18 8D 10 D8 A9 46 8D 14 D8 4C 4B 11
(6502)> d 1100 #31
1100: A9 05          LDA #$05
1102: 8D 00 D8       STA $D800
1105: A9 05          LDA #$05
1107: 8D 04 D8       STA $D804
110A: A9 00          LDA #$00
110C: 8D 0C D8       STA $D80C
110F: A9 00          LDA #$00
1111: 8D 10 D8       STA $D810
1114: A9 FF          LDA #$FF
1116: 8D 14 D8       STA $D814
1119: A9 81          LDA #$81
111B: 8D 14 D8       STA $D814
111E: A9 BD          LDA #$BD
1120: 8D 14 D8       STA $D814
1123: A9 A5          LDA #$A5
1125: 8D 14 D8       STA $D814
1128: A9 A5          LDA #$A5
112A: 8D 14 D8       STA $D814
112D: A9 BD          LDA #$BD
112F: 8D 14 D8       STA $D814
1132: A9 81          LDA #$81
1134: 8D 14 D8       STA $D814
1137: A9 FF          LDA #$FF
1139: 8D 14 D8       STA $D814
113C: A9 00          LDA #$00
113E: 8D 0C D8       STA $D80C
1141: A9 18          LDA #$18
1143: 8D 10 D8       STA $D810
1146: A9 46          LDA #$46
1148: 8D 14 D8       STA $D814
T 114B: 4C 4B 11     JMP $114B
(6502)> r pc 1100
(6502)> b 114B
(6502)> g
(6502)> m D800 1
D800: 05 00 00 00 05 00 00 00 01 00 00 00 02 00 00 00 .....
(6502)> bc 114B
```

The writes to \$D80C and \$D810 set the low and high halves of the ULA VRAM address latch. Each store to \$D814 writes one byte at the latched address and advances the latch. The first eight data bytes form the bitmap motif. The later latch

value \$1800 selects the attribute area, and \$46 gives the cell yellow ink on black paper. The d count of #31 is decimal (the # prefix forces decimal. Without it the count is parsed as hexadecimal, which is the default for d); the single m D800 1 shows the sixteen-byte row that starts at \$D800 so the writes to \$D800 (05) and \$D804 (05) appear in the first row. The \$D814 register is a write-only auto-incrementing latch port; reading it does not step through the bitmap data the program wrote, so the verification is the visible stripe on the ULA display, not a follow-on m D814 read. Try changing the first \$A5 byte to \$99; the middle of the motif changes without moving the attribute cell.

32.5 Breakpoints

Command	Argument(s)	Effect
b	addr	Set a code breakpoint at addr
bc	[addr id]	Clear a breakpoint by address or by ID
bl		List all breakpoints
bfirst		Break on the first hit only (set policy flag)

Breakpoints are sticky: setting one a second time at the same address increments a hit-counter rather than creating a duplicate.

32.6 Watchpoints (memory)

The monitor distinguishes between **byte**, **word**, **dword**, and **qword** watchpoints, and between **read**, **write**, and **read/write** flavours. The mnemonic encoding is:

bpm <size> <mode> where size = b/w/d/q and mode = r/w/(both)

Command	Effect
ww addr	Word watchpoint, read/write (legacy alias)
wr addr	Word watchpoint, read only
wrw addr	Word watchpoint, read only (verbose alias)
bpmb r addr	Byte read
bpmw w addr	Byte write
bpm r w addr	Byte read/write
bpmw r addr	Word read
bpmw w addr	Word write
bpmw r w addr	Word read/write
bpm d r addr	Dword read
bpm d w addr	Dword write
bpm d r w addr	Dword read/write
bpm q r addr	Qword read
bpm q w addr	Qword write

Command	Effect
bpmq addr	Qword read/write
wc [addr id]	Clear a watchpoint
wl	List all watchpoints

These are memory watchpoints: they do not write anything. The similar-looking ww/wr are the abbreviations sometimes confused with byte writers - they are not.

32.7 Reverse execution

The monitor records a per-instruction history of the active CPU's state. You can rewind, replay forward, and search the timeline.

Command	Argument(s)	Effect
bs	[count]	Back-step: undo one (or count) instructions
rs	[count]	Same as bs
rg		Reverse-continue: rewind until the previous breakpoint or watchpoint
rt	addr	Reverse-run-until: rewind until PC was addr
tl		Timeline: dump the recent history
history		Same as tl

Be careful: rg is **reverse-continue**, not "register inspect".

32.8 Tracing

Command	Argument(s)	Effect
trace	on off name	Enable or disable instruction trace
tracering	[size]	Enable a ring-buffer trace of recent instructions
show		Dump the ring trace

trace is the named trace command. It is distinct from t (which is **transfer memory**, not trace).

32.9 CPU freeze and thaw

These commands stop and resume execution of a specific CPU without exiting the monitor.

Command	Argument(s)	Effect
freeze	cpuName *	Freeze one CPU, or * for all
thaw	cpuName *	Thaw one CPU, or * for all
fa		Freeze audio (mixer + all engines)
ta		Thaw audio

fa and ta are **audio-only** controls, not freeze-all aliases. To freeze every CPU at once, use freeze *.

32.10 Save and restore

Command	Argument(s)	Effect
save	start end name	Save a memory range
load	name addr	Load a memory range at <code>addr</code>
ss	name	Save full machine state
sl	name	Load full machine state

save and load move memory ranges. ss and sl move the whole CPU + bus + device state. A saved state can be reloaded into a freshly reset system to resume from the same point.

32.11 Symbols, addresses, maps

Command	Argument(s)	Effect
sym	[name addr]	Look up a symbol or address
map		Show the active loaded symbol map
addr	addr	Resolve <code>addr</code> to a symbol if any

32.12 Bus, MMIO, page-level access

Command	Argument(s)	Effect
io	[device addr]	Show MMIO region map or a specific page
pg	add start end mode	Page guard: trap on access to a range
pg	list clear	List or clear page guards
accesslog	on off show [count]	Control per-page access logging
who	read wrote fetched addr	Report the last matching access

32.13 Backtrace

Command	Argument(s)	Effect
bt		Stack backtrace from the active CPU

32.14 Command Results and Limits

Commands that cannot parse an address, register, CPU name, or byte value print an error line and leave the monitor active. d, m, r, io, bt, tl, wl, and bl inspect state. w, f, t, load, sl, register writes through r, and execution commands can change state.

d disassembles bytes; it never changes the program counter. g leaves the monitor until a breakpoint, watchpoint, manual break-in, or CPU stop brings control back. The reverse timeline is a recent-history tool, not permanent storage; use ss when you need a reloadable state.

32.15 Quick Reference Card

The single-letter and short commands you will use most:

r	show registers	bt	backtrace
d [a]	disassemble	s [n]	step
m [a]	memory dump	g [a]	go
w a b...	write bytes	u a	run until
b a	breakpoint set	bs [n]	back-step
bc [a id]	breakpoint clear	rg	reverse-continue
bl	breakpoint list	rt a	reverse-run-until
ww/wr a	word watchpoint	tl	timeline
wc [a id]	watchpoint clear	x	exit
wl	watchpoint list	cpu n	switch CPU
freeze *	freeze all CPUs	thaw *	thaw all
fa / ta	freeze / thaw audio	save a b n	save range
ss / sl n	save / load full state	load n a	load range at a

32.16 What Comes Next

Chapter 33 covers IE Script, a command language that drives the monitor from stored command text rather than from a terminal. IE Script is what you use to automate session setup, breakpoint actions, data dumps after a fault, and similar batch debugging tasks.