

Industry Guides

Oil and Gas Field Operations Standard Procedures Guide

February 15, 2026 • 10 min read

KEY TAKEAWAYS

- ✓ Build oil and gas field operations SOPs covering well control, H2S safety, environmental protection, equipment maintenance, and emergency response.
- ✓ Why Oil and Gas Operations Need SOPs: The oil and gas industry is regulated by a complex web of federal, state, and local agencies.
- ✓ Key Procedures Every Oil and Gas Operation Needs: Well control procedures are the most critical SOPs in drilling and workover operations.

Introduction

The [oil and gas industry](#) operates in some of the most challenging and hazardous environments on earth. From deepwater drilling platforms to remote onshore well sites, field operations involve high pressures, toxic gases, flammable hydrocarbons, heavy equipment, and extreme weather conditions. The consequences of procedural failures are measured in lives lost, environmental devastation, and billions of dollars in damages.

The Deepwater Horizon disaster of 2010, which killed 11 workers and released an estimated 4.9 million barrels of oil into the Gulf of Mexico, was fundamentally a failure of procedures. The investigation by the National Commission on the BP Deepwater



Horizon Oil Spill identified multiple procedural failures in well control, cement testing, and emergency response that, if properly executed, could have prevented the

blowout.

This guide covers why oil and gas field operations demand rigorous SOPs, the specific procedures every operation needs, and a practical approach to building procedures that protect workers, the environment, and your operation's license to operate.

Why Oil and Gas Operations Need SOPs

The oil and gas industry is regulated by a complex web of federal, state, and local agencies. The Occupational Safety and Health Administration (OSHA) sets workplace safety standards under 29 CFR 1910 and 1926. The Bureau of Safety and Environmental Enforcement (BSEE) regulates offshore operations. The Pipeline and Hazardous Materials Safety Administration (PHMSA) governs pipeline operations. The Environmental Protection Agency (EPA) enforces air emissions, water discharge, and waste management regulations. State oil and gas commissions regulate drilling, completion, and production operations.

Non-compliance carries severe consequences. OSHA citations for serious violations average \$16,131 per violation as of 2024, with willful violations reaching \$161,323. BSEE can impose civil penalties up to \$71,666 per day per violation for offshore operations. EPA penalties for environmental violations can reach tens of millions of dollars. Criminal prosecution of individuals is increasingly common for egregious violations.

The safety imperative is equally compelling. The Bureau of Labor Statistics (BLS) reports that the oil and gas extraction industry has a fatal injury rate approximately seven times higher than the all-industry average. Common fatalities involve struck-by incidents, caught-in/between events, falls, explosions, and hydrogen sulfide (H₂S) exposure. Each of these hazard categories requires specific, detailed procedures.

Environmental risks add another dimension. Oil spills, produced water releases, air emissions, and land disturbance all carry regulatory, financial, and reputational consequences. Companies that fail to prevent environmental incidents face not only regulatory penalties but also community opposition that can threaten their social license to operate.



Key Procedures Every Oil and Gas Operation Needs

1. Well Control and Blowout Prevention

Well control procedures are the most critical SOPs in drilling and workover operations. They must define kick detection indicators, shut-in procedures for different rig configurations, kill methods (driller's method, wait-and-weight), blowout preventer (BOP) testing and maintenance schedules, and well control drills. These procedures must comply with API Standard 53 and BSEE regulations for offshore operations.

2. Hydrogen Sulfide (H₂S) Safety

H₂S is one of the deadliest hazards in oil and gas operations, capable of killing workers within minutes at high concentrations. SOPs must define H₂S monitoring requirements, alarm setpoints (typically 10 ppm for alert, 20 ppm for danger), respiratory protection requirements, safe briefing areas, wind direction monitoring, buddy system protocols, and rescue procedures. These procedures must align with ANSI/API Recommended Practice 49.

3. Permit to Work and Hot Work

The permit-to-work system is the primary control for non-routine and high-hazard activities. SOPs should define permit categories (hot work, confined space entry, line breaking, excavation, electrical isolation), the authorization process, required hazard assessments, monitoring requirements, and permit closure. Hot work procedures must specifically address fire prevention in hydrocarbon-rich environments.

4. Lockout/Tagout and Energy Isolation

Oil and gas equipment involves multiple energy sources including pressure, electrical, mechanical, thermal, chemical, and gravitational. Lockout/tagout procedures must identify all energy sources for each piece of equipment, define isolation methods, specify verification procedures, and address complex isolations involving multiple energy sources and multiple workers.

5. Environmental Protection and Spill Prevention

Spill Prevention, Control, and Countermeasure (SPCC) plans are required by EPA for facilities that store more than 1,320 gallons of oil above ground. SOPs should define



secondary containment requirements, tank inspection schedules, transfer procedures, spill response actions by size and material, and reporting requirements under the National Response Center framework.

6. Lifting Operations and Crane Safety

Crane and rigging operations are a leading cause of fatalities in oil and gas. SOPs must define lift planning requirements, load calculation procedures, rigging inspection criteria, signal person qualifications, exclusion zone management, and specific procedures for critical lifts (those involving personnel, high value, or high risk).

7. Confined Space Entry

Tanks, vessels, pits, and other confined spaces in oil and gas operations may contain toxic or flammable atmospheres, oxygen-deficient environments, or engulfment hazards. SOPs must define space evaluation, atmospheric testing requirements and action levels, ventilation procedures, entry permits, attendant duties, and rescue provisions per OSHA 29 CFR 1910.146.

8. Transportation and Driving Safety

With field operations often located in remote areas, driving is one of the most frequent exposure activities for oil and gas workers. Transportation SOPs should define journey management planning, vehicle inspection requirements, fatigue management rules, severe weather driving protocols, and incident reporting procedures.

Step-by-Step: Building Your Oil and Gas Field Operations SOP

Step 1: Identify your operational scope. Oil and gas operations vary enormously, from single-well stripper operations to major offshore platforms. Define the specific activities your SOPs must cover: drilling, completion, production, workover, pipeline, midstream processing, or some combination. Each activity has distinct hazard profiles and regulatory requirements.



WorkProcedures

Step 2: Map your regulatory obligations. Create a compliance matrix listing every applicable regulation by activity and hazard category. Include OSHA general industry

and construction standards, BSEE regulations for offshore operations, EPA air and water regulations, PHMSA pipeline regulations, state oil and gas commission rules, and local ordinances. This matrix drives your minimum procedure requirements.

Step 3: Conduct a comprehensive risk assessment. Use a structured methodology like Hazard and Operability Study (HAZOP), Job Hazard Analysis (JHA), or bowtie analysis to identify hazards, assess risks, and determine required controls for each operational activity. Risk assessment results directly inform the content and emphasis of your procedures.

Step 4: Reference industry standards. The American Petroleum Institute (API) publishes hundreds of recommended practices and standards covering virtually every aspect of oil and gas operations. Key references include API RP 75 for safety and environmental management systems, API RP 54 for occupational safety, API RP 49 for H2S safety, and API Standard 53 for well control. Align your procedures with these industry-recognized standards.

Step 5: Write procedures with field conditions in mind. Oil and gas SOPs must account for the realities of field operations: remote locations, extreme weather, limited communication, fatigued workers, and temporary workforce. Procedures that assume ideal conditions will fail in the field. Include provisions for adverse conditions and define the criteria for stopping work.

Step 6: Integrate contractor management. A significant portion of oil and gas field work is performed by contractors. Your SOPs must address how contractor procedures are verified, how contractor workers are oriented to site-specific hazards, how permit-to-work systems apply to contractors, and how contractor safety performance is monitored. API RP 76 provides guidance on contractor safety management.

Step 7: Implement a Management of Change process. Oil and gas operations frequently change through new wells, equipment modifications, process changes, and personnel turnover. A Management of Change (MOC) procedure ensures that changes are evaluated for safety, environmental, and regulatory implications before implementation, and that affected procedures are updated accordingly.

Step 8: Establish emergency response procedures. Develop site-specific emergency response plans for fires, explosions, blowouts, H2S releases, medical emergencies,



and partners.

Common Mistakes to Avoid

Copying another company's procedures without customization. Oil and gas SOPs must reflect your specific operations, equipment, hazards, and regulatory jurisdiction. Procedures copied from another operator or a generic template will not address your actual risks and may not comply with your specific regulatory requirements.

Failing to integrate procedures into daily operations. SOPs that exist only in binders in the office trailer are worthless. Effective oil and gas procedures are integrated into daily toolbox talks, pre-job safety meetings, permit-to-work processes, and job hazard analyses. They must be accessible at the work site, not just the office.

Underestimating the importance of Stop Work Authority. Every worker, regardless of position or employer, must have clear authority and procedures to stop work when they observe an unsafe condition. The SOP must define how stop work is exercised, how the concern is evaluated, and how work resumes. Stop work authority without a clear procedure becomes a meaningless policy statement.

Neglecting process safety management. Oil and gas facilities that process or store large quantities of hydrocarbons may be subject to OSHA's Process Safety Management (PSM) standard, 29 CFR 1910.119. PSM requires 14 specific elements including operating procedures, mechanical integrity, and incident investigation. Failing to identify PSM applicability is a common and costly oversight.

Treating safety procedures as separate from operational procedures. Safety and operations are not separate domains; they are inseparable. The procedure for opening a valve should include the safety steps as integral parts of the operation, not as a separate safety overlay. Integrated procedures are followed; bolt-on safety steps are skipped.

How AI Accelerates SOP Creation



Oil and gas operations require an extensive library of procedures, often numbering in the hundreds, each one tailored to specific equipment, conditions, and regulations.

Developing this library from scratch can take a dedicated team a year or more, and the procedures must be continuously updated as conditions, regulations, and equipment change.

WorkProcedures accelerates this process by generating regulation-aware, industry-standard-aligned draft procedures based on your operation type, location, and hazard profile. The platform incorporates OSHA standards, API recommended practices, and environmental regulations to produce comprehensive drafts that your operations and safety teams can review and customize.

The platform also helps manage the ongoing challenge of keeping procedures current. When regulations change, equipment is modified, or incidents reveal procedural gaps, WorkProcedures facilitates rapid updates, version control, and distribution to field locations, ensuring that every site is working from current procedures.

Conclusion

Oil and gas field operations demand some of the most rigorous and comprehensive SOPs in any industry. The combination of high-hazard environments, complex regulatory requirements, and severe consequences for failure makes thorough, well-maintained procedures an operational necessity, not an administrative preference.

Start with your highest-risk activities, align your procedures with both regulations and industry standards, account for real field conditions, and build a culture where following procedures is non-negotiable. The investment in proper procedures pays returns measured in lives protected, environmental incidents prevented, and regulatory compliance maintained.

Visit [WorkProcedures](https://www.workprocedures.com) to get started.

Ready to Streamline Your SOPs?



WorkProcedures

Generate professional, industry-standard procedures in minutes with WorkProcedures.

[Start Free Trial](#) →

Related Posts

[Industry Guides](#)

Patient Intake Process SOP: A Front-Desk Template for Medical Offices

The front desk is where revenue cycle, compliance, and patient experience collide. A documented patient intake SOP keeps eligibility checks, HIPAA forms, copays, and rooming handoffs consistent every visit.

Aug 12, 2026

8 min read

[Industry Guides](#)

Airbnb Cleaning Checklist and Turnover SOP: Protect Your Ratings

Cleanliness is the review category that sinks listings fastest. Turn your Airbnb cleaning checklist into a full turnover SOP — sequence, restocking, damage checks, and photo verification.

Aug 9, 2026

8 min read

[Industry Guides](#)



CNC Machine Shop Procedures: Setup Sheets, First Article, and Tool Control

Scrapped parts, crashed spindles, and quarantined lots almost always trace back to an undocumented step. These are the CNC machine shop procedures that keep jobs running to print.

Aug 5, 2026

9 min read

Ready to streamline your procedures?

Start free — no credit card required.

Get Started Free →

Talk to Us



WorkProcedures

AI-powered standard operating procedure generation built on 10,000+ industry SOPs. Create, collaborate, and distribute professional procedures in minutes.



PRODUCT

SOP Generation

Workflows

Handbooks

PDF & Word Export

Compliance Tracking

Pricing

RESOURCES

SOP Blog

What's New

Free AI SOP Generator

SOP Templates

SOP Templates by Industry

SOP Examples

Process Documentation Software

Developers — API & MCP

Sign Up Free

GUIDES & TEMPLATES



WorkProcedures

[Work Instructions Template](#)[Job Procedure Template](#)[Office Procedures Manual](#)[Employee Procedure Manual](#)[ISO 9001 Procedures](#)[How to Write SOPs](#)[How to Document Processes](#)[Workplace Procedures & Policies](#)

COMPANY

[Contact Us](#)[Email Support](#)[vs Smartsheet](#)[vs Document360](#)[vs Helpjuice](#)[Privacy Policy](#)[Terms of Service](#)

© 2026 WorkProcedures. All rights reserved.

WorkProcedures is a product of Evraday Ltd · Alford, Lincolnshire, United Kingdom