

شرح مفصل لطريقة الغاء الشيب للطابعات الا EPSON من خلال موقع 2manuals و Chipless solutions

١- أول حاجة بتروح لموقع chipless solutions من خلال الا رابط الخاص بيه

[www\(chiplessolutions.com](http://www(chiplessolutions.com)

أو من خلال البحث من خلال جوجل



https://www.chiplessolutions.com

ChiplessSolutions.com

Chipless Solutions for Epson printers

CHIPLESS

Main Page

Supported Models

Download Firmware

Buy Activation Keys

How to use Activation Key

Discussion Board

Live Support OFFLINE

Join us on Telegram

:: Make Your Epson Printer Chipless by Yourself!

ChiplessSolutions presents Firmware Service making Epson printers Chipless.

What does it mean? Once You modify printers Firmware - printer will not require Ink Cartridges (IC Chips on cartridges) anymore. You will not need to reset ink chips or replace them if they are broken.

Whats more? You can use CISS or Refillable Ink Cartridges on those printer models that doesn't have AutoReset Chips developed yet! Instead of using expensive Epson OEM Ink Cartridges - You can use third party Ink Cartridges, CISS or Refill Cartridges now!

How It works?


It will work for supported printers only. You can check supported models list [here](#).

Full Manual how to perform this firmware updates You can find on [Download Page](#)

٢- أول حاجة بنحمل ملف الـ Firmware الخاص بالطابعة اللي احنا محتاجين اننا نعدلها و هناخد


مثل في الشرح ده على الطابعة WF-869R

٣- هنختار Download Firmware



The screenshot shows the homepage of ChiplessSolutions.com. On the left, there's a vertical menu with links: Main Page, Supported Models, Download Firmware (which is highlighted with a red box), Buy Activation Keys, How to use Activation Key, and Discussion Board. Below the menu are two buttons: 'Live Support OFFLINE' and 'Join us on Telegram'. On the right, there's a section titled ':: Make Your Epson Printer Chipless by Yourself!' which contains text about the service and how it works, along with a 'Download Page' link. At the top of the page, there's a URL bar showing 'https://www.chiplessolutions.com' and a logo for 'CHIPLESS'.

٤- بنحمل ملف License.exe




The screenshot shows a sub-page on the ChiplessSolutions.com website titled ':: Download Chipless Firmware for Epson printers'. On the left, there's a vertical menu with links: Main Page, Supported Models, Download Firmware, Buy Activation Keys, How to use Activation Key, and Discussion Board. Below the menu are two buttons: 'Live Support OFFLINE' and 'Join us on Telegram'. In the center, there's a section titled 'Download License.exe utility' with a note '- Password - 12345'. To the right is a table listing printer models and download links. The table has three columns: Printer Model, Download Firmware, and Guide & Buy. It includes sections for 'SC-P Series' and 'Work Force Series' with various printer models listed. The URL bar at the top shows 'https://www.chiplessolutions.com/download.shtml' and the 'CHIPLESS' logo is visible.

Download Chipless Firmware for Epson printers

Printer Model	Download Firmware	Guide & Buy
SC-P Series		
P400, P405, P407, P408, PX7V2	download	Guide & Buy
P600, P607, P608, PX5V2	download	Guide & Buy
P800, P807, PX3V	download	Guide & Buy
Work Force Series		
WF-2630, WF-2631	download	Guide & Buy
WF-2650, WF-2651	download	Guide & Buy
WF-2750, WF-2751	download	Guide & Buy
WF-2760, WF-2761	download	Guide & Buy
WF-2830, WF-2831, WF-2838	download	Guide & Buy
WF-2850, WF-2851, WF-2855	download	Guide & Buy
WF-2860, WF-2861, WF-2865	download	Guide & Buy
WF-3720, WF-3721, WF-3723, WF-3725, WF-3730, WF-3733, PX-M680F	download	Guide & Buy
WF-4630	download	Guide & Buy
WF-4720, WF-4730, WF-4733, WF-4734, PX-M780F	download	Guide & Buy
WF-5620, PX-M840F	download	Guide & Buy
WF-7210, WF-7211 WF-7215, PX-S5080 New!	download	Guide & Buy
WF-7710, WF-7711, WF-7715, WF-7720, WF-7721, PX-M5080F, PX-M5081F	download	Guide & Buy
WF-C5210, PX-5884	download	Guide & Buy

Opening License.zip
You have chosen to open:
License.zip
which is: WinRAR ZIP archive (2.2 MB)
from: https://chiplessolutions.com
What should Firefox do with this file?
 Open with WinRAR archiver (default)
 Save File
 Do this automatically for files like this from now on.
OK Cancel

٥- بنفك الضغط عن ملف License.exe



٦- بنفك الضغط عن الملف ده أيضا وبيكون الباسورد الخاص بفكه 12345




محتويات الملف الأداة الخاصة بتفعيل الغاء الشيب و ملف PDF خاص بالمجموعة اللي طورت الأداة


٧- بنروح للموقع مرة تانية ونحمل ملف الـ Firmware

The screenshot shows a web browser window with the URL <https://www.chiplessolutions.com/download.shtml>. The page displays a table of printer models and their corresponding download links. A file download dialog box is overlaid on the page, prompting the user to open or save the file 'WFC869_FW483TL_HR1018_HR99Z9.zip'. The dialog also includes options to save the file automatically for future downloads.

Printer Model	Download Firmware	Guide & Buy
WF-2630, WF-2631	download	Guide & Buy
WF-2650, WF-2651	download	Guide & Buy
WF-2750, WF-2751	download	Guide & Buy
WF-2760, WF-2761	download	Guide & Buy
WF-2830, WF-2831, WF-2838	download	Guide & Buy
WF-2850, WF-2851, WF-2855	download	Guide & Buy
WF-2860, WF-2861, WF-2865	download	Guide & Buy
WF-3720, WF-3721, WF-3723, WF-3725, WF-3730, WF-3733, PX-M680F	download	Guide & Buy
WF-4630	download	Guide & Buy
WF-4720, WF-4730, WF-4733, WF-4734, PX-M780F	download	Guide & Buy
WF-5620, PX-M5080F	download	Guide & Buy
WF-7210, WF-7211 WF-7215, PX-S5080 New!	download	Guide & Buy
WF-7710, WF-7711, WF-7715, WF-7720, WF-7721, PX-M5080F, PX-M5081F	download	Guide & Buy
WF-C5210, PX-S5884	download	Guide & Buy
WF-C5290	download	Guide & Buy
WF-C5710, PX-M894F	download	Guide & Buy
WF-C5790	download	Guide & Buy
WF-C579R, WF-C579RA, WF-C579RB New!	download	Guide & Buy
WF-M5799 New!	download	Guide & Buy
WF-C8690, PX-M7110FP New!	download	Guide & Buy
WF-C869R, PX-M7070FX	download	Guide & Buy
XP Series		
XP-55, EP-306	download	Guide & Buy
XP-211, XP-212, XP-213, XP-214, XP-216, PX-046A	download	Guide & Buy
XP-230, XP-231, PX-048A	download	Guide & Buy
XP-235, XP-235A	download	Guide & Buy
XP-240, XP-241, PX-049A	download	Guide & Buy



بنزيل ملف الا Firmware ونفك الضغط



محتويات ملف الا Firmware المعدل

دلوقتي احنا محتاجين كابل USB للبرنتر عشان نوصله للابتوب أولاً عشان الـ Firmware المعدل ينزل على الطابعة

وتاني حاجة نفعل الغاء الشبيبات



بنوصل الكابل للطابعة بالطريقة دي



ونوصل الطرف الثاني للكابل في الكمبيوتر او الكمبيوتر بالطريقة دي



وبنفتح الطابعة ف وضع الا Update الخاص بالطابعة والطريقة كالتالي
في حالة المثال اللي احنا بنشرح عليه اللي هو الطابعة WF-869R فهي ليها طريقة وهي:



بنضغط على الأزرار الموضحة بالصورة

طبعا الطابعات اللي ليها نفس الشاشة والأزرار بتتفتح بنفس الطريقة زي 5710 – 5790 – 7710 – 579R –

أما لو بفتح الطابعة - 5290 - 5210 أو أي طابعة بنفس نظام الشاشة فبتكون الطريقة كالتالي




وبنكملي الخطوات بعد كده


بعد ما بنفتح الطابعة على وضع الـ UPDATE هتظهر لك الشاشة بالمنظر ده




بنزوح على الالاتوب أو الكمبيوتر وفتح ملف الا فارم ونفتح المعدل ده Firmware




بيظهر لنا الملف بالمنظر ده




بنمشي بالخطوات







بنوصل للمرحلة دي في حالة ان الكابل راكب كويس في الطابعة واللابتوب او الكمبيوتر بتظهر لك الطابعة
ومتحدد عليها لتحميل الا Firmware




Start وينضغط

في الحالة دي الا Firmware يتم تحميله على الطابعة



بعد ما الملف يتبع للطابعة ويتحمل بشكل سليم



بنضغط على زرار 0



ببيظهرلنا رقم الاـ Firmware المعدل وطالاما ظهر الرقم ده يبقى الاـ Firmware المعدل اتحمل بطريقة سليمة

HR1018



بتضغط على زرار 0 مرة تانية والطابعة بتقفل نفسها وبتفتحها تاني عشان نكمل خطوات التفعيل



هنا احنا محتاجين كود او السيریال عشان نفعل الغاء الشیبات على البرنتر

وده بيتم من خلال موقع 2manuals

نرجع للصفحة اللي احنا حملنا منها الد Firmware

وأمام نوع الطابعة اللي احنا عايزين الكود بتاعه نضغط على Guide&buy

https://www.chiplessolutions.com/download.shtml

Supported Models

Download Firmware

Buy Activation Keys

How to use Activation Key

Discussion Board

Live Support OFFLINE

Join us on Telegram

Licence.exe utility
- Password - 12345

Printer Model	Download Firmware	Guide & Buy
SC-P Series		
P400, P405, P407, P408, PX7V2	download	Guide & Buy
P600, P607, P608, PX5V2	download	Guide & Buy
P800, P807, PX3V	download	Guide & Buy
Work Force Series		
WF-2630, WF-2631	download	Guide & Buy
WF-2650, WF-2651	download	Guide & Buy
WF-2750, WF-2751	download	Guide & Buy
WF-2760, WF-2761	download	Guide & Buy
WF-2830, WF-2831, WF-2838	download	Guide & Buy
WF-2850, WF-2851, WF-2855	download	Guide & Buy
WF-2860, WF-2861, WF-2865	download	Guide & Buy
WF-3720, WF-3721, WF-3723, WF-3725, WF-3730, WF-3733, PX-M680F	download	Guide & Buy
WF-4630	download	Guide & Buy
WF-4720, WF-4730, WF-4733, WF-4734, PX-M780F	download	Guide & Buy
WF-5620, PX-M840F	download	Guide & Buy
WF-7210, WF-7211 WF-7215, PX-S5080 New!	download	Guide & Buy
WF-7710, WF-7711, WF-7715, WF-7720, WF-7721, PX-M5080F, PX-M5081F	download	Guide & Buy
WF-C5210, PX-S984	download	Guide & Buy
WF-C5290	download	Guide & Buy
WF-C5710, PX-M884F	download	Guide & Buy
WF-C5790	download	Guide & Buy
WF-C579R, WF-C579RA, WF-C579B New!	download	Guide & Buy
WF-M5799 New!	download	Guide & Buy
WF-C8690, PX-M7110FP New!	download	Guide & Buy
WF-C869R, PX-M7070FX	download	Guide & Buy
XP Series		
XP-55, EP-306	download	Guide & Buy
XP-211, XP-212, XP-213, XP-214, XP-216, PX-046A	download	Guide & Buy
XP-230, XP-231, PX-048A	download	Guide & Buy
XP-235, XP-235A	download	Guide & Buy
XP-240, XP-241, PX-049A	download	Guide & Buy
XP-243, XP-245, XP-247	download	Guide & Buy
XP-255, XP-257	download	Guide & Buy
XP-340	download	Guide & Buy
XP-342, XP-343, XP-345	download	Guide & Buy
XP-352, XP-355	download	Guide & Buy
XP-430, XP-431, XP-434	download	Guide & Buy
XP-440, XP-441, XP-446	download	Guide & Buy

بتظهر لنا الصفحة دي واللي بتكون موضحة الارشادات الخاصة بطريقة تحميل الـ Firmware على الطابعة

وزي ما موضح هنا بيكون مكتوب رقم الـ Firmware المعدل اللي بيظهر بعد نجاح عملية تحميله على الطابعة

Activation Key for making Epson WF-C869RDTWF (RIPS), PX-M7070FX Chipless!

Be sure Your printer can be modified to Chipless Version.

Don't buy Activation Key before You have checked if Your printers Firmware can be changed to Chipless! Make following steps.

Step 1
Download and extract Zip archive with WF-C869 Firmware - [version HR1018](#)

Step 2
Connect printer to PC (with Windows OS) by proper USB cable.
Disable all Epson processes and services. You can do this manually using task manager and administration tools or You can do this via [WIC Reset Utility](#) (install and run it, then select MENU Support)

Step 3
Upload Firmware to printer in the **NORMAL MODE** (do NOT use service mode yet just start the printer with the power button). Run EPFWUPD.EXE file and follow all steps until Firmware will upload

Name	Date modified	Type	Size
WF-C869...	3/29/2018 6:08 PM	File folder	137 KB
WF-C869...	3/29/2018 6:08 PM	File folder	137 KB
WF-C869...	4/2/2018 4:33 PM	Application extension	1.64 KB
WF-C869...	4/2/2018 4:33 PM	Application extension	15.6 KB
WF-C869...	4/2/2018 4:36 PM	Application	3.63 KB
WF-C869...	2/6/2018 4:57 PM	EXE File	6.69 KB
WF-C869...	2/7/2018 3:08 PM	Application extension	10 KB

When Firmware Update process is complete - printer will restart - usually it will take only a few minutes but can continue for 10-20 minutes in some rare cases.
If process hangs or stops at 80-99% - replug power cable and start printer manually.

Now check current firmware version ([how to check](#)).
If firmware version **HR1018** - Firmware has been uploaded successfully. You can go to next Step.
If NO - restart the printer and try once more time.

What do You have to do next after uploading chipless firmware?

- Buy this Activation Key
- Download [License.exe](#) application (Windows only) - [download here](#)
- Run License.exe under **Windows** and press **Activate Online** button
- Input Activation Key and press **OK!**

Buy Activation Key after You have successfully uploaded Firmware to Your printer!

Prices and discounts:

1 Activation Key - \$110

عشان نقدر اننا نشتري الكود ونفعل الغاء الشيب هنحتاج نسجل حساب على الموقع لمرة واحدة

Ink pads are at the end of their service life
[Download WIC Reset Utility - Free](#) [BUY Reset Keys or Firmware Keys here!](#)

2MANUALS.COM provides the Waste Ink Pad Reset Service

Your Printer has stopped? Waste Ink Pads counter overflow?
Want to go to Epson Customer Service? Want give them \$50?
DON'T WASTE YOUR TIME and MONEY - RESET YOUR PRINTERS YOURSELF:
1. [Download Free the WIC Reset Utility](#) and check Waste Ink Pads Counters
2. [Buy Reset Key](#) and Get Reset Key Online!
3. RESET Waste Ink Counters and continue to print!
[See Video How to Reset Waste Ink Pads in 30 seconds!](#)

BUY online -> GET online -> RESET online
Few minutes will Save Your \$50!
Few minutes will Save Your Time for NOT going to repair service!

Video tutorial for Dummies. How to Reset Epson L220 printer Waste Ink Pads counters in 20 seconds. The same for all other models supported by WIC.

هتضغط على sign in or Register

بتملا ببياناتك والايدي الـي هيوصلك عليه رسالة بالباسورد وتضغط Continue

The screenshot shows the login page for 2manuals.com. At the top, there's a header with the website name and some promotional links for ink pads and reset utilities. Below the header is a search bar and a login link. The main area is divided into two sections: 'Returning Customer.' and 'New Customer, Create account.' The 'Returning Customer.' section contains fields for E-Mail Address and Password, and a reCAPTCHA checkbox. The 'New Customer, Create account.' section contains fields for First Name, Last Name, and E-Mail Address, with a note about entering a correct email address. Both sections have reCAPTCHA checkboxes. The 'Continue' button in the 'New Customer' section is highlighted with a red box.

كده الحساب اتسجل وتحتاج انك تفتح الميل بتاعك عشان تاكد الحساب وتأخذ منه الباسورد اللي هتدخل
بيه الموقع

The screenshot shows the 'create_account_success.php' page. It displays a message 'Your Account Has Been Created!' above a small cartoon illustration of a person at a computer. Below the message, there's a 'Congratulations!' section with text about the successful creation of the account and how to place orders. A 'RESET KEY' section shows a recent purchase. The right side of the page has a sidebar with links like 'Video', 'Reviews', and 'Service Manuals'. The 'Continue' button at the bottom right is highlighted with a red box.

بتوصل الرسالة على الميل بالمنظر ده بتاخد بياناتك وتعمل تسجيل دخول للموقع

The screenshot shows a Gmail inbox with 18,050 messages. An email from "John | 2manuals.com <noreply@2manuals.com>" is selected. The subject is "Welcome to 2MANUALS.COM On-Line Store". The message body contains a welcome message, a login link (redacted), a password link (redacted), instructions to change password, a link to edit profile, and links for order history and reset keys. It also includes a note about finding Reset Keys in spam folders and a message about placing orders.

The screenshot shows the login page for 2manuals.com. The URL is https://www.2manuals.com/login.php. The page features a banner about ink pads and a CAPTCHA challenge. The login form has fields for E-Mail Address and Password, a checkbox for 'I'm not a robot', and a CAPTCHA image. A red box highlights the 'Login' button. Below the form, there are links for returning customers, new customers, and account creation.

بعد ما تم دخولك للحساب بترجع مرة تانية للصفحة اللي بنشتري منها الكود وتضغط على

ADD TO CART

The screenshot shows a web browser displaying the 2manuals.com website. The main content is about an 'Activation Key for making Epson WF-C869RDTWF (RIPS), PX-M7070FX Chipless Printer (for one device only)'. A red box highlights the '\$110.00' price and the 'ADD TO CART' button. The page also features a 'CHIPLESS' logo and payment method options like PayPal and M-Pesa.

Check out على **بتضغط على**

The screenshot shows the same website after the item has been added to the cart. The shopping cart summary shows a total of \$110.00. A red box highlights the large blue 'Checkout' button. The rest of the page content remains the same, including the activation key details and payment options.

ببیتم تحویلک لصفحة بتضییف فيها بیانات الدفع الخاصة بیک و بتضغط Pay ده في حالة انك عندك بطاقة بنکية و بتضغط

https://www.2manuals.com/checkout_payment.php#linkpointms1

STEP 2 of 3 - Select Payment Method

The secure SSL connection has been established.

(You can check it easy - the URL has to begin with <https://> not <http://>)

Credit Card payment. Secure 128-bit SSL encrypted payment.

Credit Card Owner :

Credit Card Number : 16 digits 

Expiration Date : Credit Card expiration date

Security code (CVC or CVV):
[What's this value \[?\]](#)

Billing information:

Street Address:

City:

State/Province:

Post Code:


Country:

All fields are required!

Pay!




أما في حالة لو مش معاك بطاقة بنكية بنحتاج حسب فودافون كاش الخاص بيكم تقوم بعمل بطاقة اونلاين



بالمبلغ المطلوب زي كده


من خلال تطبيق أنا فودافون




بدهه انت معاك حساب بنكي مؤقت تقدر تتفذ بيه العملية وتشتري الكود

نرجع تاني بعد ما نتم عملية الدفع بيوصلك رسالة الكترونية مباشرة على ايميلك الخاص بكود التفعيل للغا


الشيب




بنرجع مرة تانية لبرنامج License.exe وبنشغله بالطريقة دي




بنضغط على Activate online



هيطلب مننا ادخال الكود هندخل الكود اللي وصلنا على الميل ونضغط OK



كده تم تفعيل الغاء الشبيبات بنجاح ببرسستر الطابعة بعد كده



وبتلتغي الشيبات الخاصة بالطابعة بشكل نهائى

