

UMBRA

Stereo Feedback Accumulator



- 1 L Audio Input
- 3 L Signal Send Output
- 5 L Signal Return Input
- 7 L Processed Signal Output
- 9 Input Level VCA L/R Pair CV Input (0-5V)
- 10 Input Level LED Indicator
- 11 IMBUE: Input Level Knob (Attenuator when VCA CV is added)
- 12 Feedback Amount (L/R) CV Input (0-5V)
- 13 FEED: Feedback Amount Knob (Attenuator when Feed VCA CV is added)





- 2 R Audio Input
- 4 R Signal Send Output
- 6 R Signal Return Input
- 8 R Processed Signal Output
- 14 Post-Feedback Signal VCAL/R Pair CV Input
- 15 Return Level LED Indicator
- 16 DRAIN: Return Level Knob (Attenuator when Return VCA CV is added)
- 17 Serial / Parallel Switch

Stereo operation or serial mono operation. Output of the left channel enters the input on the right channel when in serial.

Orange L and R channels = Stereo operation

Orange L channel, Blue R channel = Serial operation

