

RADIO AIDS TO NAVIGATION (Continued)

Navigation and Communication Boxes - Common Elements

Frequency Protection

Frequency Protection usable range at 18,000' AGL - 40 NM

(L)

Frequency Protection usable range at 12,000' AGL - 25 NM

(T)

DISTANCE MEASURING EQUIPMENT

Facilities that operate in the "Y" mode for DME reception

(Y)

VOICE COMMUNICATIONS VIA NAVAID

Voice Transmitted

112.6

No Voice Transmitted

111.0

NAVAID SHUTDOWN STATUS

VHF/UHF

LF/MF

PART TIME OR ON-REQUEST

VHF/UHF

LF/MF

AUTOMATED WEATHER BROADCAST SERVICES

ASOS/AWOS - Automated Surface Observing Station/Automated Weather Observing Station

VHF/UHF

LF/MF

LATITUDE AND LONGITUDE

Latitude and Longitude coordinates are provided for those NAVAIDs that make up part of a route/airway or a holding pattern. All TACAN facilities will include geographic coordinates.

LOW ENROUTE

N00°00.00' W000°00.00'

HIGH ENROUTE

N00°00.00'
W000°00.00'

Navigation and Communication Boxes - Examples

LOW ENROUTE CHARTS

VOR

R - Receive only 122.1R

Controlling FSS Name - ANDERSON

122.1R
ALLEDALE
116.7 ALD
N33°00.75' W81°17.53'
[ANDERSON]

(T) - Service Volume

POLK (T)
108.4 FXU

Receive & Transmit on 122.35

(T) - Service Volume

Latitude and Longitude

Controlling FSS Name - MACON

122.35
TIFT MYERS (T)
112.5 IFM
N31°25.72' W83°29.33'
[MACON]

VOR

HIGH ENROUTE CHARTS

CECIL
117.9 VQQ
N30°12.78'
W81°53.45'