

COMPROBANDO LOS MODELOS EN SAP

File Edit View Define Draw Select S Define Grid System Data

Model Explorer

- Model
 - Project
 - Coordinate Systems
 - Properties
 - Foundations
 - Other Definitions
 - Structural Objects
 - Groups
 - Loads
 - Named Output Items

System Name: GLOBAL

Quick Start...

X Grid Data

Grid ID	Ordinate (m)	Line Type	Visible	Bubble Loc	Grid Color
A	0	Primary	Yes	End	
B	6	Primary	Yes	End	
C	12	Primary	Yes	End	

Add Delete

Y Grid Data

Grid ID	Ordinate (m)	Line Type	Visible	Bubble Loc	Grid Color
1	0	Primary	Yes	Start	
2	3	Primary	Yes	Start	

Add Delete

Z Grid Data

Grid ID	Ordinate (m)	Line Type	Visible	Bubble Loc
Z1	0	Primary	Yes	End
Z2	3	Primary	Yes	End

Add Delete

Grid Lines

Quick Start...

Display Grids as

☒ Ordinates ☐ Spacing

☐ Hide All Grid Lines

☐ Glue to Grid Lines

Bubble Size: 1,


Reset to Default Color


Reorder Ordinates


OK Cancel


Hold down left mouse button and drag to pan region


X2,974 Y3, Z5,827 GLOBAL Kg, m, C

















File Edit View Define Draw Select Assign Analyze Display Design Options Tools Help

Model Explorer

- Model
 - Project
 - Coordinate Systems
 - Properties
 - Foundations
 - Other Definitions
 - Structural Objects
 - Groups
 - Loads
 - Named Output Items

Deformed Shape (Pso). [m]

S Modal Periods And Frequencies

File View Edit Format-Filter-Sort Select Options

Units: As Noted Modal Periods And Frequencies

Filter:

	OutputCase	StepType Text	StepNum Unitless	Period Sec	Frequency Cyc/sec	CircFreq rad/sec	Eigenvalue rad2/sec2
▶	MODAL	Mode	1	0.076548	13.0637712...	82.0820958...	6737,47046...
	MODAL	Mode	2	0.009794	102,103321...	641,534092...	411565,991...
	MODAL	Mode	3	0.009673	103,376277...	649,532304...	421892,215...
	MODAL	Mode	4	0.006932	144,261200...	906,419858...	821596,959...
	MODAL	Mode	5	0.006928	144,350136...	906,978655...	822610,281...
	MODAL	Mode	6	0.006914	144,631439...	908,746133...	825819,535...

Record: << < 1 > >> of 6 Double-click row header to view row details. Add Tables... Done

Ready Start Animation GLOBAL Kg, m, C

	OutputCase	StepType Text	StepNum Unitless	Period Sec	Frequency Cyc/sec	CircFreq rad/sec	Eigenvalue rad2/sec2
►	MODAL	Mode	1	0,076548	13,0637712...	82,0820958...	6737,47046..
	MODAL	Mode	2	0,009794	102,103321...	641,534092...	411565,991..
	MODAL	Mode	3	0,009673	103,376277...	649,532304...	421892,215..
	MODAL	Mode	4	0,006932	144,261200...	906,419858...	821596,959..
	MODAL	Mode	5	0,006928	144,350136...	906,978655...	822610,281..
	MODAL	Mode	6	0,006914	144,631439...	908,746133...	825819,535..

Archivo

Inicio

Insertar

Dibujar

Disposición de página

Fórmulas

Datos

Revisar

Vista

Programador

Ayuda

¿Qué desea hacer?

Pegar

Portapapeles

Calibri

11

A

A

N

K

S

Fuente

Alineación

General

Número

Formato condicional

Dar formato como tabla

Estilos de celda

L19

</