

ARACHIS ONLINE TRAINING

FLOOR GLAZE / TILE POLISH FORMULA

Practical Formula

This formula is for making a shiny floor glaze / tile polish for cement floors, tiles, terrazzo, and smooth floors. It gives a glossy finish and helps the floor look clean and polished.

1. LOW-COST FLOOR GLAZE FORMULA

Batch Size: 5 Litres

Ingredients

Ingredient	Quantity	Purpose
Clean water	3.5 litres	Main solvent
PVA binder / PVA glue	1 litre	Gives film and shine
Acrylic binder / floor polish resin	300 ml	Improves gloss and durability
Liquid paraffin or silicone oil	100 ml	Adds smoothness and shine
Texapon / SLES	50 ml	Helps mixing and spreading
Formalin / preservative	20 ml	Prevents spoilage
Colour	Small amount	Optional
Fragrance	20–30 ml	Optional scent

Procedure

- a) Put 3.5 litres clean water into a clean bucket.
- b) Add 50 ml Texapon / SLES and stir slowly until it mixes well.
- c) Add 1 litre PVA binder or PVA glue slowly while stirring.
- d) Add 300 ml acrylic binder / floor polish resin and continue mixing.
- e) Add 100 ml liquid paraffin or silicone oil slowly and stir very well.
- f) Add 20 ml preservative.
- g) Add colour if you want a coloured glaze. Use very little colour because too much can stain floors.

- h) Add fragrance and mix again.
- i) Leave the product to settle for 12–24 hours before packing.

2. STRONGER PREMIUM FLOOR GLAZE FORMULA

Batch Size: 5 Litres

Ingredients

Ingredient	Quantity	Purpose
Clean water	3 litres	Main solvent
Acrylic binder / floor polish resin	1 litre	Main shine and protective film
PVA binder	700 ml	Adds body and adhesion
Wax emulsion	200 ml	Improves gloss and floor protection
Silicone oil	100 ml	Smooth finish and shine
Texapon / SLES	50 ml	Helps mixing
Preservative	20 ml	Prevents bad smell/spoilage
Fragrance	20–30 ml	Optional
Colour	Small amount	Optional

Procedure

- a) Add 3 litres clean water into a clean mixing bucket.
- b) Add 50 ml Texapon / SLES and stir gently.
- c) Add 1 litre acrylic binder / floor polish resin slowly while mixing.
- d) Add 700 ml PVA binder and mix until smooth.
- e) Add 200 ml wax emulsion and continue stirring.
- f) Add 100 ml silicone oil slowly and mix very well.
- g) Add preservative, fragrance, and colour.

- h) Mix for another 5–10 minutes.
- i) Allow the glaze to rest overnight before use or selling.

How to Use the Floor Glaze

- a. Clean the floor first. Remove dust, mud, oil, and soap residue.
- b. Apply a thin layer using a clean mop, sponge, or soft cloth.
- c. Do not pour too much product in one place.
- d. Leave it to dry for 20–40 minutes.
- e. For more shine, apply a second thin coat after the first one has dried.

Important Notes for Students

Do not use caustic soda, sulphuric acid, hydrochloric acid, or battery acid in floor glaze. They can damage floors and burn skin.

For a better product, use acrylic binder because it gives stronger shine and a more professional finish than PVA alone.

If the product becomes too thick, add a little clean water and mix.

If the product separates, increase mixing time and reduce oil quantity next time.

END OF MODULE