GENERAL

There are four main sections to moOde: Playback, Library, CoverView and Configuration.

Switching between Playback and the Library is accomplished by clicking on the cover art in Playback or on any open area of the Playbar in the Library.

PLAYBACK

The Playback screen includes the play queue (Queue), volume and time knobs, playback controls, cover art and metadata.

LIBRARY

The library provides Radio, Folder, Tag, Album and Playlist views for browsing and selecting content and a Playbar for displaying song information and controlling playback. Options for configuring various aspects of the Library including sort order, recently added and more are located in the Library section of Preferences.

SEARCHING THE LIBRARY

Powerful search features are available in Tag and Album view that allow the Library to be filtered based on entered text, tag value pairs or special, predefined filters. These are entered in the search field on the Library menu. There is also an Advanced search dialog that enables multiple tag value pairs to be submitted.

General

Searches are not case sensitive and partial matches are considered valid. Searches are cleared by clicking on the "Filtered by" heading.

NOTE: The search field only supports a single tag value pair or a single Predefined filter. Tag value pairs

The following tags are supported: Any, Genre, Artist, Album, Title, Album Artist, Date, Composer, Conductor, Performer, Work, Comment and File.

Examples: genre rock | artist frank sinatra | artist mccartney | any zeppelin The Any tag

The Any tag performs a search of all tags using an OR relationship. An Any search is

automatically invoked when the first word of text entered in the search field does not match any of the tag or predefined filter names. Examples: yellow submarine | all that you can't leave behind | frank sinatra | 1962

Predefined filters

The following predefined filters are available: Encoded [bits/rate], Format [.ext], Folder [path],

lossy | year 1962 | year 1994-1998

Audio, Network, System and Renderers.

the same as Add and then begins play.

Hdonly, Lossless, Lossy and Year [yyyy] or [yyyy-yyyy]. Examples: encoded 24/96 | encoded 192 | hdonly | format .dsf | folder u2/achtung baby |

COVERVIEW

CoverView section of Preferences. CONFIGURATION

The Configuration screens are accessed via the Main Menu and provide settings for the Library,

The CoverView screen saver provides a large sized cover art image or optional Analog or Digital clock, a Playbar for controlling playback and several backdrop options that can be selected in the

QUEUE

The Queue is displayed in Playback and CoverView and contains all items to be played. It's populated primarily by selecting an item from the Library and then clicking one of the Queue commands listed on a context menu. It can also be populated automatically by Auto-shuffle. The

Queue commands are listed below. Add | Play The "Add" command adds the item to the end of the Queue. The "Play" command first checks to see if the item is already in the Queue and then plays the existing item otherwise it does

Clear/Play

The "Clear/Play" command first clears the Queue then adds the item and begins play.

The "Add next" command adds the item immediately after the currently playing or last played

Add next | Play next

item. The "Play next" command first checks to see if the item is already in the Queue and then plays the existing item otherwise it does the same as "Add next" then begins play. For the track list in Library Tag and Album views the Play and Clear/Play actions can be

configured via a Preferences option to either add the selected track to the Queue or the

selected track and all following tracks. PLAYLISTS Creating, editing and managing playlists is done primarily in Library Playlist view. Playlists can also

be created via context menu items "Save Queue to playlist", "Set Favorites name" and "Add to playlist". Save Queue to playlist The "Save Queue to playlist" command displays a list of available playlists and adds the item

to the end of the selected playlist or a new playlist if one is specified.

 Set Favorites name The "Set Favorites name" command displays an input form for specifying the name of the

playlist that contains items favorited by clicking the Heart \heartsuit button. If the playlist does not

already exist it will be created. Add to playlist The "Add to playlist" command displays a list of available playlists and adds the item to the

end of the selected playlist or a new playlist if one is specified.

MULTIROOM AUDIO

dedicated moOde player configured to output to the integrated HDMI port or optioally the Headphone jack but not connected to any speakers or headphones. It functions solely as a Music Server that Sends its audio output to one or more Receivers. For additional information View Configuration

A moOde multiroom audio system consists of a Sender and Receivers. The Sender should be a

Sender and Receiver options are configured in Multiroom Config which is accessed via Menu/Configure or in the ALSA section of Audio Config. Audio sources including MPD,

AirPlay and Spotify can be distributed by the Sender. Master volume The volume knob on the Sender system provides master volume control by sending the volume change to the Receivers which apply it to their own volume. Receivers can be

configured to opt in or out of Master volume control via Multiroom Config. Receiver control

Receivers can be centrally controlled from the Sender system via the Receivers panel which is accessed by the $\mathbf{\hat{h}}$ button at the top of Playback view. Networking

and hosts. Discovery of Receivers relies on Multicast DNS. Addressing for the audio distribution protocol relies on IP Multicast using a default address of 239.0.0.1.

 Audio format The system uses 16 bit 48 kHz PCM format encoded using the Opus CODEC. Resampling if needed is handled by ALSA using the Speex converter.

The performance of the system depends on having low latency, high throughput networking

SPECIAL MENU ITEMS Most menu items are self explanatory but several perform unique functions.

This item is located on the Main menu. It displays a list of other moOde players discovered on the network. clicking a player opens it's WebUI. If a player is functioning as a Multiroom Receiver the $\mathbf{\Lambda}$ icon will appear next to its name.

சி Audio info This item is located on the Main menu and ellipsis context menus on Playback and Playbar. If its opened from the Main menu it displays hardware related information about the item

→ Players

currently being played and is divided into three sections including Input/Output, DSP and Audio Device. If its opened from the ellipsis context menu it displays metadata information about the station or track currently being played. SPECIAL BUTTONS

Display a menu of available CamillaDSP configurations. This button appears at the top of Playback view when CamillaDSP is On. CoverView

Display full screen CoverView screen saver. clicking anywhere off of the Playbar dismisses CoverView.

Most buttons are self explanatory but several perform unique functions.

Play randomly selected tracks from the Queue (default) or if Auto-shuffle is ON (see Audio Config) play randomly selected tracks or albums from the entire Music Library.

CamillaDSP Quick Select

Remove the track from the Queue after it finishes playing. Consume mode is automatically enabled when Auto-shuffle is ON.

Repeat the Queue or if Single is enabled then repeat the track. C' Single

Repeat

↓ Consume

Used in conjunction with Repeat to repeat a single track.

Randomly select an album from the Music Library and perform the action specified for the

Select a random Album for review when in Tag or Album view. ★ Play a random album

Select random album

"One touch action" setting. This setting is in the Playback section of Preferences. ○ Favorite

Add the currently selected item in the Queue to the Favorites playlist. Playlists are listed in Library Playlist view. ACTIVE ELEMENTS

There are several non-button elements in the UI that perform an action when tapped. One touch action

Toggle between the currently playing item and the last played item.

When clicking a cover in Library Radio or Album view, or clicking the "Play a random album" ★ button in Playback, perform the action specified for the "One touch action" setting. This setting is in the Library section of Preferences.

 Renderer Active screens clicking on the title in the center of Bluetooth, Analog Input or S/PDIF Input Active will launch their respective Configuration screens which allow the input/output settings to be changed.

clicking on the time while a song file is playing will toggle between counting the time up or down. clicking or dragging the time ring moves forward or backward in the song.

Volume knob

Time knob

clicking on the numeric volume level toggles the mute state. clicking ahead on the volume ring advances the volume by a maximum number of steps called the Volume step limit. This limit can be set via Audio Config. clicking the plus/minus buttons adjusts volume by 1 step.

Extra metadata In Playback clicking the extra metadata under the cover art opens the Station or Track tab on the Audio info screen.

 Song title In Playback clicking the song title under the cover art launches a search in a separate Browser tab. The search engine used can be selected in the Playback section of Preferences.

On Smartphones it scrolls the Queue to that item.

scrolled to the station.

 Station or Artist name In Playback clicking the Radio station name or the Artist name under the cover art switches to Radio or Tag view respectively. In Tag view the artist filter is applied. In Radio view the list is

Playback. In Library tag view swiping sideways shows/hides the Genres column.

 Swipe gestures On Smartphones swiping up scrolls the Queue into view and clicking on the Playbar returns to

Close