1.Installation Roll Paper

58 thermal printer using thermal 58mm paper roll, using easy paper loading mechanism, very convenient paper loading.

Thermal printer maximum outer diameter of 75mm.

Thermal paper installation method is as follows:

（1） Open the printer cover.

（2） Thermal paper roll as shown in the following figure into the paper loading position.

（3） Pull out the paper short to box outside, close the top cover.

（4） Remove the excess with a knife-edge machine rolls.

Button Instruction

| POWER（Green／Blue Light)	FEED（Red Light)	Printer Status
OFF	OFF	Turn Off
ON	Flash	Turned on and no paper
ON	ON	Have Paper
In the case of a power, holding the FEED button,		Paper Feed
In the off state and the FEED button while holding down the POWER button, and then release the POWER button for two seconds and then release the FEED button		The printer self-test

2.Driver Installation (for USB Port)

Note: Please make sure the printer is turn on, and the paper is in right direction before this step.

1： Insert the CD driver, and find the driver in the menu (58, 80 series printer driver software), then click it to start the installation, you will see the pictures as below which need to choose the language:

2：Choose the language you will use, and click" OK", you will see following picture. Click " Next":

3： Then you will find following picture, just click " I accept", then "Next":

4. You will see following picture, you can choose the default path, also can save the driver to anywhere you want :

5. Click "Next", then you will find following picture, here choose "Install". If your PC have any anti virus software, please allow this install.


6. After the installation, you will see the following picture, choose the system of the PC you using and the the model of printer you using(POS 58Series Printer). Then click "USB Port Check". If the installation is successful , the printer will print some words to show the installation is ok.

7.Click "Begin Setup",You will see following picture, choose "Install",

   Then "install this driver anyway"

8 : When finish, please find the printer driver"pos 58" in the control panel of your PC,then right click the " Printer Property", you will find the following picture

Select your printer port that matches the "port" option, select the printer you want to feature

in the "device settings". In conventional option "Print Test Page" to verify that OK.

If the Test print is ok, then the printer can working now. If it shows: Error, Please click "Ports' again, choose: USB001, or USB002 , or USB003.